

INSTRUCTIONS
FOR INSTALLING FORD 160-AL SPEEDO.

CAUTION.

GAS TANK IS DIRECTLY
IN BACK OF DASH.
BE CAREFUL WHEN DRILLING.

THIS STICKER IS TO BE PASTED
ON DASH WITH THE BOTTOM EDGE
AT THE BOTTOM EDGE OF DASH.

(A)

WHEN YOU ARE SURE THAT STICKER
IS SECURELY PASTED, AND SQUARE
WITH DASH, DRILL CENTER HOLE 'A'
WITH $\frac{3}{16}$ DRILL AND FASTEN T-39052
IN PLACE. DRILL ONE CORNER HOLE,
INSERT PIN AND DRILL ALL REMAIN-
ING HOLES. USE $\frac{3}{16}$ DRILL FOR
ALL HOLES.