



IMPORTANT

Directions for Installing Sure-Fit One-Man Tops

Loosen bottom of old rear curtain, then take nuts off of top rests and lift old top off.

Place one man top on machine and fasten back stay straps where old ones were, then tighten the back straps so it will hold the front of top about one foot above windshield. You then bolt top braces to the center bolt on windshield and draw top down to place. Then when the top is in its proper place, tack the back curtain to car and put button studs on inside of bow sockets to hold the gypsy wings in place.

To fit side curtains just button the rear side curtains to back curtain then hold in position and mark with chalk where eyelets come. Then put the eyelets in and the curtains are completed.

If the curtains are door opening, first fasten the irons between edge of door and latch and slip curtains on the irons and then hold in position and mark for buttons. Use flat head wood screws about 7-8 in., No. 7 or 8.