Price List of Parts—Ford Model T

Ford Motor Company

Main Factory and General Offices
DETROIT, U. S. A.

BRANCHES

ATLANTA
311 Peachtree Street
BOSTON
147 Columbus Avenue
BUFFALO
1048 Main Street
CAMBRIDGE
195 Massachusetts Avenue
CHICAGO
1444 Michigan Avenue
CINCINNATI
911 Race Street
CLEVELAND
4400 Euclid Ave.
DALLAS
1915 Commerce Street
DENVER
1552 Broadway
DETROIT
1550 Woodward Avenue
FARGO
17 Broadway
FOREIGN DEPT.
18 Broadway, N. Y.
HOUSTON
800 Walker Avenue
INDIANAPOLIS
526 North Capitol Avenue
KANSAS CITY
1608 Grand Avenue
LONDON
57 Shaftesbury Avenue
NEW YORK
1723 Broadway
OMAHA
1916 Harney Street
PARIS
144 Boulevard Pereire
PHILADELPHIA
250 N. Broad Street
PITTSBURG
5925 Baum Street
ST. LOUIS
3667 Olive Street
SEATTLE
532 19th Avenue, North

Canadian Trade Supplied by

The FORD MOTOR CO., of Canada, Limited

WALKERVILLE, ONTARIO

HAMILTON
128 King St. West
MELBOURNE
103 William Street
MONTREAL
7 Park Avenue
TORONTO
106 Richmond St.
WINNIPEG
309 Cumberland Avenue



2 Passenger Open Runabout

Instructions
For Ordering Parts



2 Passenger Torpedo Runabout

1. Order all parts through the nearest Branch or Dealer representing us in your territory, as parts are generally carried in stock by them.

2. Specify model, and give number and name of each part ordered, as well as the machine number.

3. Cash should accompany all orders. If it is desired to have parts shipped C. O. D., a deposit sufficient to cover transportation charges must be remitted with the order.

4. Mail orders must be accompanied by an amount sufficient to cover postage.

5. All prices are net f. o. b. Detroit.

6. Specify whether shipments are to be forwarded by mail, express or freight.

7. Orders for parts should be written separately from correspondence pertaining to other matters, as this will insure prompt handling by the proper department at the factory.



2 Passenger Coupe



5 Passenger Touring Car



6 Passenger Town Car

Telegraph Code

TO save expense, to expedite ordering and for the convenience of those ordering parts, we have arranged a code word for each part of the Model "T" car. In addition to the parts code we list below a brief general code covering miscellaneous instruction, questions and answers relative to the entering and shipping of parts ordered.

¶ In telegraphing an order for parts start with the code telling us how to ship, then use the word for the next part, stating the number required and then give the number of your car.

¶ The following will illustrate how to send in an express order for 8 push rods No. 3058, 1 fan No. 496, and 3 transmission band springs No. 3425:

FORD MOTOR COMPANY,
Detroit, Mich.

Toperig, eight Tubgener, one Tuburbain, three Tubmergin for car No. 2841.

Signed_____

Toperig	Ship to me (us) by express.
Toperkleur	Ship by express to
Topermolen	Ship to me (us) by American Express
Toperoker	Ship to me (us) by U. S. Express
Toperpool	Ship to me (us) by Dominion Express
Topersteen	Ship to me (us) by freight
Toper	Ship to me (us) by mail
Topfton	When and how did you ship parts called for in my (our) telegram of——
Topflutch	When and how will you ship parts called for in my (our) telegram of——
Topfwasser	When and how will you ship parts called for in my (our) letter of——
Topfgeld	Cancel order for parts our (my) telegram of——
Topfgicht	Cancel order for parts my (our) letter of——
Topfkiemer	Add to our (my) telegraph order of——
Topfartig	Will send duplicate shipment by——express at once.
Topfhaar	Will send duplicate order——freight at once.

When writing messages in code, print the code words in capital letters.



Plate 1—Rear Axle Parts

Rear Axle 56″ Tread

Order by these Nos.	Description	Factory No.	Price.	Code Word.
2500	Rear axle assembly	**95E**	**$100 00**	Tubial
2501	Axle housing right (drilled for ⅜" stud No. 2584)	**1B**	**16 00**	Tuability
2501½	Axle housing right (drilled for 13/32" stud No. 2584½)	**1E**	**16 00**	Tuabol
2502	Axle housing left (drilled for ⅜" stud No. 2584)	**2B**	**16 00**	Tuadebant
2502½	Axle housing left (drilled for 13/32" stud No. 2584½)	**2E**	**16 00**	Tuadero
2503A	Axle housing bolt (9/16" long)	**42A**	**05**	
2503B	Axle housing bolt (25/32" long)	**42B**	**05**	
2503C	Axle housing bolt (1-1/16" long)	**42C**	**05**	
2503D	Axle housing bolt (1-⅜" long)	**157**	**05**	
2504	Axle housing bolt nut	**44**	**02**	Tuadials
2505	Axle shaft (Gear secured by double key and pin)	**48**	**2 50**	Tuadibale
2505½	Axle shaft (Gear secured by large key and collar)	**48B**	**2 50**	Tuadonor
2506	Axle shaft washer (fibre)	**39**	**05**	Tuadibas
2507	Axle Shaft babbitt bearing	**51**	**80**	Tuadibil
2508	Axle shaft roller bearing	**97**	**1 00**	Tuadibox
2509	Axle shaft R/B sleeve	**170**	**40**	Tuadiega
2510	Axle housing cap	**56**	**10**	Tuadieot
2510¼	Axle outer R/B steel washer	**199**	**05**	Tuadio
2510½	Axle outer R/B felt washer	**104**	**05**	Tuadin
2511	Differential assembly		**30 00**	Tuadiera
2512	Differential case—left (Machined for 9/16" spider arms)	**10B**	**5 00**	Tuadierect
2512½	Differential case—left (Machined for ⅝" spider arms)		**5 00**	
2513	Differential case—right (Machined for 9/16" spider arms)		**4 00**	
2513½	Differential case—right (Machined for ⅝" spider arms)		**4 00**	
2514	Differential case stud	**52**	**10**	Tuadistes
2515	Differential case stud nut	**53**	**05**	Tuadora
2517	Differential case bushing (bronze)	**19**	**60**	Tuaire
2518	Differential drive gear—40 teeth (Specify whether gear is fastened with screws or rivets)	**12B**	**8 00**	Tuandobil
2519	Differential drive gear screw	**103**	**02**	Tuadones
2519½	Differential gear collar		**05**	
2520	Differential gear (fastened to shaft with double key and pin)	**13**	**2 50**	Tuarismo
2520½	Differential gear (fastened to shaft with large key and collar)	**13B**	**2 50**	Tuaria
2521	Differential gear key (for gear 2520)	**21B**	**10**	Tuarista
2521½	Differential gear key (for gear 2520½)	**36**	**10**	Tuasible
2523	Differential gear pin		**05**	
2523	Differential gear thrust washer (fibre)	**32**	**15**	Tuasion
2524	Differential pinion—12 teeth ... Diameter bushing 9/16	**14**	**1 25**	Tuasive
2524½	Differential pinion (Dia. bushing ⅝)		**1 25**	
2525	Differential pinion bushing (9/16)		**25**	Tuasively
2525½	Differential pinion bushing (⅝)		**25**	
2526	Differential spider with bushing (dia. arms 9/16)	**15**	**2 00**	Tuasoribis
2526½	Differential spider with bushing (dia. arms ⅝)		**2 00**	

Rear Axle—Continued

Order by these Nos.	Description	Factory No.	Price	Code Word
2527	Differential spider bushing	18	40	Tuasso
2528	Differential thrust plate washer (babbitt)	30	50	Tuastene
2529	Differential thrust plate (steel)	31	20	Tuavely
2530	Differential thrust plate pin (13/32" long)	17	05	Tuavement
2531	Differential thrust plate pin (7/32" long)	37	05	Tuaveolen
2532	Differential housing oil plug	817	05	Tuaveolus
2534	Drive shaft and R/A housing stud (1¼" long)	23	05	Tuavident
2535	D/S and R/A housing stud nut	8	05	Tuavidico
2539	D/S housing rear bushing (specify bore)	24C	1 00	Tuavignor
2540	D/S housing front bushing	69	60	Tuavioux
2541	D/S with pinion (specify diameter at rear bushing end)	154	8 00	Tuavitate
2542	Drive shaft only (specify diameter at rear bushing end)	87	3 50	Tuaviza
2543	D/S pinion—11 teeth	18	4 50	Tuavizde
2544	D/S pinion key (Woodruff)	57	10	Tuavizamo
2545	D/S grease cup	195B	25	Tuavizape
2545½	Rear axle grease cup		15	
2546	D/S thrust washer (steel)	22B	15	Tuavizent
2547	Rear radius rod	152	2 50	Tuavizora
2548	Radius rod nut	77	05	Tuavizon
2549	Radius rod lock nut	78	05	Tuavizque
2551	Radius rod bolt	83	05	Tubaccusa
2554	Ball joint support bolt	79	05	Tubacques
2555	Ball joint support bolt nut	80	05	Tubacribu
2557	Hub cam shaft—right	92R	30	Tubact
2558	Hub cam shaft—left	61R	30	Tubactaro
2559	Hub cam shaft bushing	173	20	Tubaction
2560	Hub brake spring	63	05	Tubactrom
2561	Hub spring rivet, per doz.	64	05	Tubadjuva
2562	Cam shaft lever	62	30	Tubadjuz
2563	Cam shaft lever pin	7	02	Tubadmovo
2564	Lever clevis pin	65	02	Tubagrego
2565	Lever clevis pin cotter	66	01	Tubagrest
2566	Brake shoe (cast iron)	55	75	Tubading
2567	Brake shoe support bolt	59	05	Tubalie
2568	Brake shoe support nut	60	05	Tubalar
2570	Brake shoe coil spring	67	05	Tubalbens
2571	Universal joint assembly	151	2 75	Tubalbid
2572	Joint knuckle (male)	45R	1 00	Tubalboat
2573	Joint knuckle (female)	46R	1 00	Tubalbay
2574	Joint knuckle pin	6	05	Tubalbula
2575	Joint ring complete	49	75	Tubalcaid
2576	Joint ring rivets, each	50	05	Tubalkins
2577	Joint housing	70	1 00	Tubaltenu
2578	Joint housing plug	75	05	Tubambige
2579	Ball cap oil hole plug	156	10	Tubambros
2580	Ball cap felt gasket	151B	10	Tubamigue

Drive Shaft Assembly

2581	D/S housing assembly (drilled for ⅜" stud)		14 00	Tubamn
2581½	D/S housing assembly (drilled for 13/32" stud)		14 00	
2582	D/S housing (drilled for ⅜" stud)	74C	9 00	Tubamno
2582½	D/S housing (drilled for 13/32" stud)	74D	8 00	
2583	D/S roller bearing housing (drilled for ⅜" stud)	191	1 00	Tubamla



Plate 2—Roller Bearing Drive Shaft Parts



Plate 3—Front Axle Parts

Drive Shaft Assembly—Continued

Order by these Nos.	Description	Factory No.	Price.	Code Word.
2583½	D/S roller bearing housing (drilled for 13/32" stud)	191B	1 00	
2584	D/S roller bearing stud (⅜" x 4-7/16")	183	10	Tubamlen
2584½	D/S roller bearing stud (13/32" x 4½")	183B	10	
2585	D/S roller bearing housing stud nut (⅜")	184	02	Tubamluc
2585½	D/S roller bearing housing stud nut (13/32")	184B	02	
2586	D/S roller bearing housing set screw	101	05	Tubamdent
2587	D/S roller bearing	192	2 50	Tubamaub
2588	D/S roller bearing distance plate	106	10	Tubamging
2589	D/S ball race	186	60	Tubamgu
2590	D/S ball retainer	190	05	Tubamgone
2591	D/S ball thrust collar	188	30	Tubamg
2592	D/S ball bearings (15) each	187	04	Tubamy
2593	D/S roller bearing sleeve	107	50	Tubameny
2594	D/S and pinion	154B	8 00	Tubamly
2595	D/S with sleeve fitted (straight shaft)	87C	3 50	Tubameud
2595½	D/S only (tapered end)	87D	3 00	
2595½	D/S with sleeve and ball bearing assembly		4 00	
2595¾	D/S with pinion and ball bearing assembly		8 00	
2596	D/S sleeve	163B	50	Tubamfore
2597	D/S pinion (⅞" straight bore)	16B	4 50	Tubambin
2597½	D/S pinion (for tapered shaft)	16C	4 50	
2598	D/S castle nut	124	15	

Rear Axle 60" Tread

2599	Rear axle assembly (roller bearing type)	1727C	100 00	Tubamis
2600	Rear axle housing—right (drilled for ⅜" stud No. 2584)	1701D	16 00	Tubamit
2600½	Rear axle housing—right (drilled for 13/32" stud No. 2584½)	1701E	16 00	Tubamll
2601	Rear axle housing—left (drilled for ⅜" stud No. 2584)	1702D	16 00	Tubamore
2601½	Rear axle housing—left (drilled for 13/32" stud No. 2584½)	1702E	16 00	Tubamor
2602	Rear axle shaft (33" long; gear secured by double key and pin)	1703	2 50	Tubamoty
2602½	Rear axle shaft (33" long; gear secured by large Woodruff key and collar)	1703B	2 50	Tubant
2604	Rear radius rod	1726	2 50	Tubantully
2605	Hub brake pull rod—right	1710E	45	Tubapanto
2606	Hub brake pull rod—left	1721	45	Tubapegth

Front Axle 56" Tread

2690	Front axle assembly	261B	24 00	Tubapenin
2691	Front axle only	202B	8 00	Tubapent
2694	Spindle body—right	203B	2 50	Tubapor
2695	Spindle body—left	204B	2 50	Tubapil
2696	Spindle arm	270	1 00	Tubapan
2697	Spindle arm nut	272	10	Tubapano
2702	Spindle assembly—right	203A	3 50	Tubaperes
2703	Spindle assembly—left	204A	3 50	Tubapeerlo
2704	Stationary cone (inside)	205	30	Tubapkalt
2705	Adjusting cone—right thread	206	25	Tubaquat

Front Axle 56″ Tread—Continued

Order by these Nos.	Description	Factory No.	Price.	Code Word.
2706	Adjusting cone—left thread	207	25	Tubaqueos
2707	Spindle nut—right thread	209B	10	Tubaquilo
2708	Spindle nut—left thread	209B	10	Tubaqulos
2709	Spindle washer	210	05	Tubarabun
2710	Spindle bolt	211B	50	Tubarando
2711	Spindle bolt nut	212	05	Tubarator
2713	Spindle body bushing (pair)	223	50	Tubardust
2714	Spindle arm bushing	225	20	Tubarosa
2715	Spindle oiler	218	15	Tubaresco
2716	Spindle connecting rod with yoke	264	2 60	Tubarmale
2717	Spindle con. rod with ball pin only	268	2 00	Tubasper
2718	Spindle con. rod bolt (2-7/16")	216	05	Tubassam
2719	Spindle con. rod bolt nut	231	05	Tubasese
2721	Spindle con. rod yoke	248	60	Tubastam
2722	Steering yoke clamp bolt (1-5/32" long)	250	05	Tubastane
2723	Steering yoke clamp bolt nut	251	02	Tubastape
2725	Steering gear con. rod only (½" x 20 th'd)	258	30	Tubastsl
2725½	Steering gear con. rod only (⅜" x 18 th'd)	258B	30	Tubasta
2726	Ball socket assembly	266	1 00	Tubastato
2726½	Ball socket assembly (for 2725½)	266B	1 00	Tubta
2727	Ball socket	253	50	Tubastava
2727½	Ball socket (for 2725½)	253B	50	Tubtas
2726	Ball socket cap	254B	20	Tubasto
2729	Ball socket bolt	255	05	Tubastral
2730	Ball socket nut	256	03	Tubaud
2732	Ball socket lock nut (20 th'd)	259A	05	Tubaurabs
2732½	Ball socket lock nut (13 th'd)	259B	05	Tubaubs
2733	Front radius rod	263	4 00	Tubaurad
2734	Front radius rod nut	245	05	Tubaurtos
2736	Front radius ball cap	217	20	Tubauster
2738	Front radius rod ball cap screw (⅝—24 th'd)	810	05	Tubbajlas
2739	Front radius rod ball cap screw (⅝—16 th'd)	810B	05	Tubaj

Front Axle 60″ Tread

2760	Front axle only	1720B	8 00	Tubazlt
2761	Steering spindle connecting rod	1725	2 60	Tubhajnon
2762	Steering gear con. rod only	1719	30	Tubbajtoz

Wheels

2800	Front wheel—red	291	8 00	Tubbace
2801	Front wheel—green	291	8 00	Tubbadon
2802	Front wheel (Specify Pearl or French gray)	291	8 00	Tubbagrot
2802½	Front wheel—blue	291	8 00	Tubbagoat
2803	Front hub assembly (1909-10 type)	200	6 00	Tubbalas
2804	Outer race (small)	234	50	Tubbalbe
2805	Inner race (large)	235	60	Tubbame
2806	Outer ball retainer	236	10	Tubbanous
2807	Inner ball retainer	237	10	Tubbabante
2808	Dust ring (steel)	238	25	Tubbaste
2809	Felt washer	239	05	Tubbaiano
2810	Large balls (⅜")	241	05	Tubbiase
2811	Small balls (¼")	249	04	Tubbiavan
2812	Rear wheel—red	99	8 00	Tubbibets
2813	Rear wheel—green	99	8 00	Tubbicor
2814	Rear wheel (Specify Pearl or French gray)	99	8 00	Tubbidade



Plate 4 Wheels and Parts



Plate 5—Frame, Fender and Tank Parts

Wheels—Continued

Order by these Nos.	Description	Factory No.	Price.	Code Word.
2814½	Rear wheel—blue	99	8 00	Tubbidonor
2815	Rear hub (1909-10 type)	102	5 00	Tubbibims
2816	Rear hub key	26	05	Tubbibo
2817	Rear hub pin	27	02	Tubbibent
2818	Rear hub brake drum	3	1 00	Tubbiello
2819	Hub cap	240	60	Tubbisato
2820	Hub bolt (2" x 5/16")	28A	05	Tubbracha
2821	Hub bolt nut (5/16"—18 th'd)	29A	03	Tubbrado
2822	Hub flange (5½" dia.)	233A	60	Tubbrevia
2823	Front hub assembly (1911 type)	200B	6 00	Tubbalas
2824	Rear hub assembly (1911 type)	102B	5 00	Tubbibims
2825	Hub bolt (2 x ⅜")	28B	05	Tubrach
2826	Hub bolt nut (⅜"—16 th'd)	29B	02	Tubrad
2827	Hub flange (6" dia.)	233B	60	Tubrev

Frame

2850	Frame assembly	300	15 00	Tubcandid
2851	Side member—right	301	5 00	Tubacarre
2852	Side member—left	302	5 00	Tubeaudal
2853	Front cross member	303	2 50	Tubcaute
2854	Rear cross member	304	2 50	Tubcaurn
2855	Front corner bracket—right	305	50	Tubcavabo
2856	Front corner bracket—left	306	50	Tubcava
2857	Rear corner bracket—right	307	50	Tubcaves
2858	Rear corner bracket—left	308	50	Tubcaveux
2863	Body bracket (on frame)	344	15	Tubcentda
2864	Side member—left (Runabout)	383	5 00	
2865	Side member—right (Runabout)	384	5 00	

Runabout—Gasoline Tank

2875	Gasoline tank (16½ gals.)	1990	10 00	Tubcal
2876	Filler cap	2315	30	Tubcar
2877	Sediment bulb	2341	30	Tubcane
2878	Feed pipe	1394	40	Tubcasse
2879	Feed pipe clip	1395	05	Tubcam
2880	Tank bolt (5/16 x 2½")	2345	05	Tubcat
2881	Tank bolt nut	2347	03	Tubca
2882	Tank bolt washer	2346	01	Tubces
2883	Tank stop cock	1343	35	Tubcer

Touring Car—Gasoline Tank

2900	Gasoline tank (10 gals)	1303	4 00	Tubcerna
2901	Filling plug	1317	30	Tubcerno
2902	Sediment bulb	1319	35	Tubcernut
2903	Tank bolt (25/32" long)	1320	05	Tubclavio
2904	Tank bolt (29/32" long)	1323	05	Tubcomnun
2905	Tank bolt nut	1321	03	Tubconque
2907	Stop cock	1343	35	Tubconsay
2908	Pet cock	1342	25	Tubcontin
2909	Feed pipe	1364	40	Tubcoxques
2910	Feed pipe pack nut	1374	05	Tubcoquo

Fenders 56" Tread

2925	Front fender—left (round extension cap front end) specify color	1413	4 00	Tubcorted
2926	Front fender—right (round extension cap front end) specify color	1414	4 00	Tubcortex
2927	Rear fender—left (with hole in apron for fender iron) specify color	1415B	3 50	Tubcosyn

Fenders—Continued

Order by these Nos.	Description	Factory No.	Price	Code Word.
2927½	Rear fender—left (without hole in apron for fender iron) specify color	1415	3 50	Tubcortom
2928	Rear fender—right (with hole in apron for fender iron) specify color	1416B	3 50	Tubcoyter
2928½	Rear fender—right (without hole in apron for fender iron) specify color	1416	3 50	Tubcostal
2929	Front fender iron (right or left)	343	1 00	Tubcrania
2930	Rear fender iron (right)	342B	1 50	Tubcrowd
2931	Rear fender iron (left)	349B	1 50	Tubcroyler
2932	Fender iron bolt (29/32" long)	345	05	Tubcruned
2933	Fender iron bolt (1-1/32" long)	347	05	Tubcrnot
2934	Fender iron bolt nut	346	03	Tubcanald
2935	Fender eye bolt	1942	15	Tubcunozr
2936	Fender eye bolt washer	1943	03	Tubcunuah
2937	Fender eye bolt nut	1944	03	Tubcunuth

Running Board 56" Tread

2941	Running board (Pressed steel)	1410B	1 00	Tubcunutt
2942	Running board metal shield—left	1408	2 50	Tubcurvos
2943	Running board metal shield—right	1409	2 50	Tubcustos
2944	Running board fender bolt	1944	05	Tubculile
2945	Running board fender bolt nut	1347	02	Tubdebous
2946	Running board bracket	336	75	Tubdeacana
2947	Running board truss rod (front)	338	40	Tubdecupe
2947½	Running board truss rod (rear)	371	40	Tubdecup
2948	Running board truss rod nut	339	02	Tubdefend
2949	Running board bolt	340B	05	Tubdegnoy
2950	Running board bolt nut	341	02	Tubdelero
2951	Running board fender bolt washer	1959	03	Tubdeloth
2952	Running board metal shield for Town Car (left)	1731	2 50	Tubdelom
2953	Running board metal shield for Town Car (right)	1732	2 50	Tubdelore

Fenders and Running Boards 60" Tread

3875	Front fender—right	1715	4 00	Tubdelta
3876	Front fender—left	1716	4 00	Tubdelsog
3877	Front fender iron (right and left)	1713	1 00	Tubdeming
3878	Rear fender iron—left	1711	1 50	Tubdentick
3879	Rear fender iron—right	1712	1 50	Tubdentory
3880	Running board metal shield—right	1717	2 50	Tubfrpyic
3881	Running board metal shield—left	1718	2 50	Tubdegrin
3882	Running board brackets, each	1714	75	Tubdercip
3883	Running board truss rods, each	1708	40	Tubdestirn
3884	Running board metal shield for Town Car—right	1732	2 50	
3885	Running board metal shield for Town Car—left	1731	2 50	

Running Boards

(Used on cars numbered below 2500).

1410	Running board complete—right		4 00	Tubcurote
1411	Running board complete—left		4 00	Tubcurral
1412	Running board rubber matting		1 00	Tubcurrod
1421	Running board brass (rear end)		30	Tubcutano
1422	Running board brass (left outside)		75	Tubdamus
1423	Running board brass (front end)		30	Tubdeacon
1424	Running board brass screw		01	Tubdealas
1425	Running board brass (right outside)		75	Tubdealbo



Plate 6—Motor Parts

Plate 7—Motor Parts

Running Boards—Continued

Order by these Nos.	Description	Factory No.	Price.	Code Word.
1486	Running board brass (left outside)		75	Tubdean
1487	Running board brass (right inside)		75	Tubdeary
1488	Running board brass screw (½ inch)		01	Tubdebamus
1344	Running board fender bolt		05	Tubdebile
1347	Running board fender bolt nut		02	Tubdebous
340	Running board bolt		05	Tubdela

Motor (Thermo-Syphon)

3000	Cylinder with valve covers	400B	24 00	Tubdiat
3001	Cylinder head	401C	4 00	Tubdianon
3001½	Cylinder head for metric thread foreign spark plug			
3002	Cylinder head copper gasket	402B	75	Tubdiboul
3003	Cylinder head cap screw (7/16 x 2-7/16")	483B	05	Tubdicken
3003½	Cylinder head cap screw		05	
3004	Cylinder head outlet connection	446C	25	Tubdictol
3005	Cylinder head outlet connection copper gasket	445B	15	Tubdidrom
3006	Cylinder head outlet hose (3½" long x 2" inside)	448B	30	Tubdienez
3007	Cylinder head outlet hose clip	607B	10	Tubdifido
3008	Cylinder head outlet connection screw (1-21/64" long)	550C	05	Tubdigitor
3009	Cylinder cover (front end)	403B	1 25	Tubdivory
3010	Cylinder cover bolt (13/16" long)	589	05	Tubdilosty
3011	Cylinder cover cap screw	432	05	Tubdimida
3012	Cylinder cover felt	504	10	Tubditasm
3013	Cylinder cover paper liner	505B	05	Tubditeck
3014	Cylinder cover bolt (1-7/32" long)	484	05	Tubditolt
3015	Cylinder water inlet connection (cast iron)	442B	25	Tubditoyer
3016	Cylinder water inlet connection screw (1½" long)	597	05	Tubditunck
3018	Cylinder water inlet gasket	596	15	Tubdiuray
3019	Cylinder water jacket plug	557	10	Tubdivid
3020	Piston complete (3 ring type)	586B	2 50	Tubdixons
3021	Piston only (3 ring type)	418C	2 00	Tubdiyert
3022	Piston pin	419B	50	Tubdizolt
3022¼	Piston Pin Bushing (2 pcs.)		30	
3023	Piston ring	422	17	Tubdoctor
3024	Connecting rod (no bushing in upper end)	587B	2 50	Tubdodder
3025	Connecting rod cap bolt	489B	05	Tubdoghot
3026	Connecting rod cap bolt nut	490	03	Tubduable
3027	Connecting rod cap bolt cotter pin	500	01	Tubducmus
3029	Connecting rod clamp screw (1" long)	578	05	Tubductur
3030	Crank shaft	498B	12 00	Tubdudery
3031	Crank shaft rear bearing cap	405B	1 10	Tubduniot
3032	Crank shaft front bearing cap	406B	1 00	Tubdvort
3033	Crank shaft center bearing cap	407B	1 00	Tubdupcat
3034	Crank shaft bearing bolt (center and front) 6-1/16" long)	408	15	Tubduplas
3035	Crank shaft bearing bolt nut	409	05	Tubdorrum
3036	Crank shaft rear bearing bolt (4-7/16" long)	478	15	Tubduros
3037	Crank shaft center bearing brass liner	501B	05	Tubdecorn
3038	Crank shaft center bearing brass liner	502B	05	Tubdedurl

Motor (Thermo-Syphon)—Continued

Order by these Nos.	Description	Factory No.	Price.	Code Word.
3039	Crank shaft rear bearing brass liner (Brass liners furnished .002, .004 or .006 thick as required)	503B	05	Tubdenock
3040	Crank shaft starting pin (2-11/16" long)	529B	05	Tubdepeir
3041	Cam shaft	410	6 00	Tuberamid
3042	Cam shaft front bearing	411	50	Tuberanol
3043	Cam shaft center bearing	412B	40	Tubervrox
3044	Cam shaft rear bearing (bronze)	413	30	Tubexcuse
3045	Cam shaft bearing ring	534	05	Tubexplic
3046	Cam shaft bearing set screw	414	05	Tubfeudo
3047	Cam shaft gear—large	415	1 50	Tubfeum
3048	Cam shaft gear—small	416	1 00	Tubfeunos
3049	Cam shaft gear dowel pin	417	05	Tubfidros
3050	Cam shaft large gear lock nut	475	15	Tubfolice
3051	Cam shaft small gear key	477	05	Tubfolion
3052	Exhaust and inlet valve	424B	30	Tubfolius
3053	Exhaust and inlet valve bushing	428	15	Tubfolom
3053½	Valve bushing for Cylinder with enclosed valves	428B	15	
3054	Intake valve spring	430	10	Tubfumes
3055	Exhaust valve spring	431	10	Tubfuscus
3056	Valve spring seat	425	05	Tubfusk
3057	Valve spring seat pin	429	01	Tubgenine
3058	Push rod	426	30	Tubgener
3059	Push rod bushing (brass)	427	20	Tubgenus
3059½	Push rod bushing (iron)	427B	15	
3060	Exhaust pipe	511	1 50	Tubgibeux
3061	Exhaust pipe pack nut—brass	518	40	Tubglabre
3062	Inlet pipe	512	2 00	Tubglacal
3063	Inlet and exhaust pipe gasket	513	05	Tubgronde
3064	Inlet and exhaust pipe gland	514	05	Tubhashtab
3065	Inlet and exhaust pipe clamp	515	15	Tubhaste
3066	Inlet and exhaust clamp stud (3-5/16" long)	516	05	Tubhircos
3067	Inlet and exhaust pipe clamp nut	517	03	Tubhircum
3068	Breather pipe (brass 1¼" long)	582	20	Tubicurry
3069	Crank and trans. case assembly	1526B	20 00	Tubidreso
3069½	Crank case front end bearing		1 50	
3070	Crank case and cyl. gasket—left	886	10	Tubiendo
3071	Crank case and cyl. gasket—right	887	10	Tubieron
3072	Crank case and cyl. cover cap screw	433	05	Tubrfott
3073	Crank case arm bolt-side (2¼" long)	479	05	Tubigites
3074	Crank case arm bolt-top (25/32" long)	480	05	Tubilla
3075	Crank case arm bolt nut	481	03	Tubilmer
3076	Crank case front end frame bearing	320B	60	Tubilnasty
3077	Crank case front end bearing cap	321	40	Tubilnes
3078	Crank case front end bearing screw	322	05	Tubilmima
3079	Crank case overflow pet cock	1515	25	Tubimock
3080	Trans. drain cup-plug	817	05	Tubimos
3081	Crank case oil tube	543B	50	Tubimudy
3082	Crank case oil tube clamp (on magneto coil support)	548B	10	Tubimughot
3083	Trans. case arm block—wood	890	05	Tubinana
3084	Engine pan—right	1330	60	Tubinanis
3085	Engine pan—left	1331	60	Tubinda
3086	Trans. pan—left	1332	30	Tubindate
3087	Trans. pan—right	1333	30	Tubindebat
3088	Engine and trans. pan bolt	1335	05	Tubindece
3089	Engine and trans. pan nut	1336	02	Tubundeso



Plate 8—Motor Parts



Plate 9—Commutator Parts

Motor (Thermo-Syphon)—Continued

Order Nos. by these	Description	No. Factory	Price.	Code Word.
3100	Crank case with lower cover	800D	20 00	
3101	Crank case lower cover.....	1582	1 00	
3102	Crank case lower cover gasket	1586	10	
3103	Crank case lower cover screw	1584	03	
3110	Cylinder valve cover	656	40	
3111	Cylinder valve cover gasket	660	06	
3112	Cylinder valve cover stud	654	10	
3113	Cylinder valve cover thumb nut..	655	05	

Motor—Pump Circulation

(Used on Cars 1 to 2500).

400	Cylinder with head assembled ..		28 00	Tubdelega
400A	Cyl. only (7/16" holes for cap screws)		24 00	Tuonelock
401	Cyl. head (⅜" holes for cap screws)		4 00	Tubdelury
401B	Cyl. head (7/16" holes for cap screws)		4 00	Tubdement
402	Cyl. head gasket		75	Tubdented
403	Cyl. cover (front end)		1 25	Tubdepost
483	Cyl. head cap screw (⅜")		05	Tubdigens
483B	Cyl. head cap screw (7/16")		05	Tubdepostun
446	Cyl. head outlet brass connection (⅜")		60	Tubdiacox
446B	Outlet brass connection (7/16" bolt)		60	Tubdibbel
550	Outlet brass conn. screw (⅜") ..		05	Tubdigite
550B	Outlet conn. screw (7/16")		05	Tubdihot
445	Outlet brass conn. gasket		15	Tubdiala
448	Outlet hose (1⅝ inside x 4¼) ...		40	Tubdialet
554	Outlet hose clip		10	
505	Cyl. cover paper liner		10	Tubditas
442	Cyl. water inlet brass connection		30	Tubdited
444	Cyl. water inlet pack nut		15	Tubdituro
566B	Piston assembly (3 ring type—used with connecting rod having piston pin bushing).....		2 50	Tubdivine
418	Piston only		2 00	Tubdivisti
419	Piston pin		35	Tubdoceas
420	Piston pin screw		05	Tubdoceba
567	Connecting rod assembly (bushing in head end).....		3 00	Tubdolor
423	Connecting rod piston pin bushing		25	Tubducton
498	Crank shaft		12 00	Tubdument
530	Crank shaft ratchet		40	Tubepinex
529	Crank shaft ratchet pin		02	Tubequal
543	Crank case oil tube		50	Tubepost
520	Crank case front end frame bearing		60	Tubilnem
588	Breather pipe (1" tube).....		90	Tubhoride
800	Crank case and trans. lower case.		20 00	Tubdidres

Commutator

3900	Commutator	404	2 75	Tubindud
3901	Commutator body	457C	1 00	Tubinental
3901B	Commutator body		1 00	
3902	Commutator cover	461B	15	Tubinfer
3902½	Commutator cover thumb nut ...	634	05	Tubinferol
3903	Commutator cover screw (R. H. ⅜" long)	498	02	Tubinfos
3903B	Commutator cover screw (L. H. ⅜" long)		02	
3904	Commutator body screw	463	02	Tubunfoud



Plate 10—Fly Wheel, Magneto and Fan Parts



Plate 10-A Magneto Parts

Plate 11—Transmission Parts

Commutator—Continued

Order by these Nos.	Description	Factory No.	Price.	Code Word.
3205	Commutator brush (State size of roller)	574	75	Tubinfule
3206	Commutator brush cap (steel)	468	05	Tubunsule
3207	Commutator brush cap pin	466	02	Tubintrat
3208A	Commutator fibre (⅝" thick x 2¾" O. D.)	575A	1 00	
3208B	Commutator fibre (¾" thick x 2-11/16" O. D.)	575B	1 00	
3208C	Commutator fibre (11/16" thick x 2-13/16" O. D.)	575C	1 00	
3209	Commutator contact point	464	10	Tubinvine
3210	Commutator contact point nut	472	05	Tubinvito
3211	Commutator contact point fibre insulator	473	05	Tubirate
3212	Commutator thumb nut-brass	467	05	Tubiranno
3213	Commutator felt ring	474	10	Tubiratco
3214A	Commutator roller (5/16" x ⅝").	470B	10	
3214B	Commutator roller (5/16" x ½")	470A	10	
3214C	Commutator roller (15/32 x ⅝")	470C	10	
3214D	Commutator roller (7/16 x 11/16)	470D	10	
3215A	Commutator roller pin (3/16 x ½")	465A	02	
3215B	Commutator roller pin (3/16 x ⅝")	465B	02	
3215C	Commutator roller pin (7/32 x 31/32)	465C	02	
3216	Commutator roller arm (State size roller)	460B	30	Tubireld
3217	Commutator roller arm pin	476	02	Tubiremo
3218	Commutator roller spring	469	05	Tubriams
3219	Commutator roller and arm	571	40	Tubireno
3220	Commutator lock nut	471	10	

Magneto

3250½	Magneto coil assembly (used in connection with 9/16" magnets)	591B	12 00	Tubissoir
3250¼	Magneto coil assembly (used in connection with ⅝" magnets)	591C	12 00	Tubissmar
3252	Magnet coil support screw to crank case	486	05	Tubisse
3254	Magnet bolt (1-5/16" long)	537	05	Tubista
3255	Magnet washer	540	05	Tubistels
3256	Magnet washer screw (1¾" long)	541A	05	Tubitaped
3256½	Magnet washer screw (2" long)	541B	05	Tubitaped
3257	Magnet brass supports (length ¾")	535B	15	Tubitaro
3257½	Magnet brass supports (29/32" long)	535C	15	Tubitaro
3258	Magnet clamp screw wire (44" long)	568	05	Tubitates
3259	Magnet clamp screw wire (36" long)	569	05	Tubitate
3260	Magneto contact assembly (on trans. cover)	1545	50	Tubjacmus
3261	Magneto contact thumb nut	1508	10	Tubjeccent
3262	Magneto contact spring	1509	05	Tubjected
3263	Magneto contact washer (brass).	1510	05	Tubjection
3264	Magneto contact tube with fibre	1516	20	Tubjectif
3266	Magneto insulating fibre washer screw	1505	03	Tubjewel
3269	Fly wheel (style used on cars 1 to 17500)	701	7 00	Tubjubago
3269½	Fly wheel (style used on cars 17500 to 20500)	701A	7 00	Tubjubador
3269¾	Fly wheel (style used on cars above 20500)	701B	7 00	Tubjubacon

Magneto—Continued

Order by these Nos.	Description	Factory No.	Price.	Code Word.
3270	Fly wheel cap screw	721	10	Tubjugdor
3271	Fly wheel dowel pin	722	10	Tubjugete
3272	Magneto coil support shim	584	10	Tubjurtig
3273	Magneto bronze support (used on cars below 2500)	535	3 00	Tubltaron
3275	Magneto (thickness at face 9/16")		75	Tubissimero
3276	Magneto (thickness at face 5/8" used on cars above 29500)		50	Tubissimine
3277	Magneto clamp	623	05	Tubbissiman
3278	Magneto clamp screw	625	05	Tubbissimos
3279	Magneto insulating washer	583	04	Tubissimack

Transmission

3300	Transmission assembly with fly wheel	744B	70 00	Tubjugmos
3301	Trans. Reverse plate assembly	747	6 50	Tubjugorm
3302	Trans. reverse plate	702	2 50	Tubjuncto
3303	Trans. reverse gear (30 teeth)	703	2 75	Tubjunk
3304	Trans. reverse gear bushing	705	1 00	Tubjurm
3305	Trans. reverse plate rivet	708	03	Tublaba
3306	Trans. slow speed plate assembly	748	6 75	Tublabana
3307	Trans. slow speed plate	706	2 50	Tublabend
3308	Trans. slow speed gear (21 teeth)	707	3 00	Tublabia
3309	Trans. slow speed gear bushing	745	1 00	Tublabo
3310	Trans. slow speed plate rivet	708	03	Tublaba
3311	Trans. brake drum assembly	750	10 00	Tublabold
3312	Trans. brake drum only	709	5 00	Tublabone
3313	Trans. triple gear assembly	751B	6 00	Tublabous
3314	Trans. triple gear bushing	716A	50	Tublabrat
3314½	Trans. triple gear flanged bushing	716B	50	
3315	Trans. triple gear shaft	715	50	Tublabriy
3316	Trans. triple gear riveting pin	720	05	Tublacens
3317	Trans. driven gear (27 teeth)	713	2 00	Tublacrim
3318	Trans. driven gear key	714	10	Tublapsar
3319	Trans. driven gear sleeve (on brake drum)	710	4 00	Tublapsi
3320	Trans. driven gear sleeve bushing	754	60	Tublapdodo
3320½	Trans. driven gear thrust washer	761	50	
3321	Trans. driving plate assembly (including clutch fingers)	749	8 00	Tublaquad
3323	Trans. driving plate screw	731	10	Tublarm
3324	Trans. driving plate key	734	10	Tublatart
3325	Trans. driving plate rivet	736	03	Tublatine
3326	Trans. driving plate hub	743	3 00	Tublation
3327	Trans. driving plate bushing	724	50	Tublatoro
3328	Trans. thrust plate (13 small) each	727	30	Tublatuss
3329	Trans. thrust plate (13 large) each	728	30	Tublavams
3330	Trans. distance plate	729	40	Tublavets
3331	Trans. gear shaft	723B	4 40	Tubleten
3332	Trans. clutch disc drum	725B	3 00	Tublectory
3333	Trans. clutch disc drum key	726B	10	Tubledder
3334	Trans. clutch disc drum set screw	752	05	Tublefty
3336	Trans. clutch push ring	704	2 00	Tublegero
3337	Trans. clutch finger	732B	50	Tublet
3337½	Trans. clutch finger screw	756	05	
3337¾	Trans. clutch finger washer	759	01	
3338	Trans. clutch finger pin	735	10	Tublevaba
3340	Trans. clutch spring	737	50	Tublevad
3341	Trans. clutch spring support	738	50	Tublevaen
3342	Trans. clutch spring thrust ring pin	739	10	Tubleveto
3343	Trans. clutch spring thrust ring	740	1 20	Tublevo
3344	Trans. clutch shift	733	2 00	Tublicam



Plate 12—Control Parts

Transmission Cover

Order by these Nos.	Description	Factory No.	Price	Code Word.
3360	Trans. cover complete with pedal assembly (1910)	1563	18 00	Tublicory
	(Square door type—used with closed crank case)			
3360½	Trans. cover complete with pedal assembly (1911)		18 00	
	(Sloping door type—used with crank case having detachable lower plate			
3361	Trans. cover only (1910)	826C	9 00	Tublicutt
3362	Trans. cover bolt (1-1/32")	835B	05	Tublicury
3363	Trans. cover felt	872	10	Tublicyrx
3364	Trans. cover gasket (2 pcs.)	885	15	Tubliderty
3365	Trans. cover door	1546C	75	Tubidurx
3366	Trans. cover door gasket	1547B	10	Tubliefon
3367	Trans. cover door screw	1564	05	Tubliegort
3368	Universal ball cap (rear)	818	75	Tublifort
3369	Universal ball cap (front)	819B	2 50	Tublifuler
3371	Universal ball cap bolt (13/16")	822B	05	Tubligolly
3372	Universal jt. ball cap bolt (1⅛")	1538	05	Tublihogit
3373	Universal ball cap bolt nut	828	03	Tublihurty
3374	Trans. cover bolt (1-7/32")	1570	05	Tublis
3375	Trans. cover screw (1¼")	1567	05	Tublino
3370	Trans. cover with sloping door (1911)	826D	9 00	Tublit
3377	Trans. cover gasket (2 pcs.)	885B	15	Tublito
3378	Trans. cover sloping door	1546D	80	Tublites
3379	Trans. cover sloping door gasket	1547C	10	Tubler
	(Order parts below for Cars numbered below 2500).			
723	Trans. shaft		4 40	Tublease
725	Trans. disc drum		3 00	Tublebe
726	Trans. disc drum key		10	Tublectar
716	Triple gear bushing		50	Tublabrat
712	Driven gear sleeve bushing (2) each		50	Tublaposis

Transmission Control—Three Pedal Type

3400	Trans. clutch release ring (bronze)	741	1 50	Tublimite
3401	Clutch lever	806B	30	Tublimixer
3402	Clutch lever shaft (2⅝" long)	833B	25	Tublimotz
3403	Clutch lever screw	1541	10	Tubloterv
3404	Clutch lever screw nut	1542	05	Tubloyal
3405	Clutch lever pin	1554	03	Tublozerno
3406	Clutch release fork—right	834	50	Tublucana
3407	Clutch release fork—left	894	50	Tublucid
3408	Clutch release fo[illegible] key	836	05	Tublucius
3409	Clutch release fork clamp screw.	835	05	Tubluebat
3410	Clutch release fork clamp screw. wire	837	02	Tublnero
3411	Clutch and reverse lever clevis pin	857	02	Tublumis
3413	Trans. bands (3) each	838B	1 20	Tublunase
3414	Trans. band ear	839B	20	Tubluteos
3415	Trans. band washer	840	02	Tubluxlas
3416	Trans. band raybestos lining	1555	50	Tublyre
3419	Trans. band adjusting screw	1533	15	Tubmacon
3420	Trans. band adjusting screw nut (¾" hole)	1532	05	Tubmagical
3421	Trans. band rivet (3/16" x 7/16") per doz.	842	05	Tubmarnas
3422	Trans. band rivet (3/16" x ⅝") per doz.	843	05	Tubmedial
3423	Trans. band rivet (3/32" x ½") per doz.	844	05	Tubmedlos
3424	Trans. band rivet (3/32" x 7/32") per doz.	845	05	Tubmergo

Transmission Control—Three Pedal Type

Order by these Nos.	Description	Factory No.	Price	Code Word.
3425	Trans. band spring	841B	05	Tubmergin
3426	Trans. band adjusting nut (7/16x 20 th'd)	851	05	Tubmergus
3427	Slow speed shaft	848B	30	Tubmerhuf
3428	Slow speed notch	829B	50	Tubmicky
3429	Slow speed notch pin	1560	03	Tubmidway
3430	Slow speed shaft washer	1559	05	
3432	Speed lever	853B	40	Tubmiggot
3433	Speed lever clevis pin	898	05	Tubmiss
3434	Reverse pedal	853B	1 25	Tubmitoy
3435	Brake and reverse pedal shafts (2) each	849B	20	Tubmixa
3436	Brake and reverse pedal support (2) each	1530	30	Tubmiyave
3437	Brake and reverse support bolts (2) each	1534	10	Tubmotixn
3438	Brake and reverse support bolt nuts (2) each	1535	05	Tubmoyben
3439	Brake pedal	852B	1 25	Tubmuddy
3440	High and slow speed pedal (1910)	854B	1 25	Tubmufatt
3441	Pedal pins (3) each	1553	05	Tubmugerxn
3442	High and slow speed pedal support	1531	30	Tubmumavy
3443	High and slow speed pedal support bolt	1536	05	Tubmuney
3444	High and slow speed pedal support bolt nut	1537	05	Tubmvolit
3445	Slow speed connection	1540	15	Tubmurton
3446	Slow speed connection lock nut.	850	02	Tubmyrgus
3447	Slow speed connection clevis	802	25	Tuboload
3448	Controller quadrant	309B	60	Tuboraxi
3449	Controller shaft with speed lever assembled	887C	1 00	Tubozalt
3450	Controller shaft bracket	311	25	Tubmurmer
3451	Controller shaft bracket felt	314	10	Tubmused
3452	Controller shaft bracket bolt	315	05	Tubmutedo
3453	Controller shaft bracket nut	316	03	Tubmutque
3455	Hand brake lever assembly (1910)	1550	2 50	Tubnascel
3456	Hand brake lever pin	866	02	Tubnataho
3457	Hand brake lever key	874	05	Tubnatds
3458	Hand brake lever pawl	875	20	Tubaviga
3459	Hand brake lever pawl pin	876	05	Tubnavimo
3460	Hand brake lever pawl rod (1910)	877	15	Tubnectes
3462	Hand brake lever pawl lift (includes spring)	879	40	Tubnectum
3463	Hand brake lever pawl lift spring	888	05	
3465	Hub brake lever on controller shaft	864	40	Tubnegart
3466	Hub brake lever pin	865	02	Tubnerons
3467	Hub brake lever clevis	47	25	Tubnerra
3468	Hub brake pull rod—right	891B	45	Tubnervas
3469	Hub brake pull rod—left	1513B	45	Tubnervo
3470	Hub brake pull rod support—right	1387C	15	Tubnerzor
3471	Hub brake pull rod support—left	1398C	15	Tubnethin
3472	Hub brake pull rod support bolt (1" long)	1399B	05	Tubnexis
3473	Hub brake pull rod support bolt nut	1900	02	Tubneyzal
3474	Hand brake lever assembly (runabout)	1590	2 50	
3475	Hand brake lever pawl rod (Runabout)	1593	15	
3476	High and slow speed pedal (runabout)	1591	1 25	
3477	Brake pedal (Runabout)	1592	1 25	

Steering Gear

Order by these Nos.	Description	Factory No.	Price.	Code Word.
3500	Steering gear assembly 1908-10 type (50" long)	900	20 00	Tubneuter
3501	Steering gear rim (13" O. D.)	901	1 60	Tubneutro
3502	Steering gear rim screw	919	05	Tubnexed
3503	Steering gear spider	902	1 60	Tuborno
3504	Steering gear cover	903	1 00	Tubostend
3505	Steering gear cover screw	910	05	Tuboval
3506	Steering gear cover bushing	914	25	Tubovtrac
3507	Steering gear internal gear case	904	1 50	Tuboxice
3508	Steering gear case bushing	905	1 25	Tubpectin
3509	Steering gear quadrant	906	1 20	Tubpenne
3510	Steering gear quadrant pin	907	05	Tubperfor
3511	Steering gear wheel nut	913	20	Tubjetrol
3512	Steering gear tubing assembly (includes gear case, also lead and throttle rods) (27" long)	948	8 00	Tubpiquant
3513	Steering gear tubing flange screw	927	10	Tubplinth
3514	Steering gear tubing flange screw nut	926	10	Tubplinos
3515	Steering gear tubing flange screw washer	925	05	Tublisse
3516	Steering gear post (51" long)	915	2 50	Tubpolar
3517	Steering gear pinions (3) each	916	50	Tubporan
3518	Steering gear pinion pin (⅜" x 1-1/16")	917	06	Tubprefer
3519	Steering gear drive pinion	911	1 00	Tubprior
3520	Steering gear driving pinion key	909	05	Tubpuarto
3521	Steering gear pinion shaft bushing	912	30	Tubradend
3523	Steering gear post castle nut	951	06	Tubradle
3524	Throttle rod	933	50	Tubrados
3525	Lead rod	934	50	Tubralem
3526	Lead and throttle handle(rubber)	918	25	Tubrameal
3527	Lead throttle rod spring	935	10	Tubramoso
3528	Lead & throttle rod collar	936	10	Tubrasos
3529	Lead & throttle rod collar pin	937	05	Tubrasuro
3530	Lead rod lever	946	30	Tubraucid
3531	Throttle rod lever	947	30	Tubraucos
3532	Throttle rod guide	938	40	Tubraudad
3533	Throttle rod and lead lever pin	948	02	Tubray
3534	Commutator pull rod (14" long)	1325B	25	Tubrayater
3535	Carburetor pull rod (13-13/16" long)	1329	20	Tubrayn
3536	Lead lever ball and socket joint	1326	30	Tubrayo
3537	Lead lever ball and socket joint nut	1327	03	Tubrayors
3538	Carburetor pull rod adjustment	1904	15	Tubregang
3539	Steering post bracket with bushing	932	2 50	Tubregano
3540	Steering post bracket bolt (2¼" long)	939	20	Tubregion
3541	Steering post bracket bolt (⅝" long)	940	10	Tubridebe
3542	Steering post bracket bolt nut	941	05	Tubrident
3544	Steering post bracket felt washer	943	10	Tubrigor
3545	Steering post bracket bushing (bronze)	944	1 00	Tubrigous
3546	Steering post bracket block	945	10	Tubrigum
3547	Steering gear ball arm	929B	1 20	Tubrihort
3548	Steering gear ball arm key	930	10	Tubruslon

Steering Gear—1911 Touring Car

3550	Steering gear assembly (56" long)	900B	20 00	
3551	Steering gear rim (15" O. D.)	901B	1 60	
3553	Steering gear spider	902B	1 60	



Plate 13—Steering Gear Parts



Plate 14—Floor Board and Dash with Parts

Steering Gear—Continued

Order by these Nos.	Description	No.	Price.	Code Word.
3553	Steering gear post (53" long) ..	915B	2 50	
3554	Steering gear tubing assembly ..	949B	8 00	
3555	Steering gear tubing flange screw (19/16")	954	10	
3556	Steering gear tubing flange screw (15/16")	956	10	
3559	Steering gear case bushing	905B	1 25	
3560	Throttle lever rod	933B	50	
3561	Lead lever rod	934B	50	
3562	Steering post bracket with bushing	932B	2 50	
3563	Steering post bracket grease cup (For other parts of this assembly see Nos. 3500 to 3548)	955	25	

Steering Gear—1911 Runabout

3575	Steering gear assembly (61" long)	979	20 00	
3576	Steering gear tubing assembly (34" long)	963	8 00	
3577	Steering gear post (59" long)...	959	2 50	
3578	Throttle lever rod	957	50	
3579	Lead lever rod	958	50	
3580	Steering post bracket with bushing ..... (Parts 3551-3552-3555-3556-3563-apply to this assembly: —Other parts listed under Nos. 3500 to 3548.)	953	1 50	

Body Parts—1909-10 Touring Car

3601	Body bracket on body (front end)	1002	10	Tubrogaor
3601½	Body bracket on body (centre and rear)		10	Tubrob
3602	Body bracket connecting bolt (1½" long)	1304	05	Tubroanus
3603	Body bracket connecting bolt (25/32" long)	1305	05	Tubrobnus
3605	Body bracket connecting bolt nut (square)	1307	05	Tubroine
3606	Body bracket bolt nut (hexagon)	1001	03	Tubrole
3607	Tonneau carpet for touring car .	1606	2 50	Tubrond
3607¼	Tonneau carpet for Town car ...		2 50	Tubronde
3607½	Carpet for coupe		2 50	Tubrondel
3609	Tonneau door strap	1605	35	Tubroste
3611	Tonneau door handle	1443	60	Tubrufarm
3612	Tonneau door handle screw	1479	05	Tubrumax
3613	Tonneau door lock—left	1442B	1 50	Tubrumabol
3614	Tonneau door lock—right	1444B	1 50	Tubrunult
3615	Tonneau door lock striker plate (left)	1445B	30	Tubruntla
3616	Tonneau door lock striker plate (right)	1446B	30	Tubrupter
3617	Tonneau door hinge assembly—right	1632	1 00	Tubrustic
3618	Tonneau door hinge assembly—left	1633	1 00	Tubrutile
3619	Tonneau door hinge pin.....	1012	10	Tubruto
3620	Tonneau heel board hinge	1019	15	Tubsaline
3621	Tonneau heel board latch	1020	35	Tubsalsam
3624	Front door rubber matting	1616	3 00	Tubsalt
3626	Floor board (first)	1096B	35	Hubsanact
3627	Floor board (second)	1402B	40	Tubsanerz
3628	Floor board (third)	1404B	30	Tubsanorx

Body Parts—1909-10 Touring Car—Continued

Order by these Nos.	Description	No. Factory	Price.	Code Word
3629	Floor board (fourth)	1403B	35	Tubsatrat
3630	Floor board forward plate for pedals	1400B	50	Tubsayert
3632	Floor board rear plate for pedals	1095B	40	Tubscutid
3633	Floor board plate for side lever	1094B	35	Tubsduty
3634	Dash	1091B	6 00	Tubsdaylen
3635	Dash brass moulding	1063	1 50	Tubsecutos
3638	Dash shield	1097B	20	Tubseqvox
3640	Dash bracket (left)	1017	50	Tubserite
3641	Dash bracket (right)	1018	50	Tubserved
3642	Dash bracket bolt (on frame)	1028	05	Tubservin
3643	Dash bracket bolt nut	1029	05	Tubsessa
3645	Dash bracket top bolt	1039	05	Tubsessle
3646	Dash bracket lower bolt	1032	05	Tubsessix
3649	Dash bracket top bolt nut	1035	03	Tubsessue
3650	Dash bracket lower bolt nut	1036	03	Tubsiccas
3651	Dash to body bracket	1489	15	Tubsidor
3652	Dash to body bracket bolt (on body)	1490	05	Tubsidunt
3653	Dash to body bracket bolt (on dash)	1491	05	Tubsifan
3654	Dash to body bracket bolt nut	1492	03	Tubsifer
3655	Oil lamp bracket—right (touring car)	1497	40	Tubsiform
3656	Oil lamp bracket—left (touring car)	1498	40	Tubsign
3657	Oil lamp bracket brass screw	1503	05	Tubsignal
3658	Oil lamp bracket screw nut	1608	05	Tubsigned
3659	Oil lamp bracket screw washer	1627	03	Tubsimile
3660	Tail lamp bracket (touring car)	1613	25	Tubsimone
3661	Tail lamp bracket bolt	1614	05	Tubsimor
3662	Tail lamp bracket bolt nut	1615	05	Tubsipimo
3663	Gas lamp bracket—right	1301	1 00	Tubsipic
3664	Gas lamp bracket—left	1348	1 00	Tubsipunt
3665	Gas lamp bracket nut	1302	05	Tubsist
3667	Front seat cushion for touring car	1628	12 00	Tubsistis
3670	Rear seat cushion for touring car	1627	12 00	Tubsistor
3667¼	Tourabout front seat cushion—right		6 00	
3667½	Tourabout front seat cushion—left		6 00	
3670¼	Tourabout rear seat cushion—right		6 00	
3670½	Tourabout rear seat cushion —left		6 00	
3671	Oil lamp bracket—right (town car)		1 00	Tubsisten
3672	Oil lamp bracket—left (town car)		1 00	Tubsisdo
3673	Oil lamp bracket—right (coupe)	2200	1 00	Tubsisel
3674	Oil lamp bracket—left (coupe)	2201	1 00	Tubsismen
3675	Tail lamp bracket (coupe)		50	Tubsiscog
3676	Cocoa mat (21 x 32)		3 00	

Body Parts—1911 Runabout

3700	Dash	2558	$ 6 00
3701	Dash bracket—Right	2563	50
3702	Dash bracket—Left	2562	50
3703	Dash brass moulding	2575	1 50
3704	Oil lamp bracket—Right	2577	30
3705	Oil lamp bracket—Left	2578	30
3706	Floor board (First)	2610	30
3707	Floor board (Second)	2611	30

Plate 15—Springs and Parts



Plate 16—Parts for Pump Circulation Motor

Body Parts—Continued

Order by these Nos.	Description	No. Factory	Price.	Code Word.
3708	Floor board (Third)	2612	40	
3709	Floor board (Fourth)	2613	25	
3710	Floor board (Fifth)	2629	25	
3711	Rubber matting		3 00	
3713	Torpedo door-lock—Right		1 25	
3714	Torpedo door-lock—Left		1 25	
3715	Seat with cushion (Open Runabout		40 00	
3716	Seat with cushion (Torpedo)		40 00	
3717	Seat cushion (one piece)		10 00	

Body Parts—1911 Touring Car

3750	Dash	1091B	6 00	
3751	Dash bracket—Left	1017B	50	
3752	Dash bracket—Right	1018B	50	
3753	Dash bracket moulding	1063B	1 50	
3754	Cocoa tonneau mat (31x28)	1606B	3 00	
3755	Door hinge (upper right)	2542	30	
3756	Door hinge (lower left)	2543	30	
3757	Door hinge (lower right)	2544	30	
3758	Door hinge (upper left)	2541	30	
3765	Rear body bracket	2435	40	
3766	Front cushion (state size)	1626B	12 00	
3767	Rear cushion (state size)	1627B	12 00	

"Farm" Roadster Parts

3775	Front seat with cushions (see No. 3715)		
3776	Rumble seat with cushions	$ 12	00
3777	Rumble seat cushion	4	00

Rear fenders, Metal shields, Floor boards and Rubber matting same as 1911 Touring Car. Front fenders, Running Boards, Steering gear and Dash same as 1911 Touring car.

Springs

3800	Front spring (specify color)	332	6	00	Tubsisturn
3801	First leaf (main leaf)	354	1	25	Tubsold
3802	Second leaf	355	1	10	Tubsoil
3803	Third leaf	356	1	00	Tubsoiled
3804	Fourth leaf	357		90	Tubsolad
3805	Fifth leaf	358		75	Tubsolano
3806	Sixth leaf	359		60	Tubsolary
3807	Seventh leaf	360		40	Tubsoltus
3808	Front spring clip	325B		25	Tubsolve
3809	Front spring clip nut	327		05	Tubsolvin
3811	Front spring tie bolt	1362		05	Tubsonaba
3812	Front spring tie bolt nut	1363		02	Tubsortit
3813	Front spring hanger (wide flange)	246		50	Tubsparg
3814	Front spring hanger (narrow flange)	229		50	Tubstrunt
3815	Front and rear spring hanger nut	220		02	Tubsume
3817	Front and rear spring hanger oiler	267		15	Tubtender
3818	Front spring perch—right	222	1	00	Tubtenses
3819	Front spring perch—left	222½	1	00	Tubterago
3820	Front spring perch bushing	230		20	Tubtereba
3821	Front spring perch nut	242		05	Tubterfue
3823	Front spring leather	262		10	Tubtevac

Springs—Continued

Order by these Nos.	Description	No.	Price.	Code Word.
3824	Rear spring	333	14 00	Tubterit
3825	First leaf (main leaf)	361	2 60	Tubtera
3826	Second leaf	362	2 25	Tubtiendo
3827	Third leaf	363	2 00	Tubtillely
3828	Fourth leaf	364	1 75	Tubtileza
3829	Fifth leaf	365	1 50	Tubtilliba
3830	Sixth leaf	366	1 50	Tubtilise
3831	Seventh leaf	367	1 30	Tubtility
3832	Eighth leaf	368	1 10	Tubtimear
3833	Rear spring clip	326	25	Tubtinles
3834	Rear spring clip nut	328	05	Tubtituba
3835	Rear spring clip bar	329	10	Tubtive
3837	Rear spring tie bolt	1352	05	Tubtly
3838	Rear spring tie bolt nut	1353	02	Tubtonic
3840	Rear spring hanger (narrow flange)	91	50	Tubterse
3841	Rear spring hanger (wide flange)	91½	50	Tubtraca
3842	Rear spring leather pad	94	15	Tubtrack
3843	Rear spring perch	41	60	Tubtracto
3844	Rear spring perch bushing	172	20	Tubtraho
3845	Rear spring perch nut	174	05	Tubtrahir
3846	Rear spring clip (Runabout)	399	25	
3847	Front spring retainer clip with rivet		10	
3848	Rear spring retainer clip with rivet		10	

Rear Spring 60" Tread

3850	Rear spring	1704	14 00	
3851	Rear spring clip	1737	25	
3852	Rear spring tie bolt	1738	10	
3853	First leaf (main leaf)	1739	3 60	
3854	Second leaf	1740	2 25	
3855	Third leaf	1741	2 00	
3856	Fourth leaf	1742	1 75	
3857	Fifth leaf	1743	1 60	
3858	Sixth leaf	1744	1 50	
3859	Seventh leaf	1745	1 30	
3860	Eighth leaf	1746	1 10	

Pump

551	Pump assembly		9 00	Tubtrifid
434	Pump body		4 00	Tubtrile
435	Pump Cover		3 00	Tubtrilem
443	Pump cover gasket		10	Tubtrisle
452	Pump cover screw		05	Tubtripos
436	Pump fan		1 00	Tubtrude
437	Pump shaft		1 00	Tubturbin
454	Pump fan pin		01	Tubtuto
451	Pump packing nut (right hand)		25	Tubtutorm
451½	Pump packing nut (left thread)		25	Tubueulam
450	Pump thrust washer (steel)		10	Tubueulo
576	Pump drive gear and shaft		2 50	Tubugularia
438	Pump drive gear only		1 50	Tubule
439	Pump drive gear shaft only		1 00	Tubulines
440	Pump drive gear shaft bushing (rear)		25	Tubulipap
453	Pump drive gear shaft bushing (front)		25	Tubulliped
577	Pump inlet connection assembly		1 00	Tubumdon
556	Pump inlet connection pet cock		30	Tubunctis
455	Pump inlet nut		30	Tubungor
507	Pump inlet hose 1¼ inside x 3¼		30	Tubungual

Pump—Continued

Order by these Nos.	Description	Factory No.	Price.	Code Word.
555	Pump inlet hose clip		10	Tubungunt
456	Pump support screw		05	Tuburb
496	Radiator fan and shaft		2 00	Tuburbain
496½	Radiator fan only		1 00	Tuburpago
497	Radiator fan rivet		02	Tuburbana

Starting Crank

3900	Starting crank only	519B	1 00	Tuburbiqit
3901	Starting crank handle (rubber)	520	40	Tuburbio
3902	Starting crank handle bolt	521	20	Tuburend
3903	Starting crank sleeve (steel tubing)	523B	30	Tubutten
3905	Starting crank ratchet pin (1⅜" long)	527B	05	Tubvonder
3906	Starting crank ratchet	528B	35	Tubvutigo
3907	Starting crank strap	1963	30	Tubvuzelt
3908	Starting crank spring (brass)		05	Tubvolt
519	Starting crank only		1 00	Tuburbial
522	Starting crank handle bolt nut		05	Tuburimus
523	Starting crank sleeve		50	Tuburran
524	Starting crank collar pin		02	Tubvadem
525	Starting crank collar		25	Tubvectab
526	Starting crank spring		10	Tubvelout
527	Starting crank ratchet pin		02	Tubven
528	Starting crank ratchet		35	Tubvencas

Radiator (Thermo-Syphon)

3925	Radiator-thermo-Syphon	1100C	28 00	Tubvectil
3926	Radiator cap	1103B	50	Tubvedon
3927	Radiator cap gasket (fibre)	1117	05	Tubvenga
3928	Radiator pad (leather)	1105	05	Tubvendla
3929	Radiator stud	1162	05	Tubveno
3930	Radiator stud spring	1152	05	Tubvenol
3931	Radiator stud nut	1154	05	Tubvence
3931½	Radiator stud washer	1161	05	Tubveld
3932	Radiator rod (20¾ long)	1111B	25	Tubvenscot
3933	Radiator rod washer	1112	05	Tubversod
3934	Radiator rod nut	1113	05	Tubverse
3939	Outlet connection pipe (see motor plate)	1121	50	Tubveruly
3940	Outlet connection cock	594	25	Tubvester
3944	Outlet connection hose (1¾ inside x 2¾)	507B	30	Tubvexis
3945	Outlet connection hose clip	554	10	Tubveyix
3946	Radiator stay rod (22¾" long)	1167	25	

Radiator (Pump Circulation)

1100	Radiator (pump circulation)		28 00	Tubvendra
1111B	Radiator stay rod (state length)		25	Tubverif

Radiator Fan (Thermo-Syphon Motor)

3960	Fan & pulley assembly	619	2 00	Tubiah
3961	Fan blades, each	611	25	Tubviabot
3962	Driven fan pulley (brass)	618	1 00	Tubviacod
3963	Fan drive pulley	602	30	Tubviacog
3964	Fan belt	609	60	Tubviacux
3965	Fan tension spring	610	05	Tubviadox
3966	Fan shaft	606	35	Tubviadunt
3967	Fan bracket	604	40	Tubviafule
3969	Fan bracket bolt	605	15	Tubviafyt
3970	Fan oiler assembly	601	20	Tubviagin
3971	Fan oiler body	598	10	Tubviagore
3972	Fan oiler cap	616	10	Tubviahay
3973	Fan adjusting screw	645	10	
3974	Fan adjusting screw lock nut	648	05	

Plate 17—Radiator and Parts

Muffler

Order by these Nos.	Description	Factory No.	Price	Code Word
4025	Muffler assembly	1200B	2 50	Tubvesper
4026	Muffler head-intake	1202B	60	Tubviewes
4027	Muffler shell (outer)	1203	30	Tubvinier
4028	Muffler shell (middle)	1204	25	Tubvinmes
4029	Muffler shell (inner)	1205	60	Tubvoade
4030	Muffler rod only	1206	10	Tubvocalt
4031	Muffler rod nut	1207	05	Tubvolaba
4032	Muffler bracket—exhaust	1217	30	Tubvolem
4033	Muffler bracket—intake	1218	30	Tubway
4034	Muffler bracket bolt	1210	05	Tubworker
4035	Muffler bracket bolt nut	1211	03	Tubyaga
4037	Long exhaust pipe	1214	1 50	Tubygare
4038	Muffler asbestos	1215	15	Tubyhoti
4039	Muffler asbestos bands (tin)	1216	10	Tubyhauz
4040	Rear muffler head with outlet pipe	1221	75	Tubvienta

Hood—Touring Car

4050	Hood—22" long (specify color)	1300	6 50	Tubyugot
4051	Hood handle	1314	25	Tubyugur
4052	Hood clip	1310	10	Tubzuar
4053	Hood clip spring	1311	05	Tubzuril
4054	Hood clip washer	1312	02	Tubcaro
4056	Hood-board—left (22¾" long)	1339	40	Tubccantah
4057	Hood-board—right (22¾" long)	1340	40	Tuccendan
4058	Hood-board bolt	1308	05	Tuccedase
4059	Hood-board bolt nut	1309	02	Tuccedbt
4060	Hood support on dash	1334	1 00	Tuccedemo
4061	Hood support screw	1350	01	Tucceden
4062	Hood clasp (on radiator)	1109B	05	

Hood—Runabout

4070	Hood—24" long (Specify color)	2313	6 50	Tuccedil
4071	Hood block—right (24¾" long)	2305	40	Tuccedot
4072	Hood block—left (24¾" long)	2306	40	Tuccedar

Carburetor (1910 Kingston)

4100	Carburetor complete	9	00
4101	Float		30
4102	Float chamber	2	00
4103	Gasoline valve		50
4104	Gasoline valve operating lever		30
4105	Gasoline valve operating lever shaft		10
4106	Gasoline valve cap		30
4107	Mixing chamber	2	00
4108	Spray nozzle		30
4109	Center chamber	1	00
4110	Gasket for center member		20
4111	Gasoline needle valve		50
4112	Gasoline needle valve set screw		05
4114	Throttle gate screw		05
4115	Throttle gate lever		30
4116	Throttle gate adjusting screw		05
4117	Throttle gate set screw		05
4118	Gasoline intake packing nut		15
4119	Gasoline intake elbow		35
4120	Primer assembly		40
4121	Primer lever only		20
4122	Bronze ball (for air regulation)		10
4123	Retainer cap for balls		40
4124	Constant air supply connection	1	00
4125	Constant air supply connection lock nut		20
4126	Carburetor adjusting rod head		15
4127A	Carburetor adjusting rod bracket		30



Plate 18—Hood, Muffler and Parts

Plate 19—Kingston Carburetor and Parts



Plate 20—Holly Carburetor and Parts

Carburetor (1910 Kingston)—Continued

Order by these Nos.	Description	Price.	Code Word.
4127B	Carburetor adjusting rod bracket for roadster	30	
4128	Carburetor adjusting rod head pin	05	
4129A	Carburetor adjusting rod (18-13/16" long)	25	
4129B	Carburetor adjusting rod (18-23/32" long)	25	
4129C	Carburetor adjusting rod (19½" long)	25	
4131	Carburetor adjusting bracket screw	05	
4132	Carburetor flange bolt	05	
4133	Carburetor flange bolt nut	03	
4134	Carburetor flange gasket	10	
4135	Carburetor priming rod	20	

Carburetor (1910 Holly)

4150	Carburetor complete	9 00	
4151	Float with lever	60	
4152	Float chamber	2 00	
4153	Float chamber gasket	10	
4154	Gasoline valve	60	
4155	Gasoline valve guide	50	
4157	Mixing chamber	2 00	
4158	Mixing chamber nut	40	
4159	Gasoline needle valve	50	
4160	Gasoline needle valve set screw	15	
4162	Throttle lever	25	
4163	Throttle gate lever adjusting screw	05	
4164	Throttle gate lever set screw	05	
4165	Screen holder and screen	40	
4166	Gasoline intake screen	10	
4167	Gasoline intake screen gasket	15	
4168	Primer assembly	60	
4170	Constant air supply	1 00	
4171	Constant air inlet cup screw	10	
4172	Carburetor drain cock	15	

Carburetor—(1911 Holly)

4500	Carburetor complete	$ 9 00	
4502	Mixing chamber top	2 00	
4503	Float chamber	2 00	
4504	Float	60	
4505	Float lever	25	
4506	Float lever pin	10	
4509	Spray needle	35	
4510	Spray nozzle	10	
4513	Mixing chamber nut	25	
4515	Auxiliary air valve	15	
4516	Auxiliary air valve cap	10	
4518	Throttle lever	40	
4522	Inlet needle pack nut	05	
4523	Inlet needle	25	
4524	Inlet needle guide cap	32	
4529	Pet cock	15	
4530	Air inlet elbow	85	
4532	Air inlet elbow nut	05	
4534	Primer assembly	60	
4535	Center member	30	

Coil (Kingston)

Order by these Nos.	Description	Price.	Code Word.
4200	Coil complete	30 00	Tuccinger
4201	Adjusting screw with platinum point	75	Tuccingos
4202	Vibrator spring with platinum point	60	Tuccinico
4203	Vibrator hammer	10	Tuccinide
4204	Adjusting screw lock spring	10	Tucciniel
4205	Adjusting screw bracket	40	Tuccinily
4209	Coil box complete	5 00	Tuccinon
4210	Coil box cover	80	Tuccinore
4211	Coil box cover fastener—lower	15	Tuccivus
4211½	Coil box cover fastener—upper	15	Tuccivus
4212	Coil bracket	50	Tuccivut
4214	Coil bracket stud nut	05	Tucclades
4215	Coil units, each	6 00	Tucclamea
4216	Coil unit fastener and vibrator bar	25	Tucclamo
4217	Coil unit fastener thumb nuts, each	05	Tuccalvio
4218	Vibrator unit cover (fibre)	15	Tuccollad
4219	Switch plug	25	Tuccullo
4220	Switch lever	25	Tuccomba
4221	Switch cover	25	Tuccombe
4222	Switch base assembly	75	Tuccomed
4223	Hexagon nuts on bottom of coil, each	05	Tuccosta
4224	Springs for terminal connection, each	10	Tuccosita
4225	Terminal binding posts with spring	20	Tuccosorm
4226	Terminal binding post porcelain	15	Tuccosos
4227	Terminal binding post thumb nut	05	Tuccotrin
4228	Terminal binding post hexagon nut	05	Tuccour

Coil (Kingston) New Style

4229	Coil box complete	6 00	
4230	Coil box cover	80	
4231	Coil complete	30 00	
4232	Coil unit	6 00	
4233	Switch key	15	
4234	Vibrator spring with platinum point	60	
4235	Adjusting screw with platinum point	75	

Kingston Coil (1911 type—Metal covered units)

4660	Coil assembly	30 00	
4661	Coil unit (metal cover)	6 00	
4663	Vibrator bridge with plat. point	75	
4665	Unit knurled adjusting screw	25	
4666	Vibrator with plat. point	90	
4671	Unit metal cover	60	
4675	Coil box cover	80	
4676	Coil box with cover	6 00	
4697	Switch key	15	
4699	Switch lever assembly	35	
4702	Switch base cover	25	
4705	Switch assembly	1 50	

Heinze Coil

4600	Coil	30 00	
4602	Coil box cover	80	
4604	Coil box with cover	6 00	
4611	Coil unit (male)	6 00	
4612	Coil unit (female)	6 00	

Plate 21—Kingston Coil and Parts



Plate 22—Coil (Kingston) New Style



Plate 23—Jacobson-Brandon Coil and Parts

Heinze Coil—Continued

Order by these Nos.	Description	Factory Nos.	Price.	Code Word.
4613	Adjusting nut and ratchet		15	
4616	Vibrator with platinum point		90	
4618	Vibrator bridge with platinum point		90	
4638	Switch assembly		1 50	
4639	Switch plug		15	
4640	Switch base (includes spring)		75	
4641	Switch cover		25	
4644	Switch lever with knob		35	
4645	Switch lever knob		15	
4646	Switch lever knob set screw		02	

Coil (Jacobson-Brandon)

4251	Adjusting screw		25	Tuccurow
4252	Vibrator spring with platinum point		1 00	Tuccurum
4253	Cross bar with platinum point		75	Tuccurry
4354	Coil box complete		6 00	Tuccurlow
4255	Coil box cover		80	Tuccurbob
4256	Coil units each		6 00	Tuccurdo
4257	Switch complete		2 00	Tuccurgo
4258	Switch plug		25	Tuccurven
4259	Switch lever		35	Tuccurvul
4260	Switch cover		35	Tuccurbal

Wiring

4350	Spark plug wire (15½" long: No. 1 cyl.)	1365	30	Tuccurer
4351	Spark plug wire (12½" long: No. 2 cyl.)	1366	30	Tuccubine
4352	Spark plug wire (8" long: No. 3 cyl.)	1375	25	Tuccubius
4353	Spark plug wire (8¾" long: No. 4 cyl.)	1376	20	Tuccubuer
4354	Spark plug wire terminal	1381	05	Tucculeny
4355	Commutator wires with loom	1951	1 00	Tuccumbat
4356	Commutator wires with terminal, each		10	Tuccumal
4357	Commutator wire terminal (coil end)	1385	03	Tuccumbir
4358	Commutator wire loom only	1378	60	Tuccursen
4359	Commutator wire loom support	1390	05	Tuccursor
4360	Magneto wire to coil	1968	25	Tuccurux
4361	Commutator loom rubber nipple	1964	02	
4362	Commutator wire rubber nipple	1965	03	
4363	Commutator wire support (on dash)	1638	05	
4366	Spark plug wire (17½" long: No. 1 cyl.)	2357	30	
4367	Spark plug wire (14½" long: No. 2 cyl.)	2358	30	
4368	Spark plug wire (10" long: No. 3 cyl.)	2359	25	
4369	Spark plug wire (11" long: No. 4 cyl.)	2360	20	
4370	Magneto to coil wire (11¾" long)	2361	25	

Special Tools

1349	Hub cap wrench	25	
1370	Disc drum puller clamping screw	10	
1387	Adjustable wrench	60	
1902	Screw driver	30	



Special Tools—Continued

Order by these Nos.	Description	No.	Price.	Code Word.
1903	Pliers		50	
1904	Spark plug wrench		30	
1917	Double end wrench		30	
1924	⅜" socket wrench		50	
1925	Cylinder head cap screw wrench		50	
1926	Piston pin set screw wrench		40	
1927	Commutator screw driver		05	
1928	Crank shaft bearing nut socket wrench		40	
1929	Fly wheel cap screw wrench		30	
1930X	Valve spring lifter (includes 1938)		75	
1957	Valve grinder		1 00	
1933X	Rear wheel puller (includes 1934-5)		1 50	
1934	Rear wheel puller cap screw		15	
1935	Rear wheel puller screw		35	
1936X	Cam gear puller (includes 1937)		1 50	
1937	Cam gear puller screw		35	
1938	Valve spring lifter hook		30	
1953X	Transmission clutch drum puller (includes 1370)		1 50	
1974	Drive shaft and rear axle housing stud nut wrench		40	
1975	Rear axle housing bolt nut wrench		50	
1978	Valve seat reamer		2 50	
2318	¾" T Socket wrench (short)		50	
2319	T screw driver for cam shaft set screw		50	
2320	½" T socket wrench		50	
2321	Special L socket wrench for crankshaft bearing bolt nut		50	
2322	¾" L socket wrench		50	
2323	⅝" open end wrench		35	

Special Tools—Continued

Order by these Nos.	Description	Factory No.	Price.	Code Word.
2324	Connecting rod clamp screw wrench		40	
2327	⅝" brace socket wrench (short)		60	
2328	⅝" brace socket wrench (long)		60	
2331	Piston ring squeezer		25	
2332	Magnet screw brace screw driver		50	
2333	Large cam gear lock nut wrench		40	
2335	Cylinder head bolt L socket wrench		50	

Roadster Body

4402	Front seat with cushions		40 00	Tubor
4403	Front seat cushions, per pair		12 00	Tudel
4403¼	Front seat cushion—right		6 00	Tudelor
4403½	Front seat cushion—left		6 00	Tudeled
4404	Rumble seat with cushion		10 00	Tudlet
4405	Rumble seat cushion		4 00	Tudhob
4406	Rumble seat lock		80	Tudhog
4408	Front floor rubber matting		3 00	Tudhave
4409	Rear floor rubber matting		3 00	Tudy

Cotter Pins

3/32 x 1" Cotter pins	1/8 x 3/4" Cotter pins		
3/32 x 3/4" Cotter pins	1/16 x 3/4" Cotter pins		
3/32 x 1/2" Cotter pins	1/16 x 1/2" Cotter pins		
1/8 x 1" Cotter pins			
Price, each			01
Price, per dozen			05
Price, per gross			25

Fenders and Running Boards
1911 Touring Car—56" Tread—Blue

4800	Front fender—right	1414B	4 00	
4801	Front fender—left	1413B	4 00	
4802	Rear fender—right	1416C	4 00	
4803	Rear fender—left	1415C	4 00	
4804	Rear fender iron (right and left)	379	40	
4805	Rear fender iron bolt	386	05	
4806	Rear fender iron nut	387	03	
4807	Rear fender iron lock washer	388	03	
4808	Front fender iron bolt (1⅛")	389	05	
4812	Running board—right	2530	1 00	
4813	Running board—left	2531	1 00	
4814	Running board shield—right	1409B	2 50	
4815	Running board shield—left	1408	2 50	
	Front fender iron (See No. 2929)			

Fenders and Running Boards
1911 Touring Car—60" Tread—Blue

Order by these Nos.	Description	Factory No.	Price.
4820	Front fender—right	1715B	4 00
4821	Front fender—left	1716B	4 00
4822	Rear fender—right	1749	4 00
4823	Rear fender—left	1748	4 00
4824	Rear fender iron (right and left)	2700	40
4825	Front fender iron (right and left)	1713	1 00
4826	Running board shield—right	1717B	2 50
4827	Running board shield—left	1718B	2 50
	Running board brackets (see No. 3882)		
	Running board truss rods (see No. 3883-4)		

Fenders and Running Boards
1911 Runabout—56" Tread—Blue

4840	Front fender—right	2561	4 00
4841	Front fender—left	2562	4 00
4842	Rear fender—right	2555	4 00
4843	Rear fender—left	2554	4 00
4844	Rear fender iron—right	382	1 50
4845	Rear fender iron—left	381	1 50
4846	Running board—right	2551	60
4847	Running board—left	2552	60
4848	Running board shield—right	2557	2 00
4849	Running board shield—left	2556	2 00

Fenders and Running Boards
1911 Runabout—60" Tread—Blue

4860	Front fender—right	2708	4 00
4861	Front fender—left	2707	4 00
	Front fender-iron (right and left)	See No. 3877	
4863	Rear fender—right	2708	4 00
4864	Rear fender—left	2709	4 00
4865	Rear fender iron—right	2704	1 50
4866	Rear fender iron—left	2705	1 50
4867	Running board shield—right	2703	2 50
4868	Running board shield—left	2710	2 50