Ford

PRICE LIST

—OF—

Parts and Accessories

Model T

APRIL 1st
1919

Prices subject to change without notice

Ford Motor Company

FORD FACTORIES AND BRANCHES

Ford Factory, Detroit—*Parent Plant*
Ford Factory, Ford, Ontario, Canada
Ford Factory, Manchester, England

AMERICAN WHOLESALE BRANCHES

Atlanta	Cleveland	Fargo	Los Angeles	Oklahoma City	Salt Lake City
Boston	Columbus	Houston	Louisville	Omaha	San Francisco
Buffalo	Dallas	Indianapolis	Memphis	Philadelphia	Scranton
Charlotte	Denver	Jacksonville	Milwaukee	Pittsburgh	Seattle
Chicago	Des Moines	Kansas City, Mo.	Minneapolis	Portland	Washington
Cincinnati	Detroit	Long Island City	New Orleans	St. Louis	

FOREIGN BRANCHES AND SERVICE STATIONS

Bordeaux, France	London, Eng.	Montreal, Que.	Toronto, Ont.
Buenos Aires, Argentina	London, Ontario	Paris, France	Vancouver, B. C.
Calgary, Alta.	Manchester, Eng.	Saskatoon, Sask.	Winnipeg, Manitoba
Hamilton, Ont.	Melbourne, Aus.	St. John, N. B.	

Foreign Department—New York
There are Ford Agents in all Principal Cities

Instructions for Ordering Parts

1—Order all parts through the nearest Branch or Dealer.

2—Always give **Catalog Number** and **Name** of each part ordered.

3—Mail and Parcel Post orders must be accompanied by an amount sufficient **to cover Postage.**

4—All prices are net f. o. b. Branch, Factory or Dealer.

5—Specify how shipments are to be made.

6—Orders for parts should be written separately from correspondence pertaining to other matters.

Telegraph Code

To save expense, to expedite ordering and for your convenience, we have arranged a code word for each part of the Ford Model T car. In addition, we list below a brief General Code covering miscellaneous instructions, questions and answers relative to the shipment of parts.

Toperig—Ship to me (us) by express.

Toperkleur—Ship by express to ———

Topersteen—Ship to me (us) by freight.

Toper—Ship to me (us) by parcel post.

Topfton—When and how did you ship parts called for in my (our) telegram of ———

Topflutch—When and how will you ship parts called for in my (our) telegram of ———

Topfwasser—When and how will you ship parts called for in my (our) letter of ———

Parts Price List Index

	Page
Axle—Front	7
Axle—Rear	3
Body Parts	20
Carburetor	26
Carburetor Attachments	26
Coil and Parts—Spark	26
Commutator	13
Cotter Pins	34
Fan	25
Fenders	26-31
Frame	9
Gasoline Tank	9
Hood	25
Horn	35
Lamps	35
Magneto	13
Motor	9-12-13
Muffler	25
Nuts	34
Radiator—Thermo Syphon	25
Running Board and Shields	31
Springs	21
Starting Crank	25
Steering Gear	17
Tools	31
Tops	35-36
Transmission	13
Transmission Control	16
Transmission Cover	16
Truck Parts	37-39
Wheels	7
Windshields	35
Wiring	26

PRICE LIST OF PARTS

FORD MODEL T 1909-1919

EFFECTIVE APRIL 1st, 1919

Part No.	Name of Part	Year	Specifications	Price	Code Word	Fac. No.	Req. per Car	Mailing Weight
REAR AXLE								
2500	Rear axle assembly	1909-19	56-inch tread	$80 00	Aband	95E	1	
2501	Axle housing—right	1915-19		10 00	Absolve	2835C	1	
2502	Axle housing—left	1915-19		10 00	Absume	2836C	1	
2503C	Axle housing bolt and nut		7/16" x 1 1/16"	05	Abject	42C		
2503E	Axle housing bolt and nut		5/16" x 1 1/16"	05	Ajoy	2854	7	
2505	Axle shaft—tapered	1912-19	1 13/16" x 31 7/16"	2 25	Abode	2818	2	8 lb.
2506	Axle shaft washer	1909-19	1 1/2" dia. fibre	03	Abound	39	1	
2508	Axle shaft roller bearing	1909-19	2 11/16" x 4"	1 00	Abrase	97	4	1 lb., 3 oz.
2509	Axle shaft roller bearing sleeve—right	1909-19	4" long	30	Abray	170	2	8 oz.
2509B	Axle shaft roller bearing sleeve—left	1909-19		30	Abate	161	2	8 oz.
2510	Axle housing cap	1909-19	2 13/16" dia.	05	Abroad	56	2	2 oz.
2510A	Axle outer roller bearing steel washer	1909-19	2 11/32" dia.	03	Absinthe	199	2	
2510B	Axle outer roller bearing felt washer	1909-19	2 1/16" dia.	05	Absist	54	2	
2512C	Diff. case—left (no bushing used)	1914-19		1 75	Abut	10D	1	
2513C	Diff. case—right (no bushing used)	1914-19		1 00	Ache	11C	1	
2514	Diff. case stud and nut	1909-15	3/8" x 2 3/4"	10	Arcadian	52-8	3	2 oz.
2514B	Diff. case stud and nut	1915-19	3/8" x 2 1/4"	10	Ale	2865-8	3	
2517	Diff. case bushing	1909-13	1 5/8" bore—1 11/16" dia.	50	Accite	19	2	4 oz.
2518	Diff. drive gear	1909-19	40 teeth	4 00	Accost	12	1	3 lb., 5 oz.
2519	Diff. drive gear screw	1909-19	5/16" x 11/16"	05	Accoy	103	10	
2519A	Diff. gear lock ring	1909-19		03	Acetic	118	2	
2520B	Diff. gear	1909-19	24 teeth	1 75	Ace	13B	2	1 lb., 6 oz.
2521B	Diff. gear key	1911-19	1 3/8" long	05	Acrid	137	2	
2522B	Diff. gear pin		Specify length	03	Acher	2866	2	
2523	Diff. gear thrust washer	1909-14	Fibre, 3 1/16" dia.	10	Actress	32	2	
2524C	Diff. pinion	1915-19	12 teeth	50	Admire	14D	3	
2526B	Diff. spider	1909-19		1 00	Adduce	15D	1	15 oz.
2528	Diff. thrust washer	1909-19	3 3/4" dia. metal	30	Adieu	30	2	6 oz.
2529	Diff. thrust plate	1909-19	3 3/4" dia. steel	15	Adjoin	31	4	3 oz.
2530	Diff. thrust plate pin	1909-16	1/2" long	03	Admix	17	4	
2531	Diff. thrust plate pin	1909-16	7/32" long	03	Adgase	37	2	
2531B	Diff. thrust plate pin	1917-19		03	Age	7640	6	
2532	Diff. housing oil plug	1909-19	3/4" x 24 thds	05	Agger	817	1	
2545	Rear axle grease cup	1909-19		10	Ajar	76		
2547	Rear radius rod	1909-19		3 00	Altar	152	2	4 lb., 9 oz.
2548	Radius rod nut	1909-19	3/8" x 18 thds	05	Amass	77	2	1 oz.
2549	Radius rod lock nut	1909-19	3/8", 18 thds	05	Amber	78	2	1 oz.
2550	Radius rod lock washer	1909-19	3/8"	02	Ambush	2823	2	
2551	Radius rod bolt and nut	1909-19	1/2" x 1 1/2"	10	Amplte	83-60	4	2 oz.
2557	Hub cam shaft—right	1909-19	3 1/8" long	25	Amuck	92B	1	3 oz.
2558	Hub cam shaft—left	1909-19	3 1/8" long	25	Anchor	61B	1	3 oz.
2559	Hub cam shaft bushing	1909-19	1/2" bore, 11/16" dia.	15	Ancient	173	2	1 oz.
2562	Cam shaft lever	1909-19	1/2" bore	20	Arab	62	2	2 oz.
2563	Cam shaft lever pin	1909-19	3/8" x 7/8"	03	Arbor	7	4	
2564	Lever clevis pin	1909-19	5/16" x 1"	05	Arcade	65	4	
2566	Hub brake shoe	1909-19	Cast iron	35	Arctic	2814	2	1 lb., 9 oz.
2567	Brake shoe support bolt and nut	1909-19	1/2" x 1 7/16"	10	Argus	59-60	2	2 oz.
2568	Brake shoe support nut	1909-19	1/2" x 20 thds	05	Armor	60	2	
2570B	Brake shoe coil spring	1913-19	3 5/8" long	03	Asug	2862	4	
2571	UNIVERSAL JOINT ASSEMBLY	1909-19		2 50	Ashore	151B	1	2 lb., 12 oz.
2572	Joint knuckle (male)	1909-19		80	Ashust	45B	1	1 lb.
2573	Joint knuckle (female)	1909-19		1 00	Askew	46B	1	1 lb.
2574	Joint knuckle pin	1909-19	3/8" x 1 3/4"	03	Asleep	6	1	
2575	Joint ring, complete	1909-19	3 1/4" dia.	1 00	Astert	49B	1	13 oz.
2576	Joint ring rivets (per set)	1909-19	1/8" x 1 1/16"	05	Atche	50	4	
2577	Joint housing	1909-14	4 1/8" long	2 00	Atlas	70	1	2 lb.
2578	Joint housing plug	1909-19	1/2" x 20 thds	05	Atom	75	2	
2579	Ball joint grease cup	1909-19	1/4" pipe thds	10	Attic	195	1	5 oz.
2580	Ball cap gasket	1909-19		05	Auburn	1518	1	
2582	D. S. tubing	1911-19	50 5/16" long	9 00	Ballad	153D	1	
2583	D. S. roller bearing housing	1911-19	3 11/16" long	1 50	Ballot	191B	1	2 lb., 12 oz.
2584B	D. S. roller bearing stud and nut	1912-19	11/16" x 4 5/16"	10	Balneal	183B-184	6	3 oz.
2586	D. S. roller bearing housing set screw	1911-19	1/4" x 20 thds	05	Banco	101	1	
2587	D. S. roller bearing	1911-19	2 5/8" long	1 30	Balsam	108	1	1 lb., 3 oz.

Insist upon genuine Ford parts



Plate No. 1



Plate No. 2



Plate No. 3

Part No.	Name of Part	Year	Specifications	Price	Code Word	Fac. No.	Req. per Car	Mailing Weight
REAR AXLE—Continued								
2588	D. S. roller bearing distance plate	1911-19	2 3/32" dia.	$ 0 05	Bandlet	106	1	
2589B	D. S. ball bearing assembly	1911-19		1 00	Bander	185	1	9 oz.
2589	D. S. ball race	1911-19	2 5/8" dia.	40	Bandon	186	1	5 oz.
2590	D. S. ball retainer	1911-19	2 15/32" dia.	03	Bandroe	190	1	
2591	D. S. ball thrust collar	1911-19	2 3/4" dia.	30	Bandault	188	1	3 oz.
2592	D. S. ball bearings, each	1911-19	Order 2811					
2593	D. S. roller bearing sleeve	1911-19	2 3/4" dia., 2 3/8" long	1 00	Bangle	107	1	13 oz.
2595B	D. S. only (tapered)	1911-19	1 1/32" x 5 9/16"	5 00	Banjo	87D	1	13 lb., 8 oz.
2596	D. S. sleeve	1911-19	1" bore, 3 1/16" long	1 00	Banshee	163B	1	6 oz.
2597B	D. S. pinion	1911-19	Taper bore, 11 teeth	1 40	Banwort	16C	1	11 oz.
2598	D. S. castle nut	1911-19	3/4" x 18 thds.	10	Banket	124	1	
2598B	D. S. pinion key	1911-19		05	Banker	57B	1	
2540	D. S. housing front bushing	1909-19	1" bore, 1 3/4" babbitt	60	Balkish	69	1	5 oz.
REAR AXLE—60 INCH TREAD								
2600C	Rear axle housing—right	1915-19	Dia. of ball 9 1/4"	10 00	Bang	2728C	1	
2601C	Rear axle housing—left	1915-19	Dia. of ball 9 1/4"	10 00	Bard	2729C	1	
2602B	Rear axle shaft—tapered	1911-19	1 3/4" x 33 7/16"	2 75	Baptism	2725	2	8 lb., 10 oz.
2604	Rear radius rod	1909-19	53 1/8" tube only	3 00	Barbett	1726	2	4 lb., 10 oz.
FRONT AXLE								
2690	Front axle assembly	1909-19	56" tread	28 00	Barila	261B	1	
2691	Front axle only	1909-19	56" tread	13 00	Barber	202B	1	
2694	Spindle body—right	1911-19		2 50	Bardash	276	1	2 lb., 11 oz.
2695	Spindle body—left	1911-19		2 50	Bardish	277	1	2 lb., 11 oz.
2696	Spindle arm—right or lf	1911-19		75	Bardism	7716	2	12 oz.
2696B	Spindle arm—right	1911-15	With hole for speedometer support	75	Bardo	282	1	12 oz.
2697	Spindle arm nut	1911-19	Order 2548					
2702	Spindle assembly—right	1909-10		5 00	Barkate	203A	1	3 lb., 8 oz.
2703	Spindle assembly—left	1909-10		5 00	Barker	204A	1	3 lb., 8 oz.
2704	Stationary cone	1909-19	1 1/16" bore	20	Barkless	205	2	4 oz.
2705	Adjusting cone—right thread	1909-19	3/4" x 16 thds., R. T.	20	Barley	206	1	2 oz.
2706	Adjusting cone—left thread	1909-19	3/4" x 16 thds., L. T.	20	Barrack	207	1	2 oz.
2707	Spindle nut—right thread	1909-19	3/4" x 16 R. H. thds.	10	Barrow	209B	1	2 oz.
2708	Spindle nut—left thread	1909-19	3/4" x 16 L. H. thds.	10	Baron	208B	1	2 oz.
2709	Spindle washer	1909-19	5/8" hole x 1 3/8"	02	Barras	210	2	
2710	Spindle bolt with oiler	1910-19	1/2" x 6 3/4"	25	Barter	7708	2	7 oz.
2711	Spindle bolt nut	1909-19	Order 2588					
2713	Spindle body bushing (pair)	1909-19	1 1/2" bore	25	Bartram	223	2	2 oz.
2714	Spindle arm bushing	1909-19	7/8" bore, 1 1/8" dia., 1" l.	05	Barwood	225	2	
2715	Spindle oiler	1909-16	Order 3817					
2718B	Spindle oiler cap assembly	1917-19		05	Beard	7702-7705-7707	4	
2715C	Spindle oiler	1917-19		05	Bilge	2944		
2717	Spindle con. rod	1909-19	46 3/4" long	2 00	Basalt	264	1	3 lb., 2 oz.
2718	Spindle con. rod bolt with oiler	1909-19	1/2" x 2 1/4"	20	Basan	7706	2	3 oz.
2719	Spindle con. rod bolt nut	1909-19	7/8" x 20 thds.	05	Bashful	220	2	
2721	Spindle con. rod yoke	1909-19	2 3/4" long	40	Bashule	248	1	5 oz.
2721B	Spindle con. rod yoke ball	1909-19		40	Baroko	226	1	
*2721C	Spindle con. rod yoke	1918-19		40	Barse	248B	1	
2722	Steering yoke clamp bolt and nut	1909-19		05		79 & 8		
2725B	Steering gear con. rod	1909-19	Includes ball sockets	1 00	Baslard	289	1	2 lb., 2 oz.
2728	Ball socket cap	1909-19		15	Basent	254B	2	2 oz.
2729B	Ball socket bolt and nut	1909-19	Order 2722					
2733	Front radius rod	1909-19		3 00	Beardless	263	1	
2734	Front radius rod nut	1909-19	Order 2548					
2736	Front radius rod ball cap	1909-19		15	Beaufet	217	1	3 oz.
2737	Front radius rod ball socket	1911-19		20	Beckon	809B	1	11 oz.
2741	Radius rod ball cap stud and nut	1911-19		05	Berth	4365-8	2	
2742	Radius rod ball cap spr'g	1911-19		03	Bicep	292	2	
2760	FRONT AXLE ONLY	1911-16	60" tread	14 00	Bechance	1720B	1	
2761	Steering spindle con. rod	1909-16	60" tread	2 00	Becket	1736	1	3 lb., 7 oz.
2762	Steering gear con. rod	1909-16	60" tread, includes ball sockets	1 00	Becloud	2739	1	
WHEELS								
2800	Front wheel (specify color)	1909-19	30" x 3"	7 00	Becomb	291	2	
2803	Front hub assembly less flange, bolts and nuts	1909-19		2 50	Bedew	200	2	4 lb., 9 oz.
2804	Outer race	1909-19	1 15/16" dia.	15	Bedfere	234	2	2 oz.
2805	Inner race	1909-19	2 25/32"	20	Bedight	235	2	5 oz.
2806	Outer ball retainer	1909-19	1 13/16" dia.	02	Bedim	236	2	
2807	Inner ball retainer	1909-19	2 17/32" dia.	03	Bedside	237	2	

*When substituting 2721C for old style yoke, also order 2721B Ball.

Insist upon genuine Ford parts



Plate No. 4

Part No.	Name of Part	Year	Specifications	Price	Code Word	Fac. No.	No. Req. per Car	Mailing Weight
WHEELS—Continued								
2808	Dust ring	1909-19	Steel, 2 3/32" dia.	$ 0 05	Bedward	238	2	1 oz.
2809	Front and rear hub felt washer	1909-19	2 1/16" dia.	05	Bedije	239	4	
2810	Large balls, each	1909-19	1/2"	04	Beefing	241	24	
2811	Small balls, each	1909-19	3/8"	03	Beemol	249	22	
2814C	Rear wheel—blue (taper hub)	1912-19	30" x 3 1/2"	7 06	Beggah	2815	2	
2815B	Rear hub (straight bore)	1909-11		2 00	Beggart	40B	2	4 lb., 7 oz.
2815C	REAR HUB (TAPERED) less flange, bolts and nuts	1912-19		1 50	Begol	2819	2	4 lb., 3 oz.
2816B	Rear hub key	1912-19	1/4" x 1/4" x 2 11/32"	05	Begloom	2863	2	1 oz.
2818	Rear hub brake drum	1909-19	3" hole, 8" dia.	70	Beguiler	3	2	2 lb., 9 oz.
2819	Hub cap	1909-19	2 1/16" x 24 thds.	20	Behave	7727	4	3 oz.
2825	Hub bolt and nut	1911-19	3/8" x 2 1/8" x 16 thds.	05	Belay	28B-29B	24	
2827	Hub flange	1911-19	6" dia.	30	Bellow	233B	4	1 lb., 5 oz.
2828	Rear hub lock nut	1912-19	5/8" x 18 thds.	10	Bengal	242	2	2 oz.
FRAME								
2850	Frame assembly	1909-19		15 00	Belone	2916	1	
2851B	Side member—right	1914-19		4 00	Benign	2914	1	
2852B	Side member—left	1914-19		4 00	Berdash	2915	1	
2853	Front cross member	1909-19	22 3/4" long	1 20	Beluga	303	1	3 lb., 15 oz.
2854B	Rear cross member	1914-19		1 60	Bendlet	2913	1	7 lb., 8 oz.
2855	Front corner bracket—right	1909-19		20	Benumb	305	1	8 oz.
2856	Front corner bracket—left	1909-19		20	Bequest	306	1	8 oz.
2857	Rear corner bracket—right	1909-19		20	Besiege	307	1	9 oz.
2858	Rear corner bracket—left	1909-19		20	Bespawl	308	1	9 oz.
2863	Body bracket	1909-19	On frame	15	Bestow	344	4	4 oz.
GASOLINE TANK—TOURING CAR								
2900	Gasoline tank	1909-19	10 gallons	4 00	Bibber	1303	1	
2900B	Gas tank	1916-19	Sedan	8 00	Binocle	7950		
2901	Filling plug	1909-19	2 1/8"	15	Biblist	1317	1	1 oz.
2902B	Sediment bulb	1909-19		1 00	Bickers	2088	1	1 lb., 2 oz.
2909	Feed pipe	1909-19	Touring and Runabout. Also Coupe, 1915-17.	50	Billet	1364	1	4 oz.
2910	Feed pipe pack nut	1909-19	1/2" x 18 thds.	05	Billow	1374	2	
2909B	Feed pipe	1916-19	Sedan	60	Bismuth	7965		
2909C	Feed pipe	1918-19	Coupelet	75	Bisque	9775		
2911	Feed pipe	1915	Sedan, 78" long	1 00	Betrap	1394	1	
2912	Sediment plug	1909-19		05	Blain	8802	1	
MOTOR								
3000	Cylinder	1909-19		27 00	Cabal	400C	1	
3000C	Cylinder	1919	Starter type	30 00	Calcox	400D	1	
3001	Cylinder head	1909-19		7 00	Cabin	401C	1	
3002	Cyl. head gasket	1909-19		40	Caboose	402B	1	5 oz.
3003	Cyl. head cap screw	1909-19	7/16" x 2 3/4"	05	Cackle	483B	15	2 oz.
3003B	Cyl. head cap screw	1918-19	7/16" x 3 1/4"	05	Chub	483C		
3004	Cyl. head outlet connection	1909-16	Cast iron	35	Caddow	446C	1	11 oz.
3004B	Cyl. head outlet connection	1917-19		35	Canis	8719	1	
3005	Cyl. head outlet con. gasket	1909-19		05	Caddy	445B	1	
3006	Cyl. head outlet hose	1909-19	2" x 4"	20	Cadet	448B	1	4 oz.
3007	Cyl. head outlet hose clip	1909-19	2 3/8" dia.	05	Cadger	607B	2	1 oz.
3008	Cyl. head outlet con. screw	1909-19	7/16" x 11/16"	05	Cadmean	550C	2	1 oz.
3009B	Cyl. front cover	1909-19		1 50	Cage	690B	1	2 lb., 1 oz.
3009C	Cyl. front cover	1919	Starter type	2 50	Canard	690C	1	
3010	Cyl. cover bolt and nut	1909-19	3/8" x 7/8"	05	Cafe	1028-8	1	1 oz.
3011	Cyl. cover cap screw	1909-19	3/4" x 11/16"	05	Cahoot	432	3	
3012	Cyl. cover felt	1909-19	Felt	05	Caitiff	504	1	
3013	Cyl. cover liner	1909-19	Paper	02	Cajole	505B	1	
3013B	Cyl. cover liner	1919	Paper—Starter type	03	Cajom	505C	1	
3014	Cyl. cover and crank case bolt and nut	1909-19	3/8" x 1 1/16". Order 2722.					
3015	Cyl. water inlet connection	1909-19	Cast iron	40	Calcine	442B	1	1 lb., 3 oz.
3016	Cyl. inlet con. screw	1909-19	7/16" x 1 1/8"	05	Caldron	597	2	
3017	Time gear cover	1919	Starter type	3 00	Calico	1754	1	
3018	Cyl. water inlet gasket	1909-19	Copper	05	Calefy	596	1	
3019	Cyl. water jacket plug	1909-13	1/2" pipe plug	05	Capin	557	3	1 oz.
3019B	Cyl. water jacket plug	1914-19		02	Canon	5919	3	
3020	PISTON COMPLETE	1909-19	3 1/4" dia.	2 00	Caliph	586C	4	3 lb., 9 oz.
3020C	PISTON COMPLETE	1909-19	.0025" oversize	2 00	Canopy	683A	4	
3020D	PISTON COMPLETE	1909-19	.03125" oversize	2 00	Capon	683C	4	
3020E	PISTON COMPLETE	1909-19	.033" oversize	2 00	Churn	683B	4	
3021	Piston only	1909-19	3 1/4" dia.	1 20	Callous	4472	4	
3021B	Piston only	1909-19	.0025" oversize	1 20	Chopin	5999	4	
3021C	Piston only	1909-19	.03125" oversize	1 20	Chord	5918	4	
3021D	Piston only	1909-19	.033" oversize	1 20	Chute	5901	4	
3022	Piston pin	1909-19		35	Callot	419B	4	4 oz.
3022½	Piston pin bushing (pair)	1909-19		40	Callow	668	4	3 oz.

Insist upon genuine Ford parts



Plate No. 5



Plate No. 6

Part No.	Name of Part	Year	Specifications	Price	Code Word	Fac.No.	Req. per Car	Mailing Weight
MOTOR—Continued								
3023	Piston ring	1909-19	¼″ x 3¾″	$ 0 15	Calmy	422	12	2 oz.
3023B	Piston ring	1909-19	.03125″ oversize	15	Calf	5917	12	
*3024	CONNECTING ROD	1909-19	Includes bearings	2 50	Calvish	641	4	1 lb., 9 oz.
3025	Con. rod cap bolt and nut	1909-19	⅜″ x 2″ x 24 thds.	10	Calyz	489B-490	8	
3029	Con. rod clamp screw	1909-19	⅜″ x 1 1/16″	05	Cambrie	578	4	
3030	CRANK SHAFT	1909-19	25/32″ long	12 00	Camel	498B	1	
3031	C. S. rear bearing cap	1909-19	3 1/8″ long, babbitted	90	Cameo	405B	1	1 lb., 1 oz.
3032	C. S. front bearing cap	1909-19	1 13/16″ long, babbitted	65	Camera	406B	1	10 oz.
3033	C. S. center bearing cap	1909-19	2 3/32″ long, babbitted	65	Camlet	407B	1	10 oz.
3034	C.S.bearing bolt—center and front	1909-19	½″ x 6 1/16″ x 20 thds.	20	Camphor	408	4	6 oz.
3035	C. S. bearing bolt nut	1909-19	Order 2568					
3036	C. S. rear bearing bolt	1909-19	½″ x 4 3/32″	15	Candle	478	2	4 oz.
3038	C.S.bearing liner—center and front	1909-19	1 13/16″ long, brass	01	Cannon	502B	8	
3039	C. S. rear bearing liner	1909-19	3″ long, brass	01	Canny	503B	4	
3040	C. S. starting pin	1909-19	⅜″ x 2¾″	05	Canoe	529B	1	2 oz.
3041	CAM SHAFT	1909-19		4 50	Canteen	410	1	3 lb., 4 oz.
3042	Cam shaft front bearing	1909-19	2″ long	50	Canter	411	1	6 oz.
3043	Cam shaft center bearing	1909-19	2 1/16″ long	35	Canthus	412B	1	6 oz.
3044	Cam shaft rear bearing	1909-19	Bronze, 1 7/16″ long	25	Canto	413	1	3 oz.
3045	Cam shaft bearing ring	1909-19	3/16″ x 1 ⅛″	05	Canvas	534	2	
3046	Camshaftbear'gsetscrew	1909-19	5/16″ x 5/8″	05	Capelin	414	2	
†3047	Timegear—large(on cam shaft)	1909-19	42 teeth	1 00	Caper	415	1	1 lb., 10 oz.
3047B	Timegear—large(on cam shaft)	1919	Spiral	1 25	Clang	415B	1	
†3048	Time gear—small (on crank shaft)	1909-19	21 teeth	90	Capat	416	1	11 oz.
3048B	Time gear—small (on crank shaft)	1919	Spiral	1 00	Claret	416B	1	
3049	Cam shaft gear dowel pin	1909-19	⅜″ x 5/16″	05	Capra	417	2	
3050B	Cam shaft gear lock nut	1909-19		15	Captive	4453	1	2 oz.
3051	Small time gear key	1909-19		05	Capsize	477	1	
3052	Valve	1909-19	Exhaust and inlet	20	Capstan	424	8	3 oz.
3052B	Valve	1909-19	1/64″ oversize stem	20	Cake	5913	8	
3053½	Valve bushing	1909-19	⅝″ O. D. x 2″ long	30	Captain	428	8	2 oz.
3054	Valve spring	1909-19		05	Capture	431	8	1 oz.
3056	Valve spring seat	1909-19	1⅛″ dia.	02	Carack	425	8	
3057	Valve spring seat pin	1909-19	5/64″ x 3/32″	01	Caranx	429	8	
3058	Push rod	1909-19	7/16″ dia., 2 21/32″	15	Carat	426	8	2 oz.
3058B	Push rod	1909-19	1/64″ oversize stem	15	Canine	5914	8	
3059½	Push rod bushing	1909-19	Iron	30	Chippy	427B	8	2 oz.
3060B	Exhaust manifold	1913-19	Iron	1 50	Chirp	4483	1	4 lb., 8 oz.
3061	Exhaust pipe pack nut	1909-19	1 7/8″ x 18 thds.	30	Chitter	518	1	4 oz.
3062	Inlet pipe	1909-19		1 15	Chloris	512B	1	2 lb., 8 oz.
3063	Inlet and exh't pipe gask't	1909-19	1¼″ O. D. copper	03	Choker	513	6	1 oz.
3064	Inlet and exhaust pipe gland	1909-19	1¼″ dia., iron	03	Chopper	514	6	
3065	Inlet and exhaust pipe clamp	1909-19	2¾″ long	15	Choral	515	4	3 oz.
3066	Inlet and exhaust clamp stud and nut	1909-19	⅜″ x 3¼″	10	Chorus	516-517	4	2 oz.
3068	Breather pipe	1909-19	1 5/16″ long	15	Chuck	4468	1	2 oz.
3069B	Crank case front end support	1911-17		75	Clam	801C	1	
3069C	Crank case front end support	1917-19		75	Clack	801D	1	
3070	Cr.case&cyl.gasket-left	1909-19	Felt	05	Clamp	886	1	
3070B	Cr.case&cyl.gasket-left	1909-19	Cork	10	Cider	886	1	
3071	Cr. c.&cyl. gasket-right	1909-19	Felt	05	Clad	887	1	
3071B	Cr. c.&cyl. gasket-right	1909-19	Cork	10	Cigar	887	1	
3072	Crank case and cyl. cover cap screw	1909-19	⅜″ x 1″	03	Cinter	1388	2	
3073	Crank case arm bolt and nut—side	1909-19	⅜″ x 2¼″	10	Clippers	479-8	2	2 oz.
3074	Crank case arm bolt and nut—top	1909-19	⅜″ x 11/32″	10	Circlet	940-8	2	
3076	Crank case front frame bearing	1909-19	Iron	50	Circus	320B	1	1 lb., 6 oz.
3077	Crank case front bearing cap	1909-19	Iron	15	Cizar	321	1	3 oz.
3078	Crank case front bearing screw	1909-19	1/16″ x 7/16″	05	Clabber	322	2	1 oz.
3079	Crank case oil cock	1909-19		20		1515	2	2 oz.
3080	Crankcasedrain cupplug	1909-19	Order 2532					
3080B	Crank case drain cup plug gasket	1909-19		03	Cliff	4339	1	
3081	Crank case oil tube	1909-19		20	Cleavast	543B	1	2 oz.
3083	Crank case arm block	1909-19	Wood	05	Clergy	890	2	3 oz.
3084	Engine pan—right	1909-19		40	Clicket	1330B	1	1 lb., 14 oz.
3085	Engine pan—left	1909-19		40	Clientage	1331B	1	1 lb., 11 oz.
3088B	Engine pan and hood board bolt and nut	1909-19	¼″ x 3¼″	05	Clog	4074-1309	2	
3088C	Engine pan and hood board bolt and nut	1909-19	¼″ x 3⅜″	05	Clod	4073-1309	2	

*Connecting rods requiring new bearings will be exchanged at Branch or Factory for $1.00 each.
†Substitute spiral gears when replacing old style time gears.

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Specifications	Price	Code Word	Fac.No.	Req. per Car	Mailing Weight
MOTOR—Continued								
3100	CRANK CASE WITH LOWER COVER	1912-19		$15 00	Closet	1526E	1	
3101	Crank case lower cover	1912-19	6⅛″ x 15½″	50	Closure	1582	1	2 lb., 13 oz.
3101B	Crank case lower cover reinforcement	1912-19		45	Clothes	4378-4379	1	1 lb., 11 oz.
3102	Cr. c. lower cover gasket	1912-19	Felt	05	Cloud	1586	1	
3102B	Cr. c. lower cover gasket	1912-19	Cork	10	Clotting	1586	1	
3103	Crank case lower cover screw	1912-19	1/16″ x 1/16″	05	Cloudlet	4328	14	
3110	Cylinder valve cover	1912-19	3¾″ x 8″	10	Clovate	656	2	9 oz.
3111	Cyl. valve cover gasket	1912-19	Felt	03	Clown	660	2	
3111B	Cyl. valve cover gasket	1912-19	Cork	05	Cloven	660	2	
3112	Cylinder valve cover stud and nut	1912-19	3/8″ x 2 23/32″	10	Compone	654-517	2	2 oz.
3114	Crank case arm with rivets	1909-19		35	Cloth	815	2	
COMMUTATOR								
3162	Com. case support bolt	1912-19	⅜″ x 2¼″ x 24 thds.	05	Connote	4441	1	2 oz.
3163	Com. case spring	1912-19	3¼″ C. to C.	05	Conoid	689	1	1 oz.
3165	Com. brush only	1912-19		45	Conquest	4481	1	3 oz.
3165B	Com. brush assembly	1912-19		45	Conic	4481BX		
3167	Com. roller	1912-19	11/64″ out. dia., 1/16″ long	10	Consense	673	1	
3167B	Com. plunger	1919		15	Conjure	4474BX		
3168	Com. roller pin	1912-19	1/32″ x 21/32″	05	Conserve	675	1	
3170	Com. roller arm spring	1912-19	Coil spring	03	Consort	469	1	
3170B	Com. plunger spring	1919		03	Conox	4444X		
3173	Com. arm pin	1911-19	1/32″ x 23/32″	03	Contex	476B	1	
3173B	Com. plunger cotter	1919		01	Contour	7992X		
3176	Com. oiler	1912-16	⅛″ pipe thds.	05	Coomb	2383	1	
3176B	Com. oiler	1917-19		05	Coot	480		
3177	Com. felt ring	1912-19	Felt	03	Coombox	5930	1	
3206	Com. brush cap	1909-19	7/16″ dia.	03	Convert	468	1	
3207	Com. brush cap pin	1909-19	1/16″ x 11/16″	02	Convict	466	1	
3210	Com. contact point nut	1910-19	1/16″ hex	02	Cooper	472B	8	
3212	Com. thumb nut	1909-17	No. 10, 32 thds.	05	Copeck	6764	4	
3220	Com. lock nut	1909-19	5/16″ x 18 thds.	05	Crater	471	1	
3221	Com. case with fibre assembled	1912-19		90	Crato	5908	1	
3222	Com. shield	1912-19		03	Crash	5923	1	
MAGNETO								
3250B	Magneto coil assembly	1909-10	Used with 1/16″ magnets. Obsolete — Substitute with 3250D and 3269E.					
3250C	Magneto coil assembly	1911-14	Used with 5/16″ magnets. Obsolete — Substitute with 3250D and 3276B.					
3250D	Magneto coil assembly	1915-19	Used with ¾″ magnets.	7 50	Craft	5941B	1	
3252	Magneto spool support screw	1909-19	Order 3371					
3254	Magnet bolt	1909-19	⅜″ x 1½″	05	Corbeil	537B	16	1 oz.
3255B	Magnet bolt washer	1911-19	21/64″ hole, ⅞″ dia.	01	Corupt	624	16	
3257	Magnet brass support	1909-19	⅝″ x ¾″, brass	05	Cordial	535C	16	
3260	Magneto contact assembly	1909-19	On trans. cover	35	Cormus	1545	1	2 oz.
3261	Magneto contact thumb nut	1909-19	Brass	05	Cornet	1508	1	
3262	Magneto contact spring	1909-19	Coil spring	05	Cornise	1509	1	
3266	Magneto contact fibre screw	1909-19	1/32″ long	01	Cortile	1505B	3	
3267	Magneto primary insulating block	1915-19		05	Crumple	4382		
3268	Fly wheel ring gear	1919	For starter	4 50	Cousin	1885	1	
3269C	Fly wheel	1911-19		5 00	Cosmic	701B	1	
3269E	Fly wheel with magnets assembled	1915-19	¾″ magnets	14 50	Cramp	5946	1	
3269F	Fly wheel with ring gear	1919	Starter type	12 00	Covert	701C	1	
3269G	Fly wheel only	1919	Starter type	7 50	Cozy	1901	1	
3270	Fly wheel cap screw	1909-19	7/16″ x 1 7/16″	10	Cossack	721	4	2 oz.
3271	Fly wheel dowel pin	1909-19	11/32″ x 1 1/16″	05	Costard	722	2	
3272	Magneto coil support shim	1909-19	Sheet steel	05	Costrel	584	1	
3275	Magnet (16) per set	1909-10	Thickness at face ⅝″ Obsolete — Substitute with 3250D and 3269E.					
3276	Magnet (16) per set	1911-14	Thickness at face ⅝″ Obsolete — Substitute with 3250D and 3276B.					
3276B	Magnet (16) per set	1915-19	¾″ set	6 00	Court	5933	16	
3277	Magnet clamp	1911-19		05	Cotland	623	16	
3277B	Magnet clamp	1913-14		05	Cotta	4499	16	
3278	Magnet clamp screw	1911-19	2 23/32″ x 24 thds., brass	05	Cottage	625	16	
3279	Magneto-contact washer	1909-19	On trans. cover	03	Cough	560	1	
TRANSMISSION								
3300	Transmission assembly	1909-19		50 00	Delester	744B	1	
3301	Trans. reverse plate assembly	1909-19		4 00	Dacolt	747	1	4 lb., 14 oz.

Insist upon genuine Ford parts

Plate No. 7



Plate No. 8

Part No.	Name of Part	Year	Specifications	Price	Code Word	Fac. No.	Req. per Car	Mailing Weight
TRANSMISSION—Continued								
3304	Trans. reverse gear bushing	1909-19	2 5/16" rear	$ 0 70	Daddy	705	1	9 oz.
3305	Trans. reverse and S. S. rivet	1909-19	7/32" x 11/16"	per doz.	Dado	708	8	
3306	TRANS. SLOW SPEED PLATE ASSEMBLY	1909-19		3 50	Dagger	748	1	4 lb., 8 oz.
3309	Trans. slow speed gear bushing	1909-19	1 31/32" ream		Dairy	745	1	5 oz.
3310	Trans. brake drum rivet	1909-19	7/32" x 11/16"	per doz.	Daisy	711	8	
3311	TRANS. BRAKE DRUM ASSEMBLY	1909-19		4 50	Dakir	750	1	6 lb., 2 oz.
3313	TRANS. TRIPLE GEAR ASSEMBLY	1909-19		3 00	Dallop	751B	3	2 lb.
3314	Trans. triple gear bushing	1909-10	1" dia. x 1 11/32" long		Dally	716A	3	3 1/2 oz.
3314 1/2	Trans. triple gear flanged bushing	1911-19	1 1/4" dia. x 1 11/32"		Dalriad	716B	3	4 oz.
3315	Trans. triple gear shaft	1909-19	1" dia. x 2 1/2"		Dalrotz	715	3	4 oz.
3316	Trans. triple gear riveting pin	1909-19	5/32" x 1 1/16"	per doz.	Damar	720	24	
3317	Trans. driven gear	1909-19	27 teeth	1 00	Damask	713	1	13 oz.
3318	Trans. driven gear key	1909-19			Dampen	714	2	4 oz.
3320B	Trans. driven gear sleeve bushing	1909-19	1" ream x flange 2 3/16"		Dankish	769	1	4 oz.
3320C	Trans. driven gear sleeve bushing	1909-19	1 1/2" long		Dark	712	1	3 oz.
3321	TRANS. DRIVING PLATE ASSEMBLY	1909-19		4 00	Dannock	749	1	5 lb.
3323	Trans. driving plate screw	1909-19	Order 3371					
3325	Trans. driving plate rivet	1909-19	1/2" x 5/8"	per doz.	Darner	736	8	
*3327B	Trans. driving plate bushing	1909-19	1 1/8" x 1 1/4"		Darsis	772	1	
3328	Trans. thrust plate—small	1909-19	6" dia.		Dauphin	727	12	3 oz.
3329	Trans. thrust plate—large	1909-19	6 3/8"		Davine	728	13	3 oz.
3330	Trans. distance plate	1909-16	6" O. D.		Decry	729	1	7 oz.
3331	Trans. gear shaft	1909-19	1" dia. x 7 1/2" over all	2 50	Decurt	723B	1	2 lb., 10 oz.
3332	Trans. clutch disc drum	1909-19	4 5/16" dia.	1 50	Deeply	725B	1	1 lb., 11 oz.
3333	Trans. clutch disc drum key	1909-19			Defalk	726B	1	
3334	Trans. clutch disc drum set screw	1909-19	3/8" x 3/4"		Defeat	752	1	
3336	Trans. clutch push ring	1909-19	6 1/16" O. D.		Defile	770	1	1 lb., 1 oz.
3337	Trans. clutch finger	1909-19			Define	732	3	3 oz.
3337 1/2	Trans. clutch finger screw	1909-19	6/32" x 3/4" x 24 thds.		Deflour	756	3	
3338	Trans. clutch finger pin	1909-19	11/32" x 1 5/8"		Deform	735	3	1 oz.
3340	Trans. clutch spring	1909-19	2 5/16" dia. x 2 3/4" long		Defoue	737	1	10 oz.
3341	Trans. clutch spring support	1909-19			Delator	738	1	4 oz.
3342	Trans. clutch spring thrust ring pin	1909-19	7/16" x 2 5/16"		Delete	739	1	
3344	Trans. clutch shift	1909-19		1 00	Delight	733	1	14 oz.
TRANSMISSION COVER								
3362	Trans. cover bolt and nut	1909-19	3/8" x 1 1/8", Order 2722					
3363	Trans. cover gasket (front)	1909-19	3/8" x 1/2" x 15 1/2" Felt		Defy	872B	1	
3367	Trans. cover door screw	1909-19	1/4" x 1/2"		Demain	2257B	6	
3368	Universal ball cap (rear)	1909-19	5/8"		Demarch	818	1	15 oz.
3369	Universal ball cap (front)	1909-19	Bearing included	1 25	Demarga	819D	1	1 lb., 14 oz.
3371	Universal ball cap screw	1909-19	3/8" x 1 1/8"		Demise	731	2	
3372	Universal ball cap bolt and nut	1909-19	Order 2722					
3375	Trans. cover screw	1909-19	Order 3072					
‡3376	TRANS. COVER	1911-19		7 50	Denier	826D	1	
3376B	TRANS. COVER	1919	Starter type	7 50	Den	826	1	
3377	Trans. cover gasket (pair)	1909-19	Felt		Dentist	885B	1	pr.
3377B	Trans. cover gasket (pair)	1909-19	Cork		Dennet	885B	1	pr.
3378	Trans. cover sloping door	1911-19	9 1/4" long		Dental	1546D	1	1 lb., 5 oz.
3379	Trans. cover sloping door gasket	1911-19	Felt		Denote	1547C	1	
3379B	Trans. cover sloping door gasket	1911-19	Cork		Denude	1547C	1	
TRANSMISSION CONTROL								
3400	Trans. clutch release ring	1909-19	3 13/16" long		Detail	741	1	6 oz.
3401	Clutch lever	1909-18			Derby	806B	1	4 oz.
†3402	Clutch lever shaft							
3402B	Clutch lever shaft	1913-18			Dine	4344	1	12 oz.
3402C	Clutch lever and shaft with release forks	1913-19		1 20	Dirk	1553-1548-4345	1	1 lb., 8 oz.
3402D	Clutch lever and shaft	1913-19			Disdain	1548		
3403	Clutch lever screw and nut	1909-19	3/8" x 1 1/16"		Dervish	1541-517	1	
3405	Clutch lever pin	1909-19	3/4" x 1 3/8"		Detour	1553	1	
†3406	Clutch release fork—right or left							

*When using short bushing in making repairs remove driving plate key.
†When ordered to replace cover on cars below 2044100 also order 3402B clutch lever shaft.
†Order Number 3402C for use on cars numbered below 175000.

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Specifications	Price	Code Word	Fac. No.	Req. per Car	Mailing Weight
TRANSMISSION CONTROL—Continued								
3406B	Clutch release fork—right or left	1913-19		$ 0 30	Deuce	4345	2	3 oz.
3406C	Clutch release fork pin	1913-19	Order 3405					
3408	Clutch release fork key	1909-14		05	Dilate	836	2	
3409	Clutch release fork clamp screw	1909-14	3/8" x 11/16"	10	Dipper	835	2	
3411	Clutch lever clevis pin	1909-19	Order 2564					
3413	TRANSMISSION BAND ASSEMBLY (Bands will be exchanged at Branch or Factory at 50c each.)	1909-19		75	Disblame	8388	3	1 lb., 2 oz.
3415	Trans. band washer	1909-19	25/64" hole x 3/4" dia.	05	Discure	840	2	
3416	Trans. band lining	1909-19		30	Disedge	1562	3	3 oz.
3419	Trans. band adjusting screw	1909-19	3/4" x 3 1/8"	10	Disfriar	1533	1	4 oz.
3420	Trans. band adjusting screw nut	1909-19	3/4" x 16 thds.	10	Dislimb	1532	1	
3421B	Trans. band ear iron rivet, per doz.	1909-19	3/32" x 5/16"	05	Dismal	843	12	
3422B	Trans. band brass brass rivet, per doz.	1909-19	5/64" x 1/2"	05	Dismast	844B	6	
3423B	Trans. band brass rivet, per doz.	1909-19	3/64" x 5/16"	05	Dismaw	845B	18	
3425	Trans. band spring	1909-19	Coil	05	Dispark	841B	3	
3426	Trans. band adjusting nut	1909-19	7/16" x 20 thds.	05	Displat	851	2	
3427	Slow speed shaft	1909-19	5/8" x 9 3/8"	25	Disputz	848B	1	11 oz.
3428	Slow speed notch	1909-19	On slow speed shaft	30	Distrand	4327	1	5 oz.
3429	Slow speed notch pin	1909-19	1/4" x 1 1/16"	02	Disrobe	1560	1	
3432	Speed lever	1909-19		10	Distaff	862B	1	7 oz.
3434	Reverse pedal	1909-19		80	Disting	4324	1	1 lb.
3435	Brake and rev. pedal shaft	1909-19	3/4" dia. x 7 1/8"	25	Distrite	849B	2	8 oz.
3436	Brake and rev. pedal support	1909-19		25	Distune	4325	2	3 oz.
3437	Brake and rev. support bolt and nut	1909-19	3/8" x 1 1/2"	05	Ditcher	1534-8	2	
3439	Brake pedal	1909-19		80	Dittost	4323	1	1 lb., 2 oz.
3440	Clutch pedal	1909-19		80	Ditty	854B	1	1 lb., 2 oz.
3441	Pedal pin	1909-19	Order 3405					
3442	Clutch pedal support	1909-19		20	Dookad	4326	1	3 oz.
3443	Clutch pedal support bolt and nut	1909-19	3/8" x 2"	05	Doorga	1536-8	1	
3445	Slow speed connection	1909-19		05	Doree	1540	1	
3446	Slow speed con. lock nut	1909-19	1/16" x 24 thds.	03	Doric	44	1	
3447	Slow speed con. clevis	1909-19		15	Dormer	802	1	2 oz.
3448	Controller quadrant	1909-19	On frame	30	Dormouse	309B	1	9 oz.
3449	CONTROLLER SHAFT WITH SPEED LEVER	1909-19		75	Doron	1557	1	3 lb., 15 oz.
3450	Controller shaft bracket	1909-19	On frame	15	Dorrer	311	2	5 oz.
3451	Controller shaft bracket felt	1909-19		01	Dorsal	314	2	
3452	Controller shaft bracket bolt and nut	1909-19		05	Dorture	315-316	4	
3455	HAND BRAKE LEVER ASSEMBLY	1909-19		1 50	Dotant	1550	1	2 lb., 2 oz.
3456	Hand brake lever pin	1909-19	Order 3429					
3456B	Hand brake lever pin	1909-19	Order 2574					
3457	Hand brake lever key	1909-17		05	Doublet	874	1	
3458	Hand brake lever pawl	1909-19		10	Doucet	875	1	
3459	Hand brake lever pawl pin	1909-19	7/16" x 11/16"	03	Doura	876	1	
3460	Hand brake lever pawl rod	1909-19		10	Dovecote	877	1	3 oz.
3462	Hand brake lever pawl lift assembly	1909-19	Handle and spring	10	Dovekie	4363	1	2 oz.
3463	Hand brake lever pawl lift spring	1909-19		02	Dawcet	888	1	
3465	HUB BRAKE LEVER ON CONTROLLER SHAFT	1909-19		20	Dawdy	864	1	3 oz.
3466	Hub brake lever pin	1909-19	Order 3405					
3467	Hub brake lever clevis	1909-19	2 1/16", Order 3447					
3468	Hub brake pull rod—right	1909-19	54 1/8" long	50	Drongo	891B	1	
3469	Hub brake pull rod—left	1909-19	54 1/8" long	50	Dropax	1513B	1	
3470	Hub brake rod support—right	1909-19		10	Dropsy	1367	1	4 oz.
3471	Hub brake rod support—left	1909-19		10	Drugger	1398	1	4 oz.
3472	Hub brake rod support bolt and nut	1909-19	1/4" x 1 1/8"	05	Duchess	1308-1309	2	
STEERING GEAR								
3500C	Steering gear assembly	1911-19	51" long	14 00	Estopped	5042	1	
3500D	Steering gear assembly	1911	60" long, runabout	20 00	Eurus	979	1	
3501B	Steering gear rim	1909-19	15" dia., wood	1 00	Estrade	901B	1	1 lb., 6 oz.
3502	Steering gear rim screw	1909-19	No. 12, 3/4"	02	Eblis	919	4	
3503B	Steering gear spider	1909-19	13 5/8" over all	75	Estrepe	902B	1	1 lb., 10 oz.
3503C	Steering gear spider and rim	1909-19	15" dia.	1 75	Eudora	995	1	
3504	Steering gear cover	1909-19	2 13/16" x 18 thds.	50	Echole	5039	1	10 oz.
3505	Steering gear cover screw	1909-19	No. 6, 32 x 5/8"	02	Eccope	910	1	

Insist upon genuine Ford parts



Plate No. 9



Plate No. 10

Part No.	Name of Part	Year	Specifications	Price	Code Word	Fac. No.	Req. per Car	Mailing Weight
STEERING GEAR—Continued								
3506	Steering gear cover bushing	1909-19	1" long, steel	$ 0 15	Echo	914	1	2 oz.
3506B	Steering gear driving pinion washer	1909-19	Steel	03	Elf	5026	1	
3507	Steering gear internal gear case and bushing	1909-19		1 50	Egg	5036	1	
3509	Steering gear quadrant	1909-19		20	Ectype	906B	1	7 oz.
3510	Steering gear quadrant rivet	1909-19	$\frac{3}{32}$" x 1¼"	01	Eden	5041	2	
3511	Steering gear wheel nut	1909-19	⅝" x 16 thds	10	Edict	913	1	2 oz.
3512C	Steering gear tubing assembly	1912-19	Applies to No. 3500C	6 50	Ethicer	5016	1	
3512D	Steering gear tubing assembly	1911	Applies to No. 3500D	8 00	Euryale	5011	1	
3513B	Steering tubing flange screw and nut	1911-16	$\frac{5}{16}$" x 1$\frac{5}{16}$"	05	Ethule	5019-926	1	
3513C	Steering tubing flange screw and nut	1911-19	$\frac{5}{16}$" x 1$\frac{5}{16}$"	05	Ettle	5018-926	3	
3516C	Steering gear post	1912-19	Applies to No. 3500C	2 50	Estricked	5002	1	
3516D	Steering gear post	1911	Applies to No. 3500D	3 50	Eutaxy	959	1	
3517	Steering gear pinions, each	1909-19	12 teeth	15	Egad	916	3	
3518	Steering gear pinion pin	1909-19	⅜" x 1$\frac{3}{16}$"	05	Egest	917	3	
3519	Steering gear drive pinion	1909-19	12 teeth	40	Egger	911	1	7 oz.
3520	Steering gear drive pinion key	1909-19	$\frac{3}{16}$" sq. x $\frac{31}{32}$"	03	Egma	909	1	
3521	Steering gear pinion shaft bushing	1909-14	⅞" bore x 1½"	45	Egress	912	1	
3523	Steering gear post castle nut	1909-19	Order 2568					
3524E	Throttle rod	1912-19	47 $\frac{31}{32}$" Applies to 3500C	40	Euter	5038	1	1 lb., 3 oz.
3525E	Lead rod	1912-19	51 $\frac{1}{16}$" Applies to 3500C	40	Evans	5037	1	1 lb., 4 oz.
3526	Lead and throttle handle	1909-12	1⅞" long, rubber	15	Elfin	918	2	
3527	Lead and throttle rod spring	1909-19		03	Elite	935	2	
3528	Lead and throttle rod collar	1909-19	$\frac{1}{16}$" bore x $\frac{9}{16}$"	02	Elope	936	2	
3529	Lead and throttle rod pin	1909-19	$\frac{1}{32}$" x $\frac{5}{16}$"	01	Elvan	937	5	
3530	Lead rod lever	1909-19		15	Embank	946	1	
3531	Throttle rod lever	1909-19		15	Ember	947	1	
3532	Throttle rod guide	1909-19	¾" bore	10	Emblem	938	1	
3534	Commutator pull rod	1909-11	14" long	10	Embroil	1325B	1	3 oz.
3534B	Commutator pull rod	1912-19		10	Embrace	2082	1	3 oz.
3535	Carburetor pull rod	1909-19	14 $\frac{5}{16}$" long	10	Emboss	1329	1	3 oz.
3536	Ball and socket joint	1909-19		10	Embraid	1326	1	1 oz.
3537	Ball and socket joint nut	1909-19	$\frac{1}{32}$" x 32 thds	02	Embrute	1327	1	
3539B	Steering post bracket with bushing	1911-19	Touring	1 00	Eupon	996	1	1 lb., 14 oz.
	Steering post bracket bolt and nut	1909-19	Order 3073 or 3074					
3544	Steering post bracket felt washer	1909-19		03	Endow	943	1	
3545	Steering post bracket bushing	1909-19	¾" bore, brass, 2 pieces	30	Envault	944-5027	1	2 oz.
3546	Steering post bracket block	1909-19	Wood	10	Empact	945	1	3 oz.
3547	Steering gear ball arm	1909-19		60	Eparch	929B	1	11 oz.
3548	Steering gear ball arm key	1909-19		05	Ephod	930	1	
BODY PARTS								
3601B	Body bracket on body	1910-19	Center and rear	15	Fabric	1624	6	8 oz.
3602D	Body bracket con. bolt and nut		$\frac{1}{16}$" x $\frac{23}{32}$"	05	Facade	5653-220	6	
3602E	Body bracket con. bolt and nut		$\frac{1}{16}$" x 1 $\frac{1}{32}$"	05	Fade	2431-220	2	
3624E	Front floor rubber matting	1915-19	28¼x29 $\frac{1}{16}$" Tr. & Rb't	1 75	Faith	7299	1	
3626B	Floor board (first)	1915-19	Tour, R'nab't&Coupel't	35	Farm	7296	1	
3627B	Floor board (second)	1915-19	Tour, Runab't&Coupelet	35	Faro	7297	1	
3628	Floor board (third)		Specify size	50	Fasces	1404	1	
3629	Floor board (fourth)		Specify size	35	Fasti	1403	1	
3630	Floor board forward plate for pedals	1909-19	2 $\frac{1}{16}$" x 3⅛"	10	Fateful	1400C	1	6 oz.
3632	Floor board rear plate for pedals	1909-19	2 $\frac{1}{16}$" x 4⅞"	10	Father	1095C	1	12 oz.
3633	Floor board plate for side lever	1909-19	2⅜" x 8¾"	10	Fathom	1094B	1	5 oz.
3634D	Dash	1913-14	21½" x 32¼"	3 50	Flamgo	5336	1	9 lb., 4 oz.
3634E	Dash	1915-16		2 50	Fleet	7462	1	
3634G	Dash	1917-19		2 50	Fringe	8754	1	
3638	Dash shield	1909-19	$\frac{1}{16}$" x 37⅛" x 13¾"	10	Faubit	5432	1	5 oz.
3639	Dash weatherstrip—side	1917-19		05	Flicker	8747	2	
3639B	Dash weatherstrip—top	1917-19		05	Floren	8748	1	
3640B	Dash bracket—left	1911-16	10 $\frac{31}{32}$"	20	Flanker	1017B	1	10 oz.
3640C	Dash bracket—left	1917-19		20	Foal	8722	1	
3641B	Dash bracket—right	1911-16	10 $\frac{31}{32}$"	20	Flannel	1018B	1	10 oz.
3641C	Dash bracket—right	1917-19		20	Fowl	8721	1	

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Specifications	Price	Code Word	Fac. No.	Req. per Car	Mailing Weight
BODY PARTS—Continued								
3642B	Dash bracket to dash bolt and nut	1917-19		$ 0 05	Fume	8740-926	4	
3645	Dash bracket to dash bolt and nut	1909-16	$\frac{5}{16}$" x 1¼" x 18 thds	05	Favos	2427-341	2	
3653B	Dash to body bracket bolt and nut	1915-19	Touring car	05	Feud	4248-341	2	
3654	Dash to body gasket	1918-19		05	Feaze	8769		
3660C	Tail lamp and license bracket assembly	1915-19	Touring car, Sedan, Town car	40	Flour	7506	1	
3660D	Tail lamp and license bracket assembly	1915-19	Runabout and 1916-17 Coupelet	40	Flute	7505	1	
3667E	Front seat cushion	1909-19		8 50	Farce	8076	1	
3670D	Rear seat cushion	1909-19		8 50	Forum	7032	1	
3676B	Tonneau mat	1911-19	30" x 28" wool	1 80	Flatus	1606B	1	
SPRINGS								
3800	Front spring	1909-19		4 00	Gadan	332	1	16 lb., 11 oz.
3801	First leaf (main leaf)	1909-19		1 00	Golf	2943	1	4 lb., 2 oz.
3802B	Second leaf	1909-19		80	Goose	2935	1	3 lb., 7 oz.
3803	Third leaf	1909-19	Tapered ends	70	Gaddish	356	1	2 lb., 11 oz.
3803B	Third leaf	1916-19	Square ends	70	Gopher	2936	1	2 lb., 10 oz.
3804	Fourth leaf	1909-19	Tapered ends	50	Gadoid	357	1	2 lb., 6 oz.
3804B	Fourth leaf	1916-19	Square ends	50	Gosling	2937	1	2 lb., 3 oz.
3805	Fifth leaf	1909-19	Tapered ends	35	Gallic	358	1	1 lb., 13 oz.
3805B	Fifth leaf	1916-19	Square ends	35	Gossip	2938	1	1 lb., 8 oz.
3806	Sixth leaf	1909-19	Tapered ends	30	Gafol	359	1	1 lb., 5 oz.
3806B	Sixth leaf	1916-19	Square ends	30	Gothic	2939	1	1 lb., 1 oz.
3807	Seventh leaf	1909-16	Tapered ends	25	Gaiter	360	1	15 oz.
3807B	Seventh leaf	1916-19	Square ends	25	Gally	2947	1	
3808	Front spring clip	1909-19		20	Galena	325B	2	10 oz.
3809	Front spring clip nut	1909-19	Order 2568					
3811	Front spring tie bolt and nut	1909-19	$\frac{3}{16}$" x 2¼"	06	Galley	1362-1363	1	1 oz.
3813	Front spring hanger	1909-19		30	Gambit	246B	4	4 oz.
3815	Front and rear spring hanger nut	1909-19	Order 2719					
3817	Front and rear spring hanger oiler	1909-19		05	Gamin	218	8	
3818	Front spring perch–right	1909-19		80	Gamut	274	1	15 oz.
3819	Front spring perch–left	1909-19		80	Gander	275	1	15 oz.
3820	Front spring perch bushing	1909-19	$\frac{11}{16}$" x 1½"	05	Gangue	230	4	1 oz.
3821	Front spring perch nut	1909-19	$\frac{5}{16}$" x 18 thds. Order 282S					
3823	Front spring leather	1909-19	1½" x 5¼"	05	Gannet	262	1	2 oz.
3824	REAR SPRING	1909-19	56" tread, 8 leaf	10 00	Ganoid	333	1	
3825	First leaf (main leaf)	1909-19	Tapered ends	2 00	Gantlope	361	1	9 lb.
3825B	First leaf (main leaf)	1918-19		2 00	Gallop	361B	1	
3826	Second leaf	1909-19	Tapered ends	1 60	Gantois	362	1	7 lb., 7 oz.
3826B	Second leaf	1918-19	Square ends	1 60	Galore	362B	1	
3827	Third leaf	1909-19	Tapered ends	1 50	Ganza	363	1	6 lb., 11 oz.
3827B	Third leaf	1918-19	Square ends	1 50	Garnish	363B	1	
3828	Fourth leaf	1909-19	Tapered ends	1 40	Gaphare	364	1	6 lb., 5 oz.
3828B	Fourth leaf	1918-19	Square ends	1 40	Gender	364B	1	
3829	Fifth leaf	1909-19	Tapered ends	1 30	Garden	365	1	5 lb., 13 oz.
3829B	Fifth leaf	1918-19	Square ends	1 30	Genus	365B	1	
3830	Sixth leaf	1909-19	Tapered ends	1 15	Garland	366	1	5 lb., 11 oz.
3830B	Sixth leaf	1918-19	Square ends	1 15	Ghoul	366B	1	
3831	Seventh leaf	1909-19	Tapered ends	1 00	Garlic	367	1	5 lb., 7 oz.
3831B	Seventh leaf	1918-19	Square ends	1 00	Giant	367B	1	
3832	Eighth leaf	1909-19	Tapered ends	85	Garner	368	1	3 lb., 8 oz.
3832B	Eighth leaf	1918-19	Square ends	85	Gimlet	368B	1	
3833	Rear spring clip	1909-19	4 $\frac{1}{16}$"	25	Game	326	2	11 oz.
3834	Rear spring clip nut	1909-19	Order 2548					
3835	Rear spring clip bar	1909-19	$\frac{3}{16}$" x 1⅛" x 4" x $\frac{1}{16}$"	10	Gascon	329	2	7 oz.
3837	Rear spring tie bolt and nut	1909-19	$\frac{3}{16}$" x 2 $\frac{13}{16}$"	06	Gastric	1352-1353	1	2 oz.
3840	Rear spring hanger	1909-19		30	Gaulus	911½B	4	5 oz.
3842	Rear spring leather pad	1909-19	2" x 10¼"	05	Gavel	94	1	2 oz.
3843	Rear spring perch	1909-19		60	Gavot	2804	2	12 oz.
3844	Rear spring perch bushing	1909-19	$\frac{5}{16}$" bore x ¾" dia. x 2"	05	Gawky	172	4	2 oz.
3845	Rear spring perch nut	1909-19	$\frac{11}{16}$" x 16 thds	10	Gazara	174	2	2 oz.
3847	Front spring clip assembly with bolt and nut	1909-19		10	Gazzam	374	2	3 oz.
3847B	Front spring clip assembly with bolt and nut	1916-19	(for 6 leaf spring)	10	Gown	2953	2	
3848	Rear spring clip assembly with bolt and nut	1909-17		10	Gecko	376	2	4 oz.
3848B	Rear spring clip assembly with bolt and nut	1918-19		10		378		
REAR SPRING—60 INCH TREAD								
3850	Rear spring	1909-16	48½" long, 8 leaf	15 00	Geddur	1704	1	
3851	Rear spring clip	1909-16	$\frac{5}{16}$" x 4 $\frac{7}{16}$"	25	Gelder	1737	2	12 oz.
3852	Rear spring tie bolt and nut	1909-16	⅜" x 3 $\frac{5}{32}$"	10	Gemote	1738-1353	1	3 oz.
3853	First leaf (main leaf)	1909-16		3 00	Gemsbok	1739	1	10 lb., 10 oz.

Insist upon genuine Ford parts



Plate No. 11



Plate No. 12



Plate No. 13

Part No.	Name of Part	Year	Specifications	Price	Code Word	Fac. No.	No. Req. per Car	Mailing Weight
REAR SPRING—60 INCH TREAD—Continued								
3854	Second leaf	1909-16		$ 2 50	Gershon	1740	1	9 lb., 1 oz.
3855	Third leaf	1909-16		2 00	Gerper	1741	1	8 lb., 3 oz.
3856	Fourth leaf	1909-16		1 75	Gherkin	1742	1	6 lb.
3857	Fifth leaf	1909-16		1 60	Gibbet	1743	1	5 lb., 8 oz.
3858	Sixth leaf	1909-16		1 50	Ginger	1744	1	6 lb., 10 oz.
3859	Seventh leaf	1909-16		1 30	Gipsire	1745	1	4 lb., 6 oz.
3860	Eighth leaf	1909-16		1 10	Gisarm	1746	1	3 lb., 9 oz.
STARTING CRANK								
3900	Starting crank only	1909-19		65	Hernia	519B	1	1 lb., 10 oz.
3901	Starting crank handle	1909-19		25	Heron	520	1	2 oz.
3902	Starting crank handle bolt	1909-19	½" x 4⅝"	10	Herpes	521	1	4 oz.
3903	Starting crank sleeve	1909-19	49/64" bore x 11/64" x 2¼"	15	Hesper	523	1	4 oz.
3905	Starting crank ratchet pin	1909-19	1⅜"	05	Hestern	4491	1	
3906	Starting crank ratchet	1909-19		25	Hetman	528	1	8 oz.
3908	Starting crank spring	1909-19		05	Hilding	626	1	
RADIATOR—THERMO-SYPHON								
3925	Radiator	1909-16		26 50	Hominy	1100C	1	
3925B	Radiator	1917-19		25 00	Honey	8700	1	
3925C	Radiator less shell	1917-19		23 50	Hop			
3926	Radiator cap	1909-19		25	Horhir	8714	1	2 oz.
3928	Radiator pad	1909-19	Leather	05	Hovel	1105	2	
3929	Radiator stud and nut	1909-19	⅜" x 2 1/16"	06	Hoxy	1162-1154	2	1 oz.
3930	Radiator stud spring	1909-19	Order No. 2742					
3931½	Radiator stud washer nut	1909-19	⅜" x 24 thds.	03	Huffish	1161	2	
3932	Radiator rod	1909-19	20⅜" long	20	Huller	1111B	1	8 oz.
3934	Radiator rod nut	1909-19	⅜" x 24 thds.	03	Humbler	517	1	
3939	Outlet connection pipe	1909-19	1¾" x 12"	35	Humic	1121	1	12 oz.
3940	Outlet connection cock	1909-19	Order 3079					
3944	Outlet connection hose	1909-19	1¾" x 2¾"	15	Hungry	507	2	3 oz.
3945	Outlet connection hose clip	1909-19	2⅛" dia.	05	Hunter	554	4	1 oz.
3947	Radiator shell	1917-19		1 50	Hymn	8737	1	
RADIATOR FAN								
3960	Fan and pulley assembly	1909-19		1 20	Hutten	619	1	1 lb., 8 oz.
3961	Fan blade	1909-19		10	Hyades	611	4	3 oz.
3961B	Fan blade rivets, per dozen	1909-19		05	Hyad	1566	16	
3962	Driven fan pulley	1909-19	Brass, upper	80	Hydra	618	1	13 oz.
3963	Fan drive pulley	1909-19	Steel, lower	30	Hydrant	602	1	8 oz.
3964	Fan belt	1909-16		30	Hydrate	609	1	2 oz.
3964B	Fan belt	1917-19		30	Ibis	609B	1	
3966	Fan shaft	1909-19	7/16" x 4 1/16"	20	Hyper	606	1	4 oz.
3967	Fan bracket	1909-16		40	Hypo	604	1	7 oz.
3967B	Fan bracket	1917-19		40	Idyl	604B	1	
3968	Fan bracket bolt	1909-19	½" x 2⅜"	10	Hypere	605	1	3 oz.
3970	Fan grease cup	1909-19		10	Hyppish	601	1	
3973	Fan adjusting screw and nut	1909-19	⅝" x 1 11/16"	05	Hyssop	645-517	1	1 oz.
3974	Fan driven pulley bushing	1917-19		25	Knag	8757	1	
MUFFLER								
4025	Muffler assembly	1909-19		1 75	Jobal	1200	1	8 lb.
4026	Muffler head—front	1909-17	1 5/16" bore x 5 5/16" dia.	45	Jobesh	1202	1	1 lb., 8 oz.
4026B	Muffler head—front	1917-19		45		1202C	1	
4027	Muffler shell—outer	1909-19	5" dia. x 12"	25	Jabin	1203	1	1 lb., 1 oz.
4028	Muffler shell—middle	1909-19	3½" dia. x 13"	25	Jackal	1204	1	12 oz.
4029	Muffler shell—inner	1909-19	2" dia. x 14"	15	Jaday	1205	1	1 lb., 3 oz.
4030	Muffler rod	1909-17	5/16" x 13 3/8"	10	Jadish	1206	3	4 oz.
4030B	Muffler rod	1917-19		10	Jocose	1206B	1	
4031	Muffler rod nut	1909-19	5/16" x 24 thds. Order 3446					
4037B	Long exhaust pipe	1909-19		2 00	Jaunty	1214	1	1 lb., 12 oz.
4040	Rear muffler head	1909-17		45	Jetson	1221	1	2 lb.
4040B	Muffler head—rear	1917-19		45	Jesuit	1201D	1	
4041	Muffler head to frame bolt and nut	1917-19	Order 4808B					
HOOD								
4050	Hood	1909-16	22" long	6 00	Jibsam	1300	1	7 lb., 8 oz.
4050B	Hood	1917-19		6 00	Jilt	8726	1	
4051	Hood handle	1909-19	5 1/16" long	05	Jingal	1314	2	2 oz.
4052	Hood clip	1909-16	3 11/16"	10	Jippo	1310	4	2 oz.
4052B	Hood clip	1917-19		10	Jowl	8731	4	
4053	Hood clip spring	1909-16		03	Jockey	1311	4	
4053B	Hood clip spring	1917-19		03	Juice	8734	4	
4056	Hood board—left	1909-16	22¾" long	25	Johlm	1339	1	11 oz.
4056B	Hood block—left	1917-19		25	Kilt	8742	1	
4057	Hood board—right	1909-16	22¾" long	25	Jorum	1340	1	11 oz.
4057B	Hood block—right	1917-19		25	Kine	8741	1	
4060	Hood support on dash	1909-14		1 50	Jupon	1334	1	2 lb., 2 oz.
4060B	Hood support on dash	1915-16		1 50	Juror	7464	1	
4060C	Hood pad (on dash)	1917-19		05	Kite	8711	1	

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Specifications	Price	Code Word	Fac. No.	Req. per Car	Mailing Weight
HOOD—Continued								
4060D	Hood pad (on radiator shell)	1917-19		$ 0 10	Kid	8710	1	
4061B	Hood clasp (on dash)	1917-19		05	Kit	8720	1	
4061C	Hood clasp (on dash) screw	1917-19		02	Knee	8763	2	
4073	Hood block support—front right	1917-19		05	Knot	8743	1	
4074	Hood block support—front left	1917-19		05	Kiln	8744	1	
4075	Hood block support—rear right	1917-19		05	King	8745	1	
4076	Hood block support—rear left	1917-19		05	Kirk	8746	1	
WIRING								
4350	Spark plug wire	1909-19	14⅛", No. 1 cyl.	15	Nohob	1365	1	2 oz.
4351	Spark plug wire (also magneto to coil)	1909-19	10½", No. 2 cyl.	15	Nachor	1366	1	2 oz.
4353	Spark plug wire	1909-19	7", No. 3 and 4 cyls.	10	Nalad	1376	2	1 oz.
4354	Spark plug wire terminal	1909-19		03	Nailer	1381	8	
4355	COMMUTATOR WIRE	1909-19		65	Nandu	7502	1	8 oz.
4357	Com. wire terminal	1909-19	(Coil end)	01	Napher	1385	4	
4359	Com. wire loom support	1909-19		02	Napple	1390	2	
KINGSTON CARBURETOR								
6100	Carburetor complete	1909-19		6 00	Mason	553E	1	3 lb., 14 oz.
6101A	Carburetor float assb.	1917-19		1 00	Moslem	6369	1	
6101	Float with lever	1915-16		1 00	Marsh	6351	1	
6127A	Gasoline valve	1917-19		35	Moral	6377	1	
6115	Spray needle assembly	1910-19		50	Medal	3010	1	
Parts for 1909-16 Carburetors supplied by Bryne Kingston Co., Kokomo, Ind.								
HOLLEY CARBURETOR								
6040	Carburetor complete	1909-19		6 00	Mire	553D	1	3 lb., 3 oz.
4451A	Float with lever	1914-19		1 00	Muzzle	6333	1	
4452A	Spray needle assembly	1914-19		50	Myrtle	6335	1	
4453A	Gasoline inlet needle	1914-19		30	Mystic	6324	1	
(Other parts required may be ordered by plate numbers; prices quoted on application.)								
Parts for 1909-13 Carburetors supplied by Holley Kerosene Carburetor Co., Detroit, Mich.								
CARBURETOR ATTACHMENTS								
4127A	Carb. adjusting rod bracket	1909-19	On dash	05	Lastage	1357	1	
4129A	Carb. adjusting rod	1909-19		10	Latten	7920	1	4 oz.
4130	Carb. flange bolt and nut	1909-19		05	Leaper	1388-517	2	1 oz.
4134	Carb. flange gasket	1909-19		05	Lecturn	1380B	1	
4431	Carb. priming rod	1909-19		05	Loach	2000	1	1 oz.
4582	Carb. hot air pipe	1912-19		15	Monkey	686	1	6 oz.
FORD SPARK COIL								
4725	Coil	1909-19		13 00	Negus	1383	1	14 lb.
4726	Coil box with cover	1914-19	Metal	3 00	Nenia	5858	1	4 lb.
4727	Coil box cover	1914	Metal	40	Nephew	5856	1	11 oz.
4727B	Coil box cover	1915-19		40	Neptune	7910	1	
4728	Switch assembly	1914-19		75	Nidor	5873	1	9 oz.
4730	Switch cover	1914-19		10	Nones	5835	1	1 oz.
4731	Switch plug	1914-19		05	Nopal	5815	1	
4732	Coil unit	1914-19	3½" x 2⅛" x 5"	2 50	Noggin	5845	4	2 lb.
4733	Vibrator with tungsten point	1914-19		15	Nonce	6797	4	
4734	Vibrator bridge with tungsten point	1914-19		20	Novia	6702	4	
FENDERS—56 INCH TREAD								
4800	Front fender—right	1910-16	All Cars	6 00	Scorch	1414C	1	
4800B	Front fender—right	1917-19	All Cars	5 00	Nook	7976	1	
4801	Front fender—left	1910-16	All Cars	6 00	Scoul	1413C	1	
4801B	Front fender—left	1917-19	All Cars	5 00	Noose	7977	1	
4802D	Rear fender—right	1915-16	Tour., Runab't & Coupelet	4 00	Shanty	1416D	1	
4802F	Rear fender—right	1917-19	All Cars	4 00	Norse	8850	1	
4803D	Rear fender—left	1915-16	Tour., Runab't & Coupelet	4 00	Sheen	1415D	1	
4803F	Rear fender—left	1917-19	All Cars	4 00	Nougat	8851	1	
4804D	Rear fender iron—right and left	1913-19	Touring car	25	Smile	5405A	2	12 oz.
4804E	Rear fender iron—right	1913-19	Torpedo & Coupelet	60	Shire	5563	1	1 lb., 7 oz.
4804F	Rear fender iron—left	1913-19	Torpedo & Coupelet	60	Shrub	5390	1	1 lb., 7 oz.
4804G	Rear fender iron—right or left	1916-19	Sedan	50	Nubble	8154A	2	
4804H	Rear fender iron—right or left	1918-19	Touring car	20	Shewd	5405B		
4804K	Fender iron—right or left	1918-19	Sedan	50	Shoggie	8154B	2	
4805B	Rear fender iron bolt and nut	1915-19	Touring, ⅛" x ¾"	05	Signet	8161-341	6	

Insist upon genuine Ford parts

Plate No. 14



Plate No. 15



Plate No. 16

Plate No. 17

Part No.	Name of Part	Year	Specifications	Price	Code Word	Fac. No.	Req. per Car	Mailing Weight
FENDERS—56 INCH TREAD—Continued								
4806	Fender eye bolt, nut and washer	1909-19	Old No. 2035	$ 0 10	Blenny	1945	6	3 oz.
4808	Front fender iron bolt and nut (side)	1910-19	3/8" x 3 1/4"	05	Shovel	1323-8	2	1 oz.
4808B	Front fender iron bolt and nut (bottom)	1910-19	3/8" x 1 1/4"	05	Siren	347-8	2	
4808C	Front fender apron to frame bolt and nut	1915-19	1/2" x 3/8"	05	Sickle	4088-1309	4	
4869	Front fender iron—right or left	1909-19		75	Sistom	343	2	1 lb., 14 oz.
RUNNING BOARDS AND SHIELDS—56 INCH TREAD								
4812	Running board—right or left	1909-19	44 7/8" long	2 00	Shrew	5418	1	
4814	Running board metal shield—right	1912-16	Tour., Tor. and Coupelet	2 25	Skylark	1409C	1	
4814C	Running board shield—right	1917-19	All Cars	2 70	Shrine	7986	1	
4815	Running board metal shield—left	1912-16	Touring and Torpedo	2 25	Skylight	1408C	1	
4815C	Running board shield—left	1917-19	All Cars	2 70	Shroud	7987	1	
4816	Running board truss rod—front with nuts	1909-19		40	Skybird	5804	1	2 lb., 2 oz.
4817	Running board truss rod—rear with nuts	1909-19		40	Skyman	5805	1	2 lb., 2 oz.
4818	Running board bracket	1909-19		75	Skyhawk	336	4	1 lb., 13 oz.
4819	Run. board fender bolt and nut	1909-19	1/4" x 1 1/8"	05	Boaster	1344B-1309	8	
4819B	Run board bolt and nut	1909-19	1/4" x 1 3/4"	05	Bolary	8448-341	8	
FENDERS AND RUNNING BOARDS—60 INCH TREAD—BLUE								
4820B	Front fender—right	1913-16	Touring and Torpedo	6 00	Table	2742	1	
4821B	Front fender—left	1913-16	Touring and Torpedo	6 00	Tabula	2743	1	
4822C	Rear fender—right	1915-16	Tour., Torpedo, Coupelet	5 00	Tartar	2758	1	
4823E	Rear fender—left	1915-16	Tour., Torpedo, Coupelet	5 00	Tavern	2759	1	
4824C	Rear fender iron—right and left	1915-16	Touring Car	40	Thatch	1723	2	
4825B	Front fender iron—right and left	1915-16	Order No. 4809					
4829	Running board truss rod—front	1909-12	51" long, Tour. and Torp.	50	Bosset	1708	2	
4830	Running board truss rod—rear	1909-12	Tour., Torp. and Roadster	50	Bounce	1734	1	
REPAIR TOOLS								
1349	Hub cap wrench		Regular equipment	20	Pacal	1349		
1387	Adjustable wrench		Regular equipment	50	Pacos	1387		
1902	Screw driver		Regular equipment	25	Padan	1902		
1903	Pliers		Regular equipment	30	Paddy	1903		
1917	Double end wrench		Regular equipment	20	Pagan	1917		
2335	Spark plug and cyl. head bolt wrench		Regular equipment	50	Pavid	5893		
2336	Tool roll		Regular equipment	30	Pawky	1979		
2337	Oil can		Regular equipment	15	Paxos	1384		
2338	Tire pump		Regular equipment	1 50	Payser	1368		
2340	Tire irons, each		Regular equipment	15	Pelage	4069		
2343	Jack		Regular equipment	1 00	Poser	3389	1	
3Z-775	3/8" socket wrench		8 1/4" long	40	Pallah			
3Z-1179	Fly wheel cap screw wrench		13 1/2" long	60	Palmy			
3Z-602	Valve spring lifter		15" long	50	Palpus			
3Z-703	Tire iron (large)			50	Pathos			
3Z-604	Valve grinder			1 00	Palster			
3Z-612	Rear wheel puller assembly			1 25	Panary			
3Z-611	Cam gear puller			2 00	Pantile			
3Z-614	Transmission clutch puller			1 25	Papaw			
3Z-620	Drive shaft housing stud nut wrench for 1 1/2" nut			50	Parent			
3Z-616	Rear axle housing bolt nut wrench		7 3/4" long	50	Parvis			
3Z-617-1	Valve seat reamer		7 1/2" long	2 50	Papula			
3Z-643	3/8" T socket wrench		9 1/4" long	60	Parfit			
3Z-644	Socket wrench for crank shaft bearing bolt nut		12 1/32" long	50	Passim			
3Z-645	3/8" L socket wrench		12"	50	Pastel			
3Z-646	3/8" open end wrench		7 1/2" long	30	Pastor			
3Z-647	Connecting rod clamp screw wrench		10 1/4" long	50	Parrot			
3Z-1223B	3/4" brace socket wrench		24 3/8" long	1 00	Parsee			
3Z-652	Piston ring squeezer		3 7/8" dia	35	Patile			
3Z-655	Large cam gear lock nut wrench		14" long	70	Pavan			
3Z-619	Crank shaft bearing bolt wrench		Oval head	60	Pelox			
3Z-782	Crank shaft bearing bolt wrench		Square head	50	Poloy			

Insist upon genuine Ford parts



Plate No. 18



Plate No. 19

Part No.	Name of Part	Year	Specifications	Price	Code Word	Fac.No. Req. No. per Car	Mailing Weight
REPAIR TOOLS—Continued							
3Z-2034	Trans. band ratchet wrench			$0 50	Poplin		
3Z-675	Rear axle nut open end wrench			1 00	Porite		
3Z-624	Exhaust pack nut open end wrench			1 25	Potash		
3Z-627	Rear axle entering wrench			1 00	Potion		
3Z-670	Fan bracket bolt nut brace wrench			75	Pout		
3Z-673	Body bracket connecting bolt T wrench, front and center			75	Prater		
3Z-686	Body bracket connecting bolt holding open end wrench			50	Preen		
3Z-698	Cylinder water outlet connecting screw brace wrench; Brake shoe support bolt brace wrench; D/S bearing housing screw brace wrench			each 80	Prince		
3Z-699	Spindle cone adjusting open end wrench			60	Profile		
3Z-719	Body bracket connecting bolt R. & L. wrench			65	Proverb		
3Z-738	Riveting bar for starting crank ratchet pin			60	Prude		
3Z-751	Rear axle nut and housing plug brace wrench			1 00	Pulpit		
3Z-765	Coil to dash bolt nut brace wrench			50	Pulsion		
3Z-1173	Front radius rod ball cap screw brace wrench			1 00	Pumice		
3Z-786	Cylinder head cap screw brace wrench			1 00	Pusil		
3Z-790	Drive shaft pinion T wrench			1 00	Puzzle		
3Z-783	Connecting rod T wrench			1 00	Pygmy		
3Z-2010	Connecting rod cap bolt nut L wrench (Cylinder No. 4)			50	Quack		
3Z-1955	Front wheel ball race drift			40	Quince		
3Z-1956	Spindle arm bushing driver			90	Quinsy		

COTTER PINS

	Fac. No.		Fac. No.
3/32" x 1" cotter pins	421	3/32" x 1/2" cotter pins	66
3/32" x 3/4" cotter pins	753	1/16" x 1/2" cotter pins	544
1/16" x 1" cotter pins	82	3/32" x 5/8" cotter pins	88
Price, each			$0 01
Price, per dozen			05
Price, per gross			25

NUTS

3/8"—24 thds		03

This size nut used on following parts: 2514, 2722, 2729B 3073, 3074, 3362, 3437, 3443, 2514B, 2741, 3010 4041, 4808, 4808B.

Insist upon genuine Ford parts

Price List of Accessories and Accessory Parts

Part No.	Name of Part	Make	Year	Code	Price
ELECTRIC HORN					
6432X	Electric horn complete			Ulcer	$ 2 00
7915X	Electric horn terminal wire 9"			Ulna	10
7917X	Electric horn to switch wire 35 1/8"			Ultra	10
ELECTRIC HEAD LAMPS (STANDARD 1915-19)					
6511X	Head lamp assembly—8 1/8" lens, per pair			Umpire	6 00
6511BX	Head lamp assembly—per pair (Dimmer type)		1919	Unport	7 00
6594X	Head lamp door assembly			Union	70
6589X	Head lamp switch assembly—with screws			Ural	30
8650X	Head lamp and horn switch assembly			Urith	40
8892X	Dimmer resistance coil with wires			Urbox	70
6572X	Head lamp Mazda bulb—8-9 volt used with magneto			Urban	40
6572CX	Head lamp Mazda bulb (6-8 volt single contact used with storage battery)		1919	Urcan	40
6520X	Dimmer bulb (for head and tail lamp) 6-8 volt 2 cp. single contact		1919	Vamos	27
6578X	Head lamp door lens gasket			Urchin	05
6576X	Head lamp door lens—8 1/8"			Urn	20
6592X	Head lamp plug—with thimble			Urus	20
6585X	Head lamp reflector			Urva	1 20
6577X	Head lamp door lens retainer			Usher	05
6580X	Head lamp focusing screw			Utas	05
6591X	Head lamp focusing screw spring			Ute	05
6574X	Head lamp bulb socket			Vagrant	20
6586X	Head lamp reflector spring			Vail	10
7487X	Switch to terminal wire—11 3/4" long			Valise	05
7489X	Lamp to lamp wire—40" long			Vallum	15
7490X	Lamp to ground wire—10 3/4" long			Vamp	05
SIDE OIL AND TAIL LAMPS—1915-19					
6561X	Side oil lamp, per pair			Van	4 50
6568X	Tail lamp			Vandal	2 25
7669X	Electric tail lamp assembly		1919	Vanquish	1 25
6471X	Electric tail lamp red lens		1919	Vales	15
6599X	Side oil and tail lamp fount			Vane	50
6956X	Side oil lamp door			Vanish	50
6957X	Tail lamp door			Vapid	50
6966X	Tail lamp white lens and frame			Vapor	20
6460X	Lamp burner including wick			Varix	25
6958X	Lamp chimney case			Varus	30
6472X	Lamp chimney			Vase	30
6959X	Lamp chimney cover			Vassal	25
6483X	Side oil lamp door lens			Vat	15
6484X	Tail lamp door red lens			Vault	15
6393X	Side oil lamp to bracket bolt nut			Veal	03
6486X	Lamp door hinge pin			Veer	05
6392X	Lamp wick			Vega	02
TOURING CAR AND TORPEDO WINDSHIELDS—1915-19					
*7840X	Windshield assembly, less brackets, bolts, nuts and washers			Vender	12 00
7818AX	Windshield hinge assembly—Right			Venom	45
7818BX	Windshield hinge assembly—Right		1917-19	Vent	45
7819AX	Windshield hinge assembly—Left			Venus	45
7819BX	Windshield hinge assembly—Left		1917-19	Verb	45
7820AX	Windshield upper frame assembly		1915-16	Verge	1 50
7820BX	Windshield frame assembly—upper		1917-19	Vermin	1 50
7822AX	Windshield upper half assembly		1915-16	Verse	5 00
7822BX	Windshield upper half assembly		1917-19	Verst	5 00
7823X	Windshield lower half assembly		1915-19	Vertex	7 00
7802X	Windshield lower frame only		1915-19	Venge	1 20
7803X	Windshield lower frame filler block		1915-19	Verve	20
7839X	Windshield frame filler block			Vervet	15
7888X	Windshield block (frame filler)—upper		1917	Vesper	15
7810X	Windshield hinge bolt			Vespid	05
7845X	Windshield bracket—right		1915-19	Vestal	50
7846X	Windshield bracket—left		1915-19	Vestry	50
7824X	Windshield glass clamp			Veto	05
7801X	Windshield frame—upper		1915-16	Vial	90
7887X	Windshield frame—upper		1917-19	Vicar	90
7804X	Windshield left hand lower hinge			Victor	15
7890X	Windshield hinge—lower left		1917-19	View	15
7805X	Windshield left hand upper hinge			Viking	20
7806X	Windshield right hand lower hinge			Villa	20
7889X	Windshield hinge—lower right		1917-19	Vim	20
7807X	Windshield right hand upper hinge			Vina	15
3827X	Windshield top snap loop			Vine	05
1154X	Windshield hinge bolt nuts			Vintage	05
2449BX	Windshield glass clamp screw			Viol	01
2257BX	Windshield hinge to frame screw (Order 3367)				
6013X	Windshield hinge spring			Virgin	03
7851X	Windshield upper glass stop—nickel		1915-19	Vise	35
7852X	Windshield lower glass stop—nickel		1915-19	Vitals	35
7808X	Windshield hinge thimble			Vitex	05

*Order 7845X-7846X extra for 1915-16 cars.

Insist upon genuine Ford parts

Part No.	Name of Part	Make	Year	Code	Price
TOURING CAR TOPS—1915-19					
7940X	Touring car top complete		1915-19	Warm	
6882X	Touring car storm curtain (R. H.)		1915-19	Warp	$2 25
6883X	Touring car storm curtain (L. H.)		1915-19	Warren	2 25
4966BX	Touring car side curtain (R. H.)		1915-19	Wart	2 40
4967BX	Touring car side curtain (L. H.)		1915-19	Wash	2 40
6894X	Touring car center deck complete		1915-19	Wasp	8 50
6886X	Touring car center deck only 91 ½" x 50"		1915-19	Waste	5 00
6895X	Touring car side quarter (R. H.)		1915-19	Watch	1 50
6896X	Touring car side quarter (L. H.)		1915-19	Water	1 50
6815X	Touring car side quarter pad (R. H.)		1915-19	Watt	1 25
6816X	Touring car side quarter pad (L. H.)		1915-19	Wave	1 25
6940X	Touring car back stay and curtain assembly		1915-19	Wax	2 50
6866X	Touring car wood bow (1st)		1915-17	Weak	75
3897X	Touring car wood bow (2nd and 3rd)		1913-17	Weapon	75
4957X	Touring car wood bow—rear		1914-17	Web	75
8973X	Touring car front and rear extension rib		1918-19	Yawn	25
8974X	Touring car front and rear upright rib		1918-19	Yell	25
4596X	Touring car bow separator—male		1913-17	Wedge	05
4597X	Touring car bow separator—female		1913-17	Weed	05
6832X	Touring car bow separator		1918-19	Whelp	05
6860AX	Touring car front extension bow socket (R. H.)		1915-17	Weep	75
6860BX	Touring car front extension bow socket (R. H.)		1918-19	Wealth	1 00
6861AX	Touring car front extension bow socket (L. H.)		1915-17	Weir	75
6861BX	Touring car front extension bow socket (L. H.)		1918-19	Weary	1 00
3884AX	Touring car rear extension bow socket (R. H.)		1913-17	Weld	75
3884BX	Touring car rear extension bow socket (R. H.)		1918-19	Wedding	1 00
3885AX	Touring car rear extension bow socket (L. H.)		1913-17	Welkin	75
3885BX	Touring car rear extension bow socket (L. H.)		1918-19	Welt	1 00
6862AX	Touring car front upright bow socket (R. H.)		1915-17	Well	1 00
6862BX	Touring car front upright bow socket (R. H.)		1918-19	Whig	1 00
6863AX	Touring car front upright bow socket (L. H.)		1915-17	Welsh	1 00
6863BX	Touring car front upright bow socket (L. H.)		1918-19	Whilk	1 00
3882AX	Touring car rear upright bow socket (R. H.)		1913-17	West	1 00
3882BX	Touring car rear upright bow socket (R. H.)		1913-19	Yauk	1 00
3883AX	Touring car rear upright bow socket (L. H.)		1913-17	Wether	1 00
3883BX	Touring car rear upright bow socket (L. H.)		1918-19	Yawl	1 00
6837X	Touring car key strap assembly		1913-18	Whale	05
8992X	Rib socket cotter		1918-19	Wheeze	03
3924X	Touring car top to windshield strap assembly		1915-19	Wharf	20
3629X	Touring car rear stay strap assembly complete		1913-19	Wheat	35
3631X	Touring car rear stay strap—short—lower		1913-19	Whiff	15
3632X	Touring car rear stay strap—long—upper		1913-19	Whim	20
6925X	Touring car curtain to windshield strap assembly		1915-19	Whine	10
6926X	Touring car curtain to lamp bracket strap assembly		1915-19	Whip	10
3754X	Touring car curtain glove fastener assembly		1913-19	Whist	05
6829AX	Touring car duquesne clip—upper		1914-17	Whoop	10
6829BX	Touring car extension support—upper		1918-19	Yelk	10
6830AX	Touring car duquesne clip—lower		1914-17	Wick	10
6830BX	Touring car extension support—lower		1918-19	Yeoman	05
3316X	Touring car top brass fastener—single		1913-16	Widow	05
3549X	Touring car top brass fastener—double		1913-16	Wife	05
8937X	Touring car top snap fastener—single		1917-19	Wig	05
8938X	Touring car top snap fastener—double		1917-19	Willow	06
3314X	Touring car top prop rest with strap		1913-19	Wind	60
3858X	Touring car top prop rest arm		1913-19	Wine	25
3624X	Touring car bow socket to seat iron japanned nut		1913-19	Wing	05
3383X	Curtain celluloid 20" x 36"—.015 thick		1913-19	Wink	1 20
3383X	Curtain celluloid 10" x 18"—.015 thick		1913-19	Winter	35
6881X	Touring car top dust hood		1915-19	Wire	3 00
TORPEDO TOP PARTS—1915-19					
*7941X	Torpedo top complete		1915-19	Wisdom	
4971X	Torpedo top—second and third wood bows		1914-19	Wish	50
6929X	Torpedo top—first bow		1915-19	Wisp	50
6870X	Torpedo top bow socket—upright—(R. H.)		1915-19	Witch	90
6871X	Torpedo top bow socket—upright—(L. H.)		1915-19	Withe	90
6873X	Torpedo top bow socket—front extension—(L. H.)		1915-19	Witness	80
6872	Torpedo top bow socket—front extension—(R. H.)		1915-19	Wizard	80
4907X	Torpedo top bow socket—rear extension—(R. H.)		1913-19	Wolf	80
4908X	Torpedo top bow socket—rear extension—(L. H.)		1913-19	Woman	80
6937X	Torpedo top side curtain—rear—(R. H.)		1915-19	Wood	1 20
6938X	Torpedo top side curtain—rear—(L. H.)		1915-19	Word	1 20
6935X	Torpedo top side curtain—front—(R. H.)		1915-19	Work	2 00
6936X	Torpedo top side curtain—front—(L. H.)		1915-19	World	2 00
6950X	Torpedo top back curtain assembly		1915-19	Worm	2 50
6965X	Torpedo top center deck complete		1915-19	Worry	6 00
6964X	Torpedo top deck only		1915-19	Wrap	2 50
6962X	Torpedo top side quarter—(R. H.)		1915-19	Wreck	1 00
6963X	Torpedo top side quarter—(L. H.)		1915-19	Wren	1 00
6806X	Torpedo top side quarter pad—(R. H.)		1914-19	Wrist	75
6807X	Torpedo top side quarter pad—(L. H.)		1914-19	Yacht	75
6939X	Torpedo top hood		1915-19	Yak	3 00
3877X	Torpedo top prop rest with strap		1913-19	Yam	50

*Inquire of Branch or Dealer for price.

Insist upon genuine Ford parts

Price List of Parts for Model T One Ton Truck

Part No.	Name of Part	Year	Price	Code Word	Model	Fac. No.	Req. per Car
REAR AXLE							
1000	Rear axle assembly	1918-19	$200 00	Abed	TT	95	1
1001	Axle housing assembly—right	1918-19	25 00	Abyss	TT	4	1
1002	Axle housing assembly—left	1918-19	25 00	Acme	TT	5	1
1003	Axle housing bolt and nut	1918-19	10	Acorn	TT	52-T220	13
1004	Axle housing cap	1918-19	50	Actor	TT	133	1
1005	Axle housing cap gasket	1918-19	02	Acute	TT	134	1
1006	Axle housing cap screw	1918-19	15	Adder	TT	72	4
1007	Axle housing cap screw lock wire	1918-19	02	Addle	TT	140	1
1008	Axle housing gasket—upper	1918-19	02	Agate	TT	138	1
1009	Axle housing gasket—lower	1918-19	03	Agast	TT	139	1
1010	Axle brake housing plate—right	1918-19	50	Agile	TT	147	1
1011	Axle brake housing plate—left	1918-19	50	Akin	TT	148	1
1012	Axle housing drain plug	1918-19	05	Alder	TT	136	2
1013	Axle shaft and nut	1918-19	7 15	Alex	TT	48	2
1014	Axle shaft cotter	1918-19	01	Alms	TT	165	2
1015	Axle shaft nut	1918-19	15	Aloe	TT	166	2
1016	Axle shaft washer	1918-19	05	Aloft	TT	135	2
1017	Axle shaft dust cap	1918-19	05	Alpha	TT	56	2
1018	Axle shaft inner ball bearing assembly	1918-19	6 00	Alpine	TT	125	2
1019	Axle shaft outer roller bearing assembly	1918-19	2 00	Archer	TT	171	2
1020	Axle shaft outer roller bearing sleeve	1918-19	25	Arena	TT	170	2
1021	Axle shaft bearing felt	1918-19	10	Argue	TT	143	4
1022	Axle shaft bearing retainer	1918-19	10	Ark	TT	20	2
1023	Axle shaft bearing retainer washer	1918-19	05	Arson	TT	23	2
1024	Axle shaft felt retainer assembly	1918-19	20	Astral	TT	144	2
1025	Axle shaft felt retainer cup	1918-19	05	Atwist	TT	145	2
1026	Axle shaft felt retainer plate	1918-19	03	Atoll	TT	146	2
1027	Diff. gear	1918-19	3 00	Aura	TT	13	2
1028	Diff. gear case R. or L. half	1918-19	3 00	Author	TT	11	2
1029	Diff. gear case bolt	1918-19	10	Avail	TT	52	8
1030	Order T2719						
1031	Diff. gear lock ring	1918-19	05	Avoke	TT	118	2
1032	Diff. pinion	1918-19	1 00	Awake	TT	14	2
1033	Diff. pinion shaft	1918-19	40	Awry	TT	15	1
1034	Drive shaft	1918-19	8 00	Bait	TT	87	1
1036	D. S. tube assembly	1918-19	15 00	Balm	TT	153	1
1037	D. S. tube flange gasket	1918-19	02	Bandit	TT	194	1
1038	D. S. tube flange screw. Order 1006	1918-19					
1039	D. S. felt	1918-19	10	Basil	TT	109	1
1040	D. S. felt container	1918-19	05	Beaver	TT	110	1
1041	D. S. to worm coupling	1918-19	1 50	Behind	TT	85	1
1042	D. S. to worm coupling pin	1918-19	03	Behold	TT	86	2
1043	Worm	1918-19	16 00	Berg	TT	16	1
1044	Worm gear	1918-19	18 00	Bible	TT	12	1
1045	Worm cotter. Order 1014	1918-19					
1046	Worm roller bearing assembly	1918-19	1 50	Bight	TT	108	2
1047	Worm roller bearing retainer	1918-19	05	Bigot	TT	106	1
1048	Worm roller bearing sleeve	1918-19	1 60	Bilog	TT	107	2
1049	Worm roller bearing housing screw	1918-19	05	Birch	TT	101	2
1050	Worm thrust bearing collar	1918-19	1 50	Bird	TT	114	2
1051	Worm thrust ball and separator assembly	1918-19	1 35	Bitter	TT	123	1
1052	Worm thrust bearing plate	1918-19	10	Blaze	TT	22	1
1053	Worm thrust bearing retainer	1918-19	30	Bleach	TT	111	1
1054	Worm thrust bearing retainer nut Order 1015	1918-19					
1055	Worm thrust bearing retainer pin	1918-19	03	Blend	TT	112	1
1056	Brake shoe assembly	1918-19	2 50	Blind	TT	2814	2
1057	Brake shoe lining, each	1918-19	30	Blink	TT	58	4
1058	Brake shoe lining rivet	1918-19	03	Blue	TT	68	40
1059	Brake shoe spring	1918-19	05	Blunt	TT	67	2
1060	Brake shoe bolt and nut	1918-19	30	Blush	TT	59-T242	2
1061	Brake expander	1918-19	80	Bodkin	TT	61	2
1062	Brake expander lever	1918-19	20	Booth	TT	62	2
1064	Brake expander adjustment collar	1918-19	30	Brig	TT	175	2
1065	Brake expander bushing	1918-19	15	Bronze	TT	173	2
1066	Brake expander pin	1918-19	03	Brook	TT	7	2
1067	Brake expander link	1918-19	05	Broom	TT	176	4
1068	Brake expander link pin	1918-19	05	Brow	TT	177	8
1069	Brake rod	1918-19	50	Brush	TT	119	2
1070	Brake rod support—right	1918-19	10	Buck	TT	120	1
1071	Brake rod support—left	1918-19	10	Bug	TT	121	1
1072	Brake rod support bolt and nut	1918-19	05	Buoy	TT	1308-T1309	2
1073	Rear radius rod	1918-19	5 00	Burn	TT	152	2
1074	Rear radius rod bolt and nut—front	1918-19	30	Crab	TT	84-T242	1
1075	Rear radius rod bolt and nut—rear	1918-19	20	Crag	TT	83-T242	4
1076	Universal joint bushing	1918-19	75	Crape	TT	69	1
SPRING							
1077	Rear spring—right or left, each	1918-19	6 00	Cream	TT	333	2
1078	Spring leaf No. 1	1918-19	1 20	Creed	TT	361	2
1079	Spring leaf No. 2	1918-19	90	Crew	TT	362	2
1080	Spring leaf No. 3	1918-19	75	Crib	TT	363	2
1081	Spring leaf No. 4	1918-19	70	Crisp	TT	364	2
1082	Spring leaf No. 5	1918-19	65	Croak	TT	365	2
1083	Spring leaf No. 6	1918-19	55	Crop	TT	366	2
1084	Spring leaf No. 7	1918-19	50	Croup	TT	367	2
1085	Spring leaf No. 8	1918-19	40	Crow	TT	368	2
1086	Spring leaf No. 9	1918-19	35	Crowd	TT	331	2

Insist upon genuine Ford parts



Part No.	Name of Part	Year	Price	Code Word	Model	Fac. No.	Req. per Car
SPRING—Continued							
1087	Spring bushing	1918-19	$ 0 20	Crumb	TT	332	2
1088	Spring clip	1918-19	50	Crush	TT	326	2
1089	Spring clip nut	1918-19	15	Cry	TT	327	4
1091	Spring clip plate	1918-19	45	Cuff	TT	329	2
1092	Spring tie bolt	1918-19	35	Cult	TT	330	2
1093	Spring tie bolt nut. Order 1089	1918-19					
1094	Spring tie bolt cotter	1918-19	01	Cure	TT	328	2
1095	Spring clamp	1918-19	10	Curl	TT	375	2
1096	Spring clamp bolt and nut	1918-19	05	Curse	TT	376-T926	2
1097	Spring perch	1918-19	1 20	Dale	TT	2804	2
1098	Spring perch nut. Order 1015	1918-19					
1099	Spring perch cotter. Order 1014	1918-19					
1100	Spring perch bushing	1918-19	30	Demon	TT	172	2
1101	Spring perch bushing spacer	1918-19	05	Dean	TT	169	4
1102	Spring hanger assembly	1918-19	40	Dike	TT	91	4
STEERING GEAR							
1105	Steering gear bracket	1918-19	1 00	Dream	TT	996	1
1106	Steering gear bracket block	1918-19	05	Drift	TT	945	1
1107	Steering gear bracket dust cap	1918-19	05	Drum	TT	5044	1
WHEELS							
1109	Rear wheel complete, less tire	1918-19	16 00	Duel	TT	99	2
1110	Rear wheel complete, with tire	1918-19				7645	
1111	Rear hub	1918-19	4 50	Dumb	TT	40	2
1112	Rear hub flange	1918-19	60	Dusk	TT	149	2
1113	Rear hub brake drum	1918-19	2 00	Dutch	TT	3	2
1114	Rear hub bolt and nut	1918-19	10	Dwarf	TT	28-29	12
1116	Rear hub cap	1918-19	35	Dyke	TT	150	2
1117	Rear hub key	1918-19	10	Ear	TT	26	2
1118	Rear hub felt	1918-19	05	East	TT	162	2
FRAME							
1119	Frame assembly	1918-19	35 00	Eat	TT	300	1
1120	Side member—right	1918-19	12 00	Ebb	TT	301	1
1121	Side member—left	1918-19	12 00	Fish	TT	302	1
1122	Front cross member	1918-19	1 50	Flirt	TT	303	1
1123	Rear cross member	1918-19	6 00	Flock	TT	304	1
1124	Front corner bracket—right	1918-19	15	Frost	TT	305	1
1125	Front corner bracket—left	1918-19	15	Froth	TT	306	1
1126	Rear cross member gusset plate	1918-19	25	Ghost	TT	307	2
MOTOR							
1127	Crank case arm block	1918-19	05	Grape	TT	890	2
1128	Hood board to frame bolt and nut—long	1918-19	05	Guest	TT	4073-T1309	2
RUNNING BOARD							
1129	Running board	1918-19	75	Gull	TT	5418	2
1130	Board bracket	1918-19	40	Heck	TT	2926	4
1131	Board bracket brace	1918-19	15	Hedge	TT	2927	4
TRANSMISSION CONTROL							
1133	Speed lever	1918-19	20	Hoe	TT	862	1
1134	Controller shaft with speed lever	1918-19	75	Hod	TT	1557	1
TOOLS							
3Z2257	Rear wheel puller assembly	1918-19	1 00	Hock	TT		1
3Z711	Rear axle housing bolt L socket wrench	1918-19	50	Prosy	TT		
3389X	Jack		2 25	Hog	TT		

Insist upon genuine Ford parts