

Ford

THE UNIVERSAL CAR

Price List of Parts
and Accessories

MODEL T

Ford Motor Company
DETROIT, MICHIGAN

November 1st, 1919

Prices subject to change without notice

**These Prices Free of Excise Tax
to Consumer**

Ford Motor Company

FORD FACTORIES AND BRANCHES

Ford Factory, Detroit—*Parent Plant*
Ford Factory, Ford, Ontario, Canada
Ford Factory, Manchester, England

AMERICAN WHOLESALE BRANCHES

Atlanta	Cleveland	Fargo	Los Angeles	Oklahoma City	Salt Lake City
Boston	Columbus	Houston	Louisville	Omaha	San Francisco
Buffalo	Dallas	Indianapolis	Memphis	Philadelphia	Scranton
Charlotte	Denver	Jacksonville	Milwaukee	Pittsburgh	Seattle
Chicago	Des Moines	Kansas City, Mo.	Minneapolis	Portland	Washington
Cincinnati	Detroit	Long Island City	New Orleans	St. Louis	

FOREIGN BRANCHES AND SERVICE STATIONS

Bordeaux, France	London, Eng.	Montreal, Que.	Toronto, Ont.
Buenos Aires, Argentina	London, Ontario	Paris, France	Vancouver, B. C.
Calgary, Alta.	Manchester, Eng.	Saskatoon, Sask.	Winnipeg, Manitoba
Hamilton, Ont.	Melbourne, Aus.	St. John, N. B.	

Foreign Department—New York
There are Ford Agents in all Principal Cities

Instructions for Ordering Parts

- 1—Order all parts through the nearest Branch or Dealer.
- 2—Always give Catalog Number and Name of each part ordered.
- 3—Mail and Parcel Post orders must be accompanied by an amount sufficient to cover Postage.
- 4—All prices are net f. o. b. Branch, Factory or Dealer.
- 5—Specify how shipments are to be made.
- 6—Orders for parts should be written separately from correspondence pertaining to other matters.

Telegraph Code

To save expense, to expedite ordering and for your convenience, we have arranged a code word for each part of the Ford Model T car. In addition, we list below a brief General Code covering miscellaneous instructions, questions and answers relative to the shipment of parts.

Toperig—Ship to me (us) by express.

Toperkleur—Ship by express to ———

Topersteen—Ship to me (us) by freight.

Toper—Ship to me (us) by parcel post.

Topfton—When and how did you ship parts called for in my (our) telegram of ———

Topflutch—When and how will you ship parts called for in my (our) telegram of ———

Topfwasacr—When and how will you ship parts called for in my (our) letter of ———

Parts Price List Index

	Page
Axle—Front	7
Axle—Rear	5
Body Parts	21
Carburetor	24
Carburetor Attachments	24
Coil and Parts—Spark	24
Commutator	13
Cotter Pins	32
Fan	23
Fenders	28
Frame	9
Gasoline Tank	9
Hood	24
Horn	33
Lamps	33
Magneto	13
Motor	9-12-13
Muffler	24
Nuts	32
Radiator—Thermo Syphon	23
Running Board and Shields	28
Springs	21
Starter Parts	28-30
Starting Crank	23
Steering Gear	19
Tools	30
Tops	36
Transmission	16
Transmission Control	17
Transmission Cover	17
Truck Parts	37-39
Wheels	7
Windshields	33
Wiring	24


PRICE LIST OF PARTS

FORD MODEL T 1909-1919

EFFECTIVE NOVEMBER 1st, 1919

Part No.	Name of Part	Year	Specifications	Price	Code Word	Fac.No. Req. No. per Car	Mailing Weight
REAR AXLE							
2500	Rear axle assembly	1909-19	50-inch tread	\$80 00	Aband	95E	1
2501	Axle housing—right	1915-19		11 00	Absolve	7635	1
2502	Axle housing—left	1915-19		11 00	Absume	7636	1
2503C	Axle housing bolt and nut		$\frac{3}{8}$ " x $1\frac{1}{2}$ "		05	Abject	42C
2503E	Axle housing bolt and nut		$\frac{3}{8}$ " x $1\frac{1}{2}$ "		05	Ajoy	2854
2505	Axle shaft—tapered	1912-19	$1\frac{1}{2}$ " x $31\frac{1}{2}$ "	2 25	Abode	2818	2
2506	Axle shaft washer	1909-19	$1\frac{1}{2}$ " dia. fibre		03	Abound	39
2508	Axle shaft roller bearing	1909-19	$2\frac{1}{2}$ " x $4\frac{1}{2}$ "	1 00	Abrase	97	1 lb., 3 oz.
2509	Axle shaft roller bearing sleeve—right	1909-19	$4\frac{1}{2}$ " long		30	Abray	170
2509B	Axle shaft roller bearing sleeve—left	1909-19			30	Abate	161
2510	Axle housing cap	1909-19	$2\frac{1}{2}$ " dia.		05	Abroad	56
2510A	Axle outer roller bearing steel washer	1909-19	$2\frac{1}{2}$ " dia.		03	Absinthe	199
2510B	Axle outer roller bearing felt washer	1909-19	$2\frac{1}{2}$ " dia.		05	Absist	54
2512C	Diff. case—left (no bushing used)	1914-19		2.00	1 75	Abut	10D
2513C	Diff. case—right (no bushing used)	1914-19		1.25	1 00	Ache	81
2514	Diff. case stud and nut	1909-15	$\frac{3}{8}$ " x $2\frac{1}{4}$ "		10	Arcadian	52-8
2514B	Diff. case stud and nut	1915-19	$\frac{3}{8}$ " x $2\frac{1}{4}$ "		10	Ale	2865-8
2517	Diff. case bushing	1909-13	$1\frac{1}{2}$ " bore— $1\frac{1}{2}$ " dia.		50	Accite	19
2518	Diff. drive gear	1909-19	40 teeth	4 00	05	Accost	12
2519	Diff. drive gear screw	1909-19	$1\frac{1}{2}$ " x $4\frac{1}{2}$ "		05	Accoy	103
2519A	Diff. gear lock ring	1909-19			03	Acetic	118
2520B	Diff. gear	1909-19	24 teeth	1 75	Acc	13B	2
2521B	Diff. gear key	1911-19	$1\frac{1}{2}$ " long		05	Acrid	137
2522B	Diff. gear pin		Specify length.		03	Acher	2866
2523	Diff. gear thrust washer	1909-14	Fibre, $3\frac{1}{2}$ " dia.		10	Actress	32
2524C	Diff. pinion	1915-19	12 teeth		50	Admire	14D
2526B	Diff. spider	1909-19		1 00	02	Adduce	15D
2528	Diff. thrust washer	1909-19	$3\frac{1}{2}$ " dia. metal		30	Adieu	30
2529	Diff. thrust plate	1909-19	$3\frac{1}{2}$ " dia. steel		15	Adjoin	31
2530	Diff. thrust plate pin	1909-16	$\frac{1}{2}$ " long		03	Admix	17
2531	Diff. thrust plate pin	1909-16	$\frac{1}{2}$ " long		03	Adgase	37
2531B	Diff. thrust plate pin	1917-19			03	Age	7640
2532	Diff. housing oil plug	1909-19	$3\frac{1}{2}$ " x 24 thds.		05	Agger	817
2545	Rear axle grease cup	1909-19			10	Ajar	76
2547	Rear radius rod	1909-19		3 00	05	Altar	152
2548	Radius rod nut	1909-19	$\frac{1}{2}$ " x 18 thds.		05	Amass	77
2549	Radius rod lock nut	1909-19	$\frac{1}{2}$ " x 18 thds.		05	Amber	78
2550	Radius rod lock washer	1909-19			02	Ambush	2823
2551	Radius rod bolt and nut	1909-19	$1\frac{1}{2}$ " x $1\frac{1}{2}$ "		10	Ampite	83-60
2557	Hub cam shaft—right	1909-19	$3\frac{1}{2}$ " long	10	25	Amuck	92B
2558	Hub cam shaft—left	1909-19	$3\frac{1}{2}$ " long		25	Anchor	61B
2559	Hub cam shaft bushing	1909-19	$\frac{1}{2}$ " bore, $\frac{1}{2}$ " dia.		10	Ancient	173
2562	Cam shaft lever	1909-19	$\frac{1}{2}$ " bore		20	Arab	62
2563	Cam shaft lever pin	1909-19	$\frac{1}{2}$ " x $\frac{1}{2}$ "		03	Arbor	7
2564	Lever clevis pin	1909-19	$\frac{1}{2}$ " x $1\frac{1}{2}$ "		05	Arcade	65
2566	Hub brake shoe	1909-19	Cast iron		35	Arctic	2814
2567	Brake shoe support bolt and nut	1909-19	$\frac{1}{2}$ " x $1\frac{1}{2}$ "		10	Argus	59-60
2568	Brake shoe support nut	1909-19	$\frac{1}{2}$ " x 20 thds.		05	Armor	60
2570B	Brake shoe coil spring	1913-19	$3\frac{1}{2}$ " long		03	Asug	2862
2571	UNIVERSAL JOINT ASSEMBLY	1909-19		2 50	50	Ashore	151B
2572	Joint knuckle (male)	1909-19			80	Ashust	45B
2573	Joint knuckle (female)	1909-19		1 00	03	Askew	46B
2574	Joint knuckle pin	1909-19	$\frac{1}{2}$ " x $1\frac{1}{2}$ "		03	Asleep	6
2575	Joint ring, complete	1909-19	$3\frac{1}{2}$ " dia.	1 00	05	Astert	49B
2576	Joint ring rivets (per set)	1909-19	$1\frac{1}{2}$ " x $1\frac{1}{2}$ "		05	Arche	50
2577	Joint housing	1909-14	$4\frac{1}{2}$ " long	2 00	05	Atlas	70
2577B	Univ. joint housing	1914-19		1 50	05	Atoll	7609
2578	Joint housing plug	1909-19	$1\frac{1}{2}$ " x 20 thds.		05	Atom	75
2579	Ball joint grease cup	1909-19	$\frac{1}{2}$ " pipe thds.		10	Attic	195
2580	Ball cap gasket	1909-19			05	Auburn	1518
2582	D. S. tubing	1911-19	$50\frac{1}{2}$ " long	9 50	50	Ballad	153D
2583	D. S. roller bearing housing	1911-19	$3\frac{1}{2}$ " long	1 50	50	Ballot	191B
2584B	D. S. roller bearing stud and nut	1912-19	$\frac{1}{2}$ " x $4\frac{1}{2}$ "		10	Balneal	183B-184
2586	D. S. roller bearing housing set screw	1911-19	$\frac{1}{2}$ " x 20 thds.		05	Banco	101
2587	D. S. roller bearing	1911-19	$2\frac{1}{2}$ " long	1 50	50	Balsam	108

Insist upon genuine Ford parts



Part No.	Name of Part	Year	Specifications	Price	Code Word	Fac.No. No. per Car	Req. Weight	Mailing
REAR AXLE—Continued								
2588.	D. S. roller bearing dis-							
	ance plate	1911-19.	2 1/2" dia.	\$ 0	05.	Bandlet.	106.	1
2589B.	D. S. ball bearing as-							
	sembly	1911-19.						
2589.	D. S. ball race	1911-19.	2 3/4" dia.	35	1 00.	Bander.	185.	1
2590.	D. S. ball retainer	1911-19.	2 1/4" dia.		40.	Bandon.	186.	1
2591.	D. S. ball thrust collar	1911-19.	2 1/4" dia.		03.	Bandroe	190.	1
2592.	D. S. ball bearings, each	1911-19.	Order 2811		30.	Bandault.	188.	1
2593.	D. S. roller bearing sleeve	1911-19.	2 3/4" dia., 2 3/4" long.		1 00.	Bangle.	107.	1
2595B.	D. S. only (tapered)	1911-19.	1 1/2" x 53 1/4"		5 00.	Banjo	87D.	1
2596.	D. S. sleeve	1911-19.	1" bore, 3 1/2" long.		1 00.	Banshee	163B.	1
2597B.	D. S. pinion	1911-19.	Taper bore, 11 teeth.		1 40.	Banewort.	16C.	1
2598.	D. S. castle nut	1911-19.	5/8" x 18 thds.		10.	Banket	124.	1
2598B.	D. S. pinion key	1911-19.			05.	Banker	57B.	1
2540.	D. S. housing front bush	1909-19.	1" bore, 1 1/2" babbitt.		60.	Balkish	69.	1

REAR AXLE—60 INCH TREAD

2600C.	Rear axle housing—right	1915-19.	Dia. of bell 9 1/4"	11 00.	Bang	2728C.	1	
2601C.	Rear axle housing—left	1915-19.	Dia. of bell 9 1/4"	11 00.	Bard	2729C.	1	
2602B.	Rear axle shaft—tapered	1911-19.	1 1/2" x 33 1/2"	2 75.	Baptism	2725.	2	8 lb., 10 oz.
2604.	Rear radius rod	1909-19.	53 1/2" tube only	3 50.	Barbett	1726.	2	4 lb., 19 oz.

FRONT AXLE


2690.	Front axle assembly	1909-19.	56" tread.	28 00.	Barila	261B.	1	
2691.	Front axle only	1909-19.	56" tread.	14 00.	Barber	202B.	1	
2694.	Spindle body—right	1911-19.		2 50.	Bardash	276.	1	2 lb., 11 oz.
2695.	Spindle body—left	1911-19.		2 50.	Bardish.	257.	1	2 lb., 11 oz.
2696.	Spindle arm—right or left	1911-19.		75.	Bardism	7716	2	12 oz.
2696B.	Spindle arm—right	1911-15.	With hole for speedometer support.	75.	Bardo	282.	1	12 oz.
2696C.	Spindle arm—right	1919.		75.		7715B.	1	
2696D.	Spindle arm—left	1919.		75.		7716B.	1	
2697.	Spindle arm nut	1911-19.	Order 2548.					
2702.	Spindle assembly—right	1909-10.		5 00.	Barkate	203A.	1	3 lb., 8 oz.
2703.	Spindle assembly—left	1909-10.		5 00.	Barker	204A.	1	3 lb., 8 oz.
2704.	Stationary cone	1909-19.	1 1/8" bore.	20.	Barkless	205.	2	4 oz.
2705.	Adjusting cone—right							
	thread	1909-19.	3/4" x 16 thds., R. T.	20.	Barley	206.	1	2 oz.
2706.	Adjusting cone—left							
	thread	1909-19.	3/4" x 16 thds., L. T.	20.	Barrack	207	1	2 oz.
2707.	Spindle nut—right							
	thread	1909-19.	3/4" x 10 R. H. thds.	10.	Barrow	209B.	1	2 oz.
2708.	Spindle nut—left thread	1909-19.	3/4" x 10 L. H. thds.	10.	Baron	208B.	1	2 oz.
2709.	Spindle washer	1909-19.	1/2" hole x 1 3/8"	02.	Barras	210.	2	
2710.	Spindle bolt with oiler	1910-19.	1 1/2" x 5 3/4"	25.	Barter	7708.	2	7 oz.
2711.	Spindle bolt nut	1909-19.	Order 2568.					
2713.	Spindle body bush (pair)	1909-19.	1/2" bore.	25.	Bartram	223.	2	2 oz.
2714.	Spindle arm bushing	1909-19.	1/2" bore, 1 1/2" dia., 1" L.	05.	Barwood	225.	2	
2715.	Spindle oiler	1909-16.	Order 3817.					
2715B.	Spindle oiler cap as-			05.	Beard	7702-		
	sembly	1917-19.				7705-7707.	4	
2715C.	Spindle oiler	1917-19.		05.	Bilge	2944.		
2717.	Spindle con. rod	1909-19.	46 3/4" long.	2 50.	Basalt	264.	1	3 lb., 2 oz.
2718.	Spindle con. rod bolt							
	with oiler	1909-19.	1 1/8" x 2 3/4"	20.	Basan	7706.	2	3 oz.
2719.	Spindle con. rod bolt nut	1909-19.	1 1/8" x 20 thds.	05.	Bashful	220.	2	
2721.	Spindle con. rod yoke	1909-19.	2 3/4" long.	40.	Bashule	248.	1	5 oz.
2721B.	Spindle con. rod yoke ball	1909-19.		40.	Baroko	226.	1	
2721C.	Spindle con. rod yoke	1918-19.		40.	Barse	248B.	1	
2722.	Steering yoke clamp bolt							
	and nut	1909-19.		05.		79 & 8.		
2725B.	Steering gear con. rod	1909-19.	Includes ball sockets.	1 00.	Baslard	289.	1	2 lb., 2 oz.
2728.	Ball socket cap	1909-19.		15.	Basent	254B.	2	2 oz.
2729B.	Ball socket bolt and nut	1909-19.	Order 2722.					
2733.	Front radius rod	1909-19.		3 00.	Beardless	263.	1	
2733B.	Front radius rod	1919.		3 00.	Bedazzle	263B.	1	
2734.	Front radius rod nut	1909-19.	Order 2548.					
2736.	Front radius rod ball cap	1909-19.		15.	Beaufet	217.	1	3 oz.
2737.	Front radius rod ball							
	socket	1911-19.		20.	Beckon	809B.	1	11 oz.
2741.	Radius rod ball cap stud							
	and nut	1911-19.		05.	Berth	4365-8.	2	
2742.	Radius rod ball cap spr	1911-19.		03.	Bicep	292.	2	
2760.	FRONT AXLE ONLY	1911-16	60" tread.	14 00.	Bechance	1720B.	1	
2761.	Steering spindle con. rod	1909-16.	60" tread.	3 00.	Becket	4199.	1	3 lb., 7 oz.
2762.	Steering gear con. rod	1909-16.	60" tread, includes ball sockets.	1 25.	Becloud	2739.	1	

WHEELS

2800.	Front wheel (specify color)	1909-19.	30" x 3"	9.00				
T2801.	Front wheel comp. R—			13.00				
	Demountable.		Timken Bearings included	12-00.	Bereave	291C.	1	
T2802.	Front wheel comp. L—			13.00				
	Demountable.		Timken Bearings included	12-00.	Behest	291C.	1	
2803.	Front hub assembly less							
	flange, bolts and nuts	1909-19.		2 50.	Bedew	200.	2	4 lb., 9 oz.

*When substituting 2721C for old style yoke, also order 2721B Ball.

Insist upon genuine Ford parts




Part No.	Name of Part	Year	Specifications	Price	Code Word	Fac.No.	Req.	Mailing Weight
WHEELS—Continued								
2804.	Outer race	1909-19	1 1/8" dia.	\$ 0 15	Bedfere	234	.2	2 oz.
2805.	Inner race	1909-19	2 3/8" dia.	20	Bedlight	235	.2	5 oz.
2806.	Outer ball retainer	1909-19	1 1/8" dia.	02	Bedim	236	.2	
2807.	Inner ball retainer	1909-19	2 1/8" dia.	03	Bedside	237	.2	
2808.	Dust ring	1909-19	Steel 2 3/8" dia.	05	Bedward	238	.2	1 oz.
2809.	Front and rear hub felt washer	1909-19	2 1/4" dia.	05	Bedje	239	.4	
2810.	Large balls, each	1909-19	1 1/2"	04	Beding	241	.24	
2811.	Small balls, each	1909-19	3/8"	03	Beemol	249	.22	
2814C.	Rear wheel—blue (taper hub)	1912-19	30" x 3 1/2"	9.00	Beegah	2815	.2	
2814E.	Rear wheel comp.—Demountable			10.00	Begin	2815B	.1	
2815B.	Rear hub (straight bore)	1909-11		2 00	Beggart	40B	.2	4 lb. 7 oz.
2815C.	REAR HUB (TAPERED) less flange, bolts & nuts	1912-19		2 00	Begol	2819	.2	4 lb. 3 oz.
2816B.	Rear hub key	1912-19	1/2" x 1/2" x 2 1/4"	05	Begloom	2863	.2	1 oz.
2818.	Rear hub brake drum	1909-19	3" hole, 8" dia.	70	Beguller	3	.2	2 lb. 9 oz.
2819.	Hub cap	1909-19	2 1/2" x 2 1/2" thds.	20	Behave	727	.4	3 oz.
2825.	Hub bolt and nut	1911-19	5/8" x 2 3/8" x 16 thds.	05	Belay	28B-29B	.24	
2827.	Hub flange	1911-19	6" dia.	30	Bellow	233B	.4	1 lb. 5 oz.
2828.	Rear hub lock nut	1912-19	5/8" x 18 thds.	10	Bengal	242	.2	2 oz.
2831.	Timken bearing assembly inner and outer R. including dust ring (in carton)			3 50	Bemix	2962	.1	
2832.	Timken bearing assembly inner and outer L. including dust ring (in carton)			3 50	Ben	2961	.1	
2833.	Front hub bearing cup inner			60	Benip	2955	.2	
2834.	Inside spindle cone and roller assembly			1 25	Bent	205B	.2	
2835.	Front hub bearing assembly inner (less dust ring)			1 85	Bemusk	2954	.2	
2836.	Front hub bearing cup outer			45	Bepad	2956	.2	
2837.	Outside spindle cone and roller assembly R.			1 00	Beplay	206B	.1	
2838.	Outside spindle cone and roller assembly L.			1 00	Beplume	207B	.1	
2839.	Front hub bearing assembly outer R.			1 45	Berot	351	.1	
2840.	Front hub bearing assembly outer L.			1 45	Beset	352	.1	
2841.	Front hub dust cap assembly			20	Besunk	350	.2	
2845.	Demountable rim only			2 50	Bethrone	8774	.4	
2846.	Demountable rim clamp and nut assb.			15	Betime	8829	.16	
2847.	Demountable rim bolt			06	Bewax	8832	.16	
FRAME								
2850.	Frame assembly	1909-19		16 00	Befone	2916	.1	
2851B.	Side member—right	1914-19		5 00	Benign	2914	.1	
2852B.	Side member—left	1914-19		5 00	Berdash	2915	.1	
2853.	Front cross member	1909-19	22 3/4" long	1 40	Beluga	303	.1	3 lb. 15 oz.
2854B.	Rear cross member	1914-19		1 60	Bendlot	2913	.1	7 lb. 8 oz.
2855.	Front corner bracket—right	1909-19		20	Benumb	305	.1	.8 oz.
2856.	Front corner bracket—left	1909-19		20	Bequest	306	.1	.8 oz.
2857.	Rear corner bracket—right	1909-19		20	Besiege	307	.1	.9 oz.
2858.	Rear corner bracket—left	1909-19		20	Bespawl	308	.1	.9 oz.
2863.	Body bracket	1909-19	On frame	15	Bestow	344	.4	.4 oz.
GASOLINE TANK—TOURING CAR								
2900.	Gasoline tank	1909-19	10 gallons	4 00	Bibber	1303	.1	
2900B.	Gas tank	1916-19	Sedan	20.00	Binocle	7950		
2901.	Filling plug	1909-19	2 1/8"	10	Biblist	1317	.1	1 oz.
2902B.	Sediment bulb	1909-19		1.00	Bickers	2088	.1	1 lb. 2 oz.
2908.	Pet cock	1909-19	Order 3079					
2909.	Feed pipe	1909-19	Touring and Runabout. Also Coupe, 1915-17.	50	Billet	1364	.1	.4 oz.
2910.	Feed pipe pack nut	1909-19	1/2" x 18 thds.	05	Biflow	1374	.2	
2909B.	Feed pipe	1916-19	Sedan	60	Bismuth	7965		
2909C.	Feed pipe	1918-19	Couplet	75	Bisque	9775		
2911.	Feed pipe	1915	Sedan, 78" long	1 00	Betrap	1394	.1	
2912.	Sediment plug	1909-19		05	Blain	8802	.1	
MOTOR								
3000.	Cylinder	1909-19		30 00	Cabal	400C	.1	
3000C.	Cylinder	1919	Starter type	30 00	Calcox	400D	.1	
3001.	Cylinder head	1909-19		7 00	Cabin	401C	.1	
3002.	Cyl. head gasket	1909-19		40	Caoose	402B	.1	.5 oz.
3003.	Cyl. head cap screw	1909-19	1/2" x 2 1/2"	05	Cackle	483B	.15	.2 oz.
3003B.	Cyl. head cap screw	1918-19	1/2" x 3 1/4"	05	Chub	483C		
3004.	Cyl. head outlet connect.	1909-16	Cast iron	35	Caddow	446C	.1	11 oz.

Insist upon genuine Ford parts



3001



3000



3002



3009 B



3000-C




3009-C



3017




3013



3071



3084



3101 B

3070



3085



3101



3100



3102



3110



3111



3112



3165



3163




3176



3221



3012



Parts Price List

Ford Motor Company

Part No.	Name of Part	Year	Specifications	Price	Code Word	Fac.No. Req. No. per Car	Mailing Weight
MOTOR—Continued							
3004B...	Cyl. head outlet connection	1917-19.		\$ 0 35.	Cania.	8719...1	
3005...	Cyl. head outlet con. gasket	1909-19.			05. Caddy	445B...1	
3006...	Cyl. head outlet hose	1909-19.	2" x 4"		25. Cadet	448B...1	4 oz.
3007...	Cyl. head outlet hose clip	1909-19.	2 1/2" dia.		05. Cadger	607B...2	1 oz.
3008...	Cyl. head outlet con. screw	1909-19.	1/4" x 1 1/2"		05. Cadmean	550C...2	1 oz.
3009B...	Cyl. front cover	1909-19.			1 50. Cage	690B...1	2 lb., 1 oz.
3009C...	Cyl. front cover	1919.	Starter type.		1 50. Canard	690C...1	
3010...	Cyl. cover bolt and nut	1909-19.	1/2" x 3/4"		05. Cafe	1028-8...1	1 oz.
3011...	Cyl. cover cap screw	1909-19.	1/2" x 1 1/2"		05. Cahoot	432...3	
3012...	Cyl. cover felt	1909-19.	Felt		05. Caitiff	504...1	
3013...	Cyl. cover liner	1909-19.	Paper		02. Cajole	505B...1	
3013B...	Cyl. cover liner	1919.	Paper—Starter type		03. Cajom	505C...1	
3014...	Cyl. cover and crank case bolt and nut	1909-19.	3/8" x 1 1/2". Order 2722				
3015...	Cyl. water inlet connection	1909-19.	Cast iron		40. Calcine	442B...1	1 lb., 3 oz.
3016...	Cyl. inlet con. screw	1909-19.	1/4" x 1 1/2"		05. Caldron	597...2	
3017...	Time gear cover	1919.	Starter type.		2 00. Calico	1754...1	
3018...	Cyl. water inlet gasket	1909-19.	Copper		05. Calisy	596...1	
3019...	Cyl. water jacket plug	1909-13.	1/2" pipe plug		05. Capin	557...3	1 oz.
3019B...	Cyl. water jacket plug	1914-19.			02. Canon	5919...3	
3020...	PISTON COMPLETE	1909-19.	3/4" dia.		2 30. Caliph	586C...4	3 lb., 9 oz.
3020C...	PISTON COMPLETE	1909-19.	.0025" oversize		2 30. Canopy	683A...4	
3020D...	PISTON COMPLETE	1909-19.	.03125" oversize		2 30. Capon	683C...4	
3020E...	PISTON COMPLETE	1909-19.	.033" oversize		2 30. Churn	683B...4	
3021...	Piston only	1909-19.	3/4" dia.		1 50. Callous	4472...4	
3021B...	Piston only	1909-19.	.0025" oversize		1 50. Chopin	5999...4	
3021C...	Piston only	1909-19.	.03125" oversize		1 50. Chord	5918...4	
3021D...	Piston only	1909-19.	.033" oversize		1 50. Chute	5901...4	
3022...	Piston pin	1909-19.			35. Callot	419B...4	4 oz.
3022 1/2...	Piston pin bushing (pair)	1909-19.			40. Callow	668...4	3 oz.
3023...	Piston ring	1909-19.	1/2" x 3 3/4"		15. Calmy	422...12	2 oz.
3023B...	Piston ring	1909-19.	.03125" oversize		15. Calif	5917...12	
*3024...	CONNECTING ROD	1909-19.	Includes bearings		2 50. Calvish	641...4	1 lb., 9 oz.
3025...	Con. rod cap bolt and nut	1909-19.	1/2" x 2" x 24 thds.		10. Calyz	489B-490...8	
3029...	Con. rod clamp screw	1909-19.	3/8" x 1 1/2"		05. Camble	578...4	
3030...	C.R. K. SHAFT	1909-19.	2 1/2" long		10. Camel	498B...1	1 lb., 1 oz.
3031...	C. S. rear bearing cap	1909-19.	3 1/2" long, babbitted		90. Camel	405B...1	1 lb., 1 oz.
3032...	C. S. front bearing cap	1909-19.	1 1/2" long, babbitted		65. Camera	406B...1	10 oz.
3033...	C. S. center bearing cap	1909-19.	2 1/2" long, babbitted		65. Camlet	407B...1	10 oz.
3034...	C.S. bearing bolt—center and front	1909-19.	1/2" x 6 1/2" x 20 thds.		20. Camphor	408...4	6 oz.
3035...	C. S. bearing bolt nut	1909-19.	Order 2568				
3036...	C. S. rear bearing bolt	1909-19.	1/2" x 4 1/2"		15. Candle	478...2	4 oz.
3038...	C.S. bearing liner—center and front	1909-19.	1 1/2" long, brass.		01. Cannon	502B...8	
3039...	C. S. rear bearing liner	1909-19.	3" long, brass.		01. Cannv	503B...4	
3040...	C. S. starting pin	1909-19.	3/8" x 2 3/4"		05. Canoe	529B...1	2 oz.
3041...	CAM SHAFT	1909-19.			5 00. Canteen	410...1	3 lb., 4 oz.
3042...	Cam shaft front bearing	1909-19.	2" long		50. Canter	411...1	6 oz.
3043...	Cam shaft center bearing	1909-19.	2 1/2" long		35. Canthus	412B...1	6 oz.
3044...	Cam shaft rear bearing	1909-19.	Bronze, 1 1/2" long		25. Canto	413...1	3 oz.
3045...	Cam shaft bearing ring	1909-19.	1/2" x 1 1/2"		05. Canvas	534...2	
3046...	Cam shaft bearing gasket	1909-19.	1/2" x 3/4"		05. Capelln	414...2	
3047...	Time gear—large (on cam shaft)	1909-19.	42 teeth		1 25. Capet	415...1	1 lb., 10 oz.
3047B...	Time gear—large (on cam shaft)	1919.	Spiral		1 25. Clang	415B...1	
3048...	Time gear—small (on crank shaft)	1909-19.	21 teeth		1 00. Capat	416...1	11 oz.
3048B...	Time gear—small (on crank shaft)	1919.	Spiral		1 00. Claret	416B...1	
3049...	Cam shaft gear dowel pin	1909-19.	3/8" x 1/2"		05. Capra	417...2	
3050B...	Cam shaft gear lock nut	1909-19.			15. Captive	4453...1	2 oz.
3051...	Small time gear key	1909-19.			05. Capsize	477...1	
3052...	Valve	1909-19.	Exhaust and inlet		20. Capstan	424...8	3 oz.
3052B...	Valve	1909-19.	1/2" oversize stem		20. Cake	5913...8	
3053 1/2...	Valve bushing	1909-19.	1/2" O. D. x 2" long		30. Captain	428...8	2 oz.
3054...	Valve spring	1909-19.			05. Capture	431...8	1 oz.
3056...	Valve spring seat	1909-19.	1 1/2" dia.		02. Carack	425...8	
3057...	Valve spring seat pin	1909-19.	1/2" x 1 1/2"		01. Caranx	429...8	
3058...	Push rod	1909-19.	1/2" dia., 2 1/2"		15. Carat	426...8	2 oz.
3058B...	Push rod	1909-19.	1/2" oversize stem		15. Canine	5914...8	
3059 1/2...	Push rod bushing	1909-19.	Iron		30. Chippy	427B...8	2 oz.
3060B...	Exhaust manifold	1913-19.	Iron		1 75. Chirp	4483...1	4 lb., 8 oz.
3061...	Exhaust pipe pack nut	1909-19.	1 1/2" x 18 thds.		30. Chitter	518...1	4 oz.
3062...	Inlet pipe	1909-19.			1 25. Chloris	512B...1	2 lb., 8 oz.
3063...	Inlet and exhaust pipe gasket	1909-19.	1 1/2" O. D. copper		03. Choker	513...6	1 oz.
3064...	Inlet and exhaust pipe gland	1909-19.	1 1/2" dia., iron		03. Chopper	514...6	
3065...	Inlet and exhaust pipe clamp	1909-19.	2 3/4" long		15. Choral	515...4	3 oz.

*Connecting rods requiring new bearings will be exchanged at Branch or Factory for \$1.00 each.
 †Substitute spiral gears when replacing old style time gears.

Insist upon genuine Ford parts

Name of Part	Year	Specifications	Price	Code Word	Fac.No. per Car	Req. Mailing Weight
MOTOR—Continued						
3065... Inlet and exhaust pipe clamp	1909-19	2 3/4" long	\$ 0 15	Choral	515	4 3 oz.
3066... Inlet and exhaust clamp stud and nut	1909-19	3/8" x 3 3/4"	10	Chorus	516-517	4 2 oz.
3068... Breather pipe	1909-19	1 1/8" long	10	Chuck	4468	1 2 oz.
3069B... Crank case front end support	1911-17		75	Clam	801C	1
3069C... Crank case front end support	1917-19		75	Clack	801D	1
3070B... Cr. case & cyl. gasket—left	1909-19	Cork	10	Cider	886	1
3071B... Cr. c. & cyl. gasket—right	1909-19	Cork	10	Cigar	887	1
3072... Crank case and cyl. cover cap screw	1909-19	3/8" x 1"	05	Cinter	1388	2
3073... Crank case arm bolt and nut—side	1909-19	3/8" x 2 1/4"	10	Clippers	479-8	2 2 oz.
3074... Crank case arm bolt and nut—top	1909-19	3/8" x 1 1/2"	10	Circlet	940-8	2
3076... Crank case front frame bearing	1909-19	Iron	50	Circus	320B	1 1 lb., 6 oz.
3077... Crank case front bearing cap	1909-19	Iron	15	Cizar	321	1 3 oz.
3078... Crank case front bearing screw	1909-19	1/8" x 7/8"	05	Clabber	322	2 1 oz.
3079... Crank case oil cock	1909-19		20		1515	2 2 oz.
3080... Crank case drain cupplug	1909-19	Order 2532				
3080B... Crank case drain cup plug gasket	1909-19		03	Cliff	4339	1
3081... Crank case oil tube	1909-19		20	Cleavast	543B	1 2 oz.
3083... Crank case arm block	1909-19	Wood	05	Clergy	890	2 3 oz.
3084... Engine pan—right	1909-19		40	Clicket	1330B	1 1 lb., 14 oz.
3085... Engine pan—left	1909-19		40	Clientage	1331B	1 1 lb., 11 oz.
3088B... Engine pan and hood board bolt and nut	1909-19	1/4" x 3 1/4"	05	Clog	4074-1309	2
3088C... Engine pan and hood board bolt and nut	1909-19	1/4" x 3 3/8"	05	Clod	4073-1309	2
3100... CRANK CASE WITH LOWER COVER	1913-19		16 00	Closet	1526E	1
3101... Crank case lower cover	1912-19	6 3/8" x 15 1/4"	50	Closure	1582	1 2 lb., 13 oz.
3101B... Crank case lower cover reinforcement	1912-19		45	Clothes	4378-4379	1 1 lb., 11 oz.
3102B... Cr. c. lower cover gasket	1912-19	Cork	10	Clotting	1586	1
3103... Crank case lower cover screw	1912-19	1/8" x 1 1/8"	05	Cloudlet	4328	14
3110... Cylinder valve cover	1912-19	3/4" x 8"	40	Clovate	656	2 9 oz.
3111B... Cyl. valve cover gasket	1912-19	Cork	05	Cloven	669	2
3112... Cylinder valve cover stud and nut	1912-19	3/8" x 2 1/4"	10	Compoie	654-517	2 2 oz.
3114... Crank case arm with rivets	1909-19		35	Cloth	815	2


COMMUTATOR

3162... Com. case support bolt	1912-19	3/8" x 2 1/4" x 24 thds	05	Connote	4441	1 2 oz.
3162B... Com. case support bolt	1919	Starter type	07	Constrict	1756	1
3163... Com. case spring	1912-19	3 1/4" C. to C.	05	Conold	689	1 1 oz.
3165... Com. brush only	1912-19		40	Conquest	4481	1
3176... Com. oiler	1912-16	1/8" pipe thds	05	Coomb	2383	1
3176B... Com. oiler	1917-19		05	Coot	480	
3177... Com. felt ring	1912-19	Felt	03	Coombox	5930	1
3206... Com. brush cap	1909-19	7/8" dia.	03	Convert	468	1
3207... Com. brush cap pin	1909-19	1/8" x 1 1/2"	02	Convict	466	1
3210... Com. contact point nut	1910-19	1" hex.	02	Cooper	472B	8
3212... Com. thumb nut	1909-17	No. 10, 32 thds.	05	Copeck	6764	4
3220... Com. lock nut	1909-19	1/4" x 18 thds.	05	Crater	471	1
3221... Com. case with fibre assembled	1912-19		40	Crato	5908	1
3222... Com. shield	1912-19		03	Crash	5923	1

MAGNETO

3250B... Magneto coil assembly	1909-10	Used with 5/8" magnets. Obsolete — Substitute with 3250D and 3269E.				
3250C... Magneto coil assembly	1911-14	Used with 5/8" magnets. Obsolete — Substitute with 3250D and 3276B.				
3250D... Magneto coil assembly	1915-19	Used with 3/4" magnets.	8 00	Craft	5941B	1
3252... Magneto spool support screw	1909-19	Order 3371				
3254... Magnet bolt	1909-19	3/8" x 1 1/2"	05	Corbell	537B	16 1 oz.
3255B... Magnet bolt washer	1911-19	1 1/2" hole, 3/8" dia.	02	Corrupt	624	16
3257... Magnet brass support	1909-19	5/8" x 3/4", brass	05	Cordial	535C	16
3260... Magneto con. assembly	1909-19	On trans. cover.	35	Cornus	1545	1 2 oz.
3261... Magneto contact thumb nut	1909-19	Brass	05	Cornet	1508	1
3261B... Magneto contact nut	1909-19		01	Cornute	T1508	2

Insist upon genuine Ford parts



3250-D



3254



3276-B



3260



3268



3277



3257



3277-B



3270




3278



3255-B




3272




3269-C



3279



3269-E




3301



3304



3309



3306



3311



3314



3314 1/2



3320-B



3313




3315




3317



3320-C



3321



3300



3328




3327-B



3329



3331



3332



3336



3330



3337



3338



3334



3340



3341



3368



3342



3344



3369

Part No.	Name of Part	Year	Specifications	Price	Code Word	Fac.No. Req. No. per Car	Mailing Weight
MAGNETO—Continued							
3261C.	Magneto contact screw washer	1909-19			01. Cornel.	T1565	
3262	Magneto contact spring	1909-19	Coil spring		05. Cornlae.	1509	1
3262B.	Magneto contact screw and spring assb.	1919			15. Corsage.	T1516B-1509	
3266	Magneto contact fibre screw	1909-19	$\frac{1}{2}$ " long.		01. Cortile	1505B	3
3267	Magneto primary insulating block	1915-19			05. Crumple	4382	
3267B.	Magneto contact insulator	1919			10. Crush	T1503B	
3267C.	Magneto contact insulator shell	1919			03. Crutch	T8611	
3268	Fly wheel ring gear	1919	For starter	3.50	03. Cousin	1885	1
3268B.	Fly wheel ring gear lug	1919			03. Covey	1886	4
3269C.	Fly wheel	1911-19		6.50	03. Cosmic	701B	1
3269E.	Fly wheel with magnets assembled	1915-19	$\frac{3}{4}$ " magnets		15 00. Cramp	5946	1
3269G.	Fly wheel only	1919	Starter type	4.50	03. Cozy	701C	1
3270	Fly wheel cap screw	1909-19	$\frac{1}{4}$ " x $1\frac{1}{2}$ "		10. Cosack	721	4
3271	Fly wheel coil pin	1909-19	$\frac{1}{4}$ " x $1\frac{1}{2}$ "		05. Costard	722	2
3272	Magneto coil support shlm.	1909-19	Sheet steel		05. Costrel	584	1
3275	Magnet (16) per set.	1909-10	Thickness at face $\frac{1}{4}$ " Obsolete — Substitute with 3250D and 3269E.				
3276	Magnet (16) per set.	1911-14	Thickness at face $\frac{1}{4}$ " Obsolete — Substitute with 3250D and 3276B.				
3276B.	Magnet (16) per set.	1915-19	$\frac{3}{4}$ "		7 00. Court	5933	16
3277	Magnet clamp	1911-19			05. Cotland	623	16
3277B.	Magnet clamp	1913-14			05. Cotta	4499	16
3278	Magnet clamp screw	1911-19	2 $\frac{1}{2}$ " x 24 thds. brass.	10	05. Cottage	625	16
3279	Magneto-contact washer	1909-19	On trans. cover cork		03. Cough	560	1

TRANSMISSION

3300	Transmission assembly	1909-19		50 00.	Delester	744B	1	
3301	Trans. reverse plate assembly	1909-19		4 00.	Dacolt	747	1	4 lb., 14 oz.
3304	Trans. reverse gear bushing	1909-19	2 $\frac{1}{2}$ " rear	70.	Daddy	705	1	9 oz.
3305	Trans. reverse and S. S. rivet	1909-19	$\frac{1}{2}$ " x $\frac{1}{4}$ "		05.	Dado	708	8
3306	TRANS. SLOW SPEED PLATE ASSEMBLY	1909-19		3 50.	Dagger	748	1	4 lb., 8 oz.
3309	Trans. slow speed gear bushing	1909-19	1 $\frac{1}{2}$ " ream		60.	Dairy	745	1
3310	Trans. brake drum rivet	1909-19	$\frac{1}{2}$ " x $\frac{1}{4}$ "		05.	Daisy	711	8
3311	TRANS. BRAKE DRUM ASSEMBLY	1909-19		4 50.	Daklr	750	1	6 lb., 2 oz.
3313	TRANS. TRIPLE GEAR ASSEMBLY	1909-19		3 00.	Dallop	751B	3	2 lb.
3314	Trans. triple gear bushing	1909-10	1" dia. x 1 $\frac{1}{4}$ " long.	30.	Dally	716A	3	3 $\frac{1}{2}$ oz.
3314 $\frac{1}{2}$	Trans. triple gear flanged bushing	1911-19	1 $\frac{1}{4}$ " dia. x 1 $\frac{1}{4}$ "	40.	Dalriad	716B	3	4 oz.
3315	Trans. triple gear shaft	1909-19	$\frac{1}{4}$ " dia. x 2 $\frac{1}{2}$ "	25.	Dalrotz	715	3	4 oz.
3316	Trans. triple gear riveting pin	1909-19	$\frac{1}{4}$ " x 1 $\frac{1}{4}$ "		05.	Damar	720	24
3317	Trans. driven gear	1909-19	27 teeth	1 00.	Damask	713	1	13 oz.
3318	Trans. driven gear key	1909-19			05.	Dampen	714	2
3320B	Trans. driven gear sleeve bushing	1909-19	1" ream x flange 2 $\frac{3}{8}$ "		60.	Dankish	769	1
3320C	Trans. driven gear sleeve bushing	1909-19	1 $\frac{1}{2}$ " long	35.	Dark	712	1	3 oz.
3321	TRANS. DRIVING PLATE ASSEMBLY	1909-19		4.00	4 50.	Dannock	749	1
3323	Trans. driving plate screw	1909-19	Order 3371		05.	Darner	736	8
3325	Trans. driving plate rivet	1909-19	$\frac{3}{8}$ " x $\frac{3}{8}$ "					
3327B	Trans. driving plate bushing	1909-19	1 $\frac{1}{2}$ " x 1 $\frac{1}{4}$ "	25	20.	Darsis	772	1
3328	Trans. thrust plate—small	1909-19	6" dia.		15.	Dauphin	727	12
3329	Trans. thrust plate—large	1909-19	6 $\frac{1}{2}$ "		20.	Davine	728	13
3330	Trans. distance plate	1909-16	6" O. D.		30.	Decry	729	1
3331	Trans. gear shaft	1909-19	7" dia. x 7 $\frac{1}{2}$ " over all.	2 50.	Decurt	723B	1	2 lb., 10 oz.
3332	Trans. clutch disc drum	1909-19	4 $\frac{1}{2}$ " dia.	1 75.	Deeply	725B	1	1 lb., 11 oz.
3333	Trans. clutch disc drum key	1909-19			05.	Defalk	726B	1
3334	Trans. clutch disc drum set screw	1909-19	$\frac{3}{4}$ " x $\frac{3}{4}$ "		05.	Defeat	752	1
3336	Trans. clutch push ring	1909-19	6 $\frac{1}{2}$ " O. D.		50.	Defile	770	1
3337	Trans. clutch finger	1909-19			20.	Define	732	3
3337 $\frac{1}{2}$	Trans. clutch fingerscrew	1909-19	$\frac{1}{2}$ " x $\frac{3}{4}$ " x 24 thds.		05.	Defleur	756	3
3338	Trans. clutch finger pin	1909-19	$\frac{1}{4}$ " x 1 $\frac{1}{2}$ "		02.	Deform	735	3

*When using short bushing in making repairs remove driving plate key.

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Specifications	Price	Code Word	Fac.No.	Req. No. per Car	Mailing Weight
TRANSMISSION—Continued								
3340	Trans. clutch spring	1909-19	.285" dia. x 2 3/4" long	\$ 0 40	Defoue	737	1	10 oz.
3341	Trans. clutch spring support	1909-19			10	Delator	738	1 4 oz.
3342	Trans. clutch spring thrust ring pin	1909-19	3/16" x 2 3/8"		05	Delete	739	1
3344	Trans. clutch shift	1909-19		1 90	Delight	733	1	14 oz.
TRANSMISSION COVER								
3362	Trans. cover bolt and nut	1909-19	3/8" x 1 1/2". Order 2722					
3363	Trans. cover gasket (front)	1909-19	3/4" x 1 1/2" x 15 1/2" Felt		05	Defy	872B	1
3367	Trans. cover door screw	1909-19	3/8" x 1 1/2"		02	Demain	479	6
3368	Universal ball cap (rear)	1909-19	8 5/8" x 1 1/2"		50	Demarch	818	1 15 oz.
3369	Universal ball cap (front)	1909-19	Bearing included	1 25	Demarga	819D	1	1 lb., 14 oz.
3371	Universal ball cap screw	1909-19	3/8" x 1 1/2"		05	Demise	731	2
3372	Universal ball cap bolt and nut	1909-19	Order 2722					
3375	Trans. cover screw	1909-19	Order 3072					
*3376	TRANS. COVER	1911-19		8 00	Denier	826D	1	
3376R	TRANS. COVER	1919	Starter type	8 00	Den	826	1	
3377B	Trans. cover gasket (pair)	1909-19	Cork	15	Dennot	885B	1	pr
3378	Trans. cover sloping door	1911-19	.914" long	10	Dental	1546D	1	1 lb., 5 oz.
3379B	Trans. cover sloping door gasket	1911-19	Cork	10	Denude	1547C	1	
TRANSMISSION CONTROL								
3400	Trans. clutch releasing	1909-19	3 1/2" long	30	Detail	741	1	6 oz.
3402B	Clutch lever shaft	1913-18		30	Dine	434	1	12 oz.
3402C	Clutch lever and shaft with release forks	1913-19		1 20	Dirk 1553-1548-4345	1	1 lb., 8 oz.	
3402D	Clutch lever and shaft	1913-19		60	Disdain	1548		
3403	Clutch lever screw and nut	1909-19	3/8" x 1 1/2"		05	Dervish 1541-517	1	
3405	Clutch lever pin	1909-19	3/4" x 1 1/2"		02	Detour	1553	1
3406B	Clutch release fork—right or left	1913-19		30	Deuce	4345	2	3 oz.
3406C	Clutch release fork pin	1913-19	Order 3405					
3408	Clutch release fork key	1909-14		05	Dilate	836	2	
3409	Clutch release fork clamp screw	1909-14	1/2" x 1 1/2"	10	Dipper	835	2	
3411	Clutch lever clevis pin	1909-19	Order 2564					
3413	TRANSMISSION BAND ASSEMBLY	1909-19		75	Disblame	838B	3	1 lb., 2 oz.
(Bands will be exchanged at Branch or Factory at 60c each.)								
3415	Trans. band washer	1909-19	1 1/2" hole x 7 3/4" dia	03	Discure	840	2	
3416	Trans. band lining	1909-19		30	Disedge	1562	3	3 oz.
3419	Trans. band adjusting screw	1909-19	3/4" x 3 1/2"	10	Disfriar	1533	1	4 oz.
3420	Trans. band adjusting screw nut	1909-19	3/4" x 16 thds	05	Dislimb	1532	1	
3421B	Trans. band ear iron rivet, per doz.	1909-19	3/16" x 3/8"	05	Dismal	843	12	
3422B	Trans. band brass rivet, per doz.	1909-19	3/4" x 1 1/2"	05	Dismast	844B	6	
3423B	Trans. band brass rivet, per doz.	1909-19	3/8" x 1 1/2"	05	Dismaw	845B	18	
3425	Trans. band spring	1909-19	Coil	05	Dispark	841B	3	
3426	Trans. band adjusting nut	1909-19	1 1/2" x 20 thds	05	Displat	851	2	
3427	Slow speed shaft	1909-19	5/8" x 9 3/4"	25	Disputz	848B	1	11 oz.
3428	Slow speed notch	1909-19	On slow speed shaft	30	Disstrand	4327	1	5 oz.
3429	Slow speed notch pin	1909-19	1/4" x 1 1/2"	02	Disrobe	1560	1	
3432	Speed lever	1909-19		10	Distaff	862B	1	7 oz.
3434	Reverse pedal	1909-19		80	Disting	4324	1	1 lb.
3435	Brake and rev. pedal shaft	1909-19	3/8" dia. x 7 1/2"	25	Distrite	849B	2	8 oz.
3436	Brake and rev. pedal support	1909-19		25	Distune	4325	2	3 oz.
3437	Brake and rev. support bolt and nut	1909-19	3/8" x 1 1/2"	05	Ditcher	1534-8	2	
3439	Brake pedal	1909-19		80	Dittost	4323	1	1 lb., 2 oz.
3440	Clutch pedal	1909-19		80	Ditty	854B	1	1 lb., 2 oz.
3441	Pedal pin	1909-19	Order 3405					
3442	Clutch pedal support	1909-19		20	Dookad	4326	1	3 oz.
3443	Clutch pedal support bolt and nut	1909-19	3/8" x 2"	05	Doorga	1536-8	1	
3445	Slow speed connection	1909-19		05	Dorce	1540	1	
3446	Slow speed con. lock nut	1909-19	1 1/2" x 24 thds	03	Doric	44	1	
3447	Slow speed con. clevis	1909-19		15	Dormer	802	1	2 oz.
3448	Controller quadrant	1909-19	On frame	20	Dormouse	309B	1	9 oz.
3449	CONTROLLER SHAFT WITH SPEED LEVER	1909-19		1 00	Doron	1557	1	3 lb., 15 oz.
3450	Controller shaft bracket	1909-19	On frame	15	Dorrer	311	2	5 oz.
3451	Controller shaft bracket felt	1909-19		01	Dorsal	314	2	
3452	Controller shaft bracket bolt and nut	1909-19		05	Dorture	315-316	4	
3455	HAND BRAKE LEVER ASSEMBLY	1909-19		2 00	Dotant	1550	1	2 lb., 2 oz.

*Substitute with 3376B.

†When ordered to replace cover on cars below 2044100 also order 3402B clutch lever shaft.

Insist upon genuine Ford parts



Part No.	Name of Part	Year	Specifications	Price	Code Word	Fac. No.	Req. per Car	Mailing Weight
SPRINGS—Continued								
3829	Fifth leaf	1909-19	Tapered ends	\$ 1 30	Garden	365	1	5 lb., 13 oz.
3829B	Fifth leaf	1918-19	Square ends	1 30	Genus	365B	1	
3830	Sixth leaf	1909-19	Tapered ends	1 15	Garland	366	1	5 lb., 11 oz.
3830B	Sixth leaf	1918-19	Square ends	1 15	Ghoul	366B	1	
3831	Seventh leaf	1909-19	Tapered ends	1 00	Garlic	367	1	5 lb., 7 oz.
3831B	Seventh leaf	1918-19	Square ends	1 00	Giant	367B	1	
3832	Eighth leaf	1909-19	Tapered ends	85	Garner	368	1	3 lb., 8 oz.
3832B	Eighth leaf	1918-19	Square ends	85	Gimlet	368B	1	
3833	Rear spring clip	1909-19	4 in.	25	Game	326	2	11 oz.
3834	Rear spring clip nut	1909-19	Order 2548					
3835	Rear spring clip bar	1909-19	$\frac{3}{8}$ " x $1\frac{1}{2}$ " x $4\frac{1}{2}$ " x $\frac{1}{8}$ "	10	Gascon	329	2	7 oz.
3837	Rear spring tie bolt and nut	1909-19	$\frac{3}{8}$ " x $2\frac{1}{2}$ "					
3840	Rear spring hanger	1909-19		06	Gastric	1352-1353	1	2 oz.
3842	Rear spring leather pad	1909-19	$2\frac{1}{2}$ " x $10\frac{1}{4}$ "	20	Gaulus	91 $\frac{1}{2}$ B	4	5 oz.
3843	Rear spring perch	1909-19		10	Gavel	94	1	2 oz.
3844	Rear spring perch bushing	1909-19		60	Govot	2804	2	12 oz.
3845	Rear spring perch nut	1909-19	$\frac{1}{8}$ " bore x $\frac{3}{4}$ " dia. x 2"	05	Gawky	172	4	2 oz.
3847	Front spring clip assembly with bolt and nut	1909-19	$\frac{1}{8}$ " x 16 thds	10	Gazara	174	2	2 oz.
3847B	Front spring clip assembly with bolt and nut	1916-19	(for 6 leaf spring)	10	Gazzam	374	2	3 oz.
3848	Rear spring clip assembly with bolt and nut	1909-17		10	Gown	2953	2	
3848B	Rear spring clip assembly with bolt and nut	1918-19		10	Gecko	376	2	4 oz.
				10		378		
REAR SPRING—60 INCH TREAD								
3850	Rear spring	1909-16	48 $\frac{1}{2}$ " long, 8 leaf	15 00	Geddur	1704	1	
3851	Rear spring clip	1909-16	$\frac{1}{8}$ " x $4\frac{1}{2}$ "	25	Gelder	1737	2	12 oz.
3852	Rear spring tie bolt and nut	1909-16	$\frac{3}{8}$ " x $3\frac{1}{2}$ "					
3853	First leaf (main leaf)	1909-16		10	Gemote	1738-1739	1	3 oz.
3854	Second leaf	1909-16		3 00	Gembok	1739	1	10 lb., 10 oz.
3855	Third leaf	1909-16		2 50	Gershon	1740	1	9 lb., 1 oz.
3856	Fourth leaf	1909-16		2 00	Gerper	1741	1	8 lb., 3 oz.
3857	Fifth leaf	1909-16		1 75	Gherkin	1742	1	6 lb., 1 oz.
3858	Sixth leaf	1909-16		1 50	Gibbet	1743	1	5 lb., 8 oz.
3859	Seventh leaf	1909-16		1 50	Ginger	1744	1	6 lb., 10 oz.
3860	Eighth leaf	1909-16		1 30	Gipsire	1745	1	4 lb., 6 oz.
				1 10	Gisarm	1746	1	3 lb., 9 oz.
STARTING CRANK								
3900	Starting crank only	1909-19		65	Hernia	519B	1	1 lb., 10 oz.
3901	Starting crank handle	1909-19		26	Heron	520	1	2 oz.
3902	Starting crank handle bolt	1909-19	$\frac{1}{4}$ " x $4\frac{1}{2}$ "					
3903	Starting crank sleeve	1909-19	$\frac{1}{4}$ " bore x $\frac{1}{2}$ " x $2\frac{3}{4}$ "	10	Herpes	521	1	4 oz.
3905	Starting crank ratchet pin	1909-19	$\frac{1}{8}$ "	10	Hesper	523	1	4 oz.
3906	Starting crank ratchet	1909-19	$\frac{1}{8}$ "	05	Hestern	4491	1	
3908	Starting crank spring	1909-19		25	Hetman	528	1	8 oz.
				05	Hilding	626	1	
RADIATOR—THERMO-SYPHON								
3925	Radiator	1909-16		26 50	Hominy	1100C	1	
3925B	Radiator	1917-19		25 00	Honey	8700	1	
3925C	Radiator less shell	1917-19		23 50	Hop			
3926	Radiator cap	1909-19		25	Hothot	8714	1	2 oz.
3928	Radiator pad	1909-19	Leather	05	Hovel	1105	2	
3929	Radiator stud and nut	1909-19	$\frac{3}{8}$ " x $2\frac{1}{2}$ "	06	Hoxy	1162-1154	2	1 oz.
3930	Radiator stud spring	1909-19	Order No. 2742					
3931	Radiator stud washernut	1909-19	$\frac{3}{8}$ " x 24 thds	03	Huffish	1161	2	
3932	Radiator rod	1909-19	20 $\frac{1}{2}$ " long	20	Huller	1111B	1	8 oz.
3934	Radiator rod nut	1909-19	$\frac{3}{8}$ " x 24 thds	03	Humbler	517	1	
3939	Outlet connection pipe	1909-19	$1\frac{1}{2}$ " x 12"	35	Humic	1121	1	12 oz.
3940	Outlet connection cock	1909-19	Order 3079					
3944	Outlet connection hose	1909-19	$1\frac{1}{4}$ " x $2\frac{3}{4}$ "	15	Hungry	507	2	3 oz.
3945	Outlet connection hose clip	1909-19	$2\frac{1}{4}$ " dia					
3947	Radiator shell	1917-19		1 50	Hunter	554	4	1 oz.
3947B	Radiator shell	1919			Hymn	8737	1	
						8737B	1	
RADIATOR FAN								
3960	Fan and pulley assembly	1909-19		1 20	Hutten	619	1	1 lb., 8 oz.
3961	Fan blade	1909-19		10	Hyades	611	4	3 oz.
3961B	Fan blade rivets, per dozen	1909-19						
3962	Driven fan pulley	1909-19	Brass, upper	05	Hyad	1566	16	
3963	Fan drive pulley	1909-19	Steel, lower	80	Hydra	618	1	13 oz.
3964	Fan belt	1909-16		30	Hydrant	602	1	8 oz.
3964B	Fan belt	1917-19		30	Hydrate	609	1	2 oz.
3966	Fan shaft	1909-19	$\frac{1}{2}$ " x $4\frac{1}{8}$ "	35	Ibis	609B	1	
3967	Fan bracket	1909-16		20	Hyper	606	1	4 oz.
3967B	Fan bracket	1917-19		40	Hypo	604	1	7 oz.
3968	Fan bracket belt	1909-19	$\frac{1}{2}$ " x $2\frac{3}{8}$ "	40	Idyl	604B	1	
3970	Fan grease cup	1909-19		10	Hyper	605	1	3 oz.
3973	Fan adjusting screw and nut	1909-19	$\frac{3}{8}$ " x $1\frac{1}{2}$ "	10	Hyppish	601	1	
3974	Fan driven pulley bushing	1917-19		05	Hyssop	645-517	1	1 oz.
				20	Knag	8757	1	

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Specifications	Price	Code Word	Fac.No. Req. No. per Car	Mailing Weight
MUFFLER							
4025	Muffler assembly	1909-19		1.00 1.75	Jobal	1200	1 8 lb.
4026	Muffler head—front	1909-17	1 1/8" bore x 5 1/8" dia.	45	Jobesh	1202	1 1 lb., 8 oz.
4026B	Muffler head—front	1917-19		45	Jabun	1202C	1 1 lb., 1 oz.
4027	Muffler shell—outer	1909-19	5" dia. x 12"	25	Jackal	1204	1 1 lb., 12 oz.
4028	Muffler shell—middle	1909-19	3 1/2" dia. x 13"	25	Jadad	1205	1 1 lb., 3 oz.
4029	Muffler shell—inner	1909-19	2" dia. x 14"	15	Jadish	1206	3 4 oz.
4030	Muffler rod	1909-17	1/8" x 13 3/8"	10	Jacose	1206B	1
4030B	Muffler rod	1917-19		10			
4031	Muffler rod nut	1909-19	1/8" x 24 thda. Order 3446	2 00	Jaunty	1214	1 1 lb., 12 oz.
4037B	Long exhaust pipe	1909-19		45	Jetson	1221	1 2 lb.
4040	Rear muffler head	1909-17		45	Jesuit	1201D	1
4040B	Muffler head—rear	1917-19					
4041	Muffler head to frame bolt and nut	1917-19	Order 4808B				

HOOD

4050	Hood	1909-16	22" long	6.00 7.50	Jibsam	1300	1 7 lb., 8 oz.
4050B	Hood	1917-19		6 00	Jilt	8720	1
4051	Hood handle	1909-19	5 1/2" long	05	Jingal	1314	2 2 oz.
4052	Hood clip	1909-16	3 1/8"	10	Jippo	1310	4 2 oz.
4052B	Hood clip	1917-19		10	Jowl	8731	4
4053	Hood clip spring	1909-16		03	Jockey	1311	4
4053B	Hood clip spring	1917-19		03	Juice	8734	4
4056	Hood board—left	1909-16	22 3/4" long	25	Johim	1339	1 11 oz.
4056B	Hood board—left	1917-19		25	Kilt	8742	1
4057	Hood board—right	1909-16	22 3/4" long	25	Jorum	1340	1 11 oz.
4057B	Hood board—right	1917-19		25	Kine	8741	1
4060	Hood support on dash	1909-14		1 50	Jupon	1334	1 2 lb., 2 oz.
4060B	Hood support on dash	1915-16		1 50	Juror	7464	1
4060C	Hood pad (on dash)	1917-19		05	Kite	8711	1
4060D	Hood pad (on radiator shell)	1917-19		1.00 1.25	Kid	8710	1
4061B	Hood clasp (on dash)	1917-19		05	Kit	8720	1
4061C	Hood clasp (on dash) screw	1917-19		02	Knee	8763	2
4073	Hood block support—front right	1917-19		05	Knot	8743	1
4074	Hood block support—front left	1917-19		05	Kiln	8744	1
4075	Hood block support—rear right	1917-19		05	King	8745	1
4076	Hood block support—rear left	1917-19		05	Kirk	8746	1

WIRING

4350	Spark plug wire	1909-19	14 1/8", No. 1 cyl.	15	Nohob	1365	1 2 oz.
4351	Spark plug wire (also magneto to coil)	1909-19	10 1/4", No. 2 cyl.	15	Nachor	1366	1 2 oz.
4353	Spark plug wire	1909-19	7", No. 3 and 4 cyls.	10	Nalad	1376	2 1 oz.
4354	Spark plug wire terminal	1909-19		03	Nailer	1381	8
4355	COMMUTATOR WIRE	1909-19		75	Nandu	7502	1 8 oz.
4357	Com. wire terminal	1909-19	(Coil end)	01	Napher	1385	4
4359	Com. wire loom support	1909-19		03	Napple	1390	2

KINGSTON CARBURETOR

6100	Carburetor complete	1909-19		6 00	Mason	553E	1 3 lb., 14 oz.
6101A	Carburetor float assb.	1917-19		1 00	Moslem	6369	1
6101	Float with lever	1915-16		1 00	Marsh	6351	1
6127A	Gasoline valve	1917-19		35	Moral	6377	1
6115	Spray needle assembly	1910-19		50	Medal	3010	1

Parts for 1909-16 Carburetors supplied by Bryne Kingston Co., Kokomo, Ind.

HOLLEY CARBURETOR

6040	Carburetor complete	1909-19		6 00	Mire	553D	1 3 lb., 3 oz.
4451A	Float with lever	1914-19		1 00	Muzzle	6333	1
4452A	Spray needle assembly	1914-19		50	Myrtle	6335	1
4453A	Gasoline inlet needle	1914-19		30	Mystic	6324	1

(Other parts required may be ordered by plate numbers; prices quoted on application.)

Parts for 1909-13 Carburetors supplied by Holley Kerosene Carburetor Co., Detroit, Mich.


CARBURETOR ATTACHMENTS

4127A	Carb. adjusting rod bracket	1909-19	On dash	05	Lastage	1357	1 4 oz.
4129A	Carb. adjusting rod	1909-19		15	Latten	7920	1 4 oz.
4130	Carb. flange bolt and nut	1909-19		05	Leaper	1388-517	2 1 oz.
4134	Carb. flange gasket	1909-19		05	Lecturn	1380B	1
4431	Carb. priming rod	1909-19		05	Loach	2009	1 1 oz.
4582	Carb. hot air pipe	1912-19		15	Monkey	680	1 6 oz.

FORD SPARK COIL

4725	Coil	1909-19		13 00	Negus	1383	1 14 lb.
4725B	Coil (starter type)	1919		12 25	Neil	7920	1
4726	Coil box with cover	1914-19	Metal	3 00	Nenia	5858	1 4 lb.
4726B	Coil box with cover	1919	Starter type	2 25	Nepeta		1
4727	Coil box cover	1914	Metal	40	Nepew	5856	1 11 oz.
4727B	Coil box cover	1915-19		30	Neptune	7910	1

Insist upon genuine Ford parts



6040



4451A



6101A



6100



6042



4452A



6115



6101



6048



4453A



6104



6124A



6052



6126A



6041



6055



6126



6107A



6076



6125



6057



6061



6127



6127A



6070



6077



6102



6103A



4431



6046



4582



6106A



4728



4727-B



4731



4732



4725



4733



4734




4736



4736-A



4739



4353

4350

4351

4355



4737




4737-A



4740



4800
4801



4800B
4801B



4802D
4803D



4802E
4803E



4804D



4802F
4803F




4806




4812




4809




4814
4815




4816




4817



4814B
4815B



4814C
4815C



4818

Part No.	Name of Part	Year	Specifications	Price	Code Word	Fac.No. per Car	Req. Weight
----------	--------------	------	----------------	-------	-----------	-----------------	-------------

FORD SPARK COIL—Continued

4728	Switch assembly	1914-19		\$ 0 75	Nidor	5873	1 9 oz.
4730	Switch cover	1914-19		05	Nones	5835	1 1 oz.
4731	Switch plug	1914-19		05	Nopal	5815	1
4732	Coil unit	1914-19	3 1/2" x 2 1/4" x 5 1/2"	2 50	Noggin	5845	4 2 lb.
4733	Vibrator with tungsten point	1914-19		15	Nonce	6797	4
4734	Vibrator bridge with tungsten point	1914-19		20	Novia	6702	4

FENDERS—56 INCH TREAD

4800	Front fender—right	1910-16	All Cars	6 00	Scorch	1414C	1
4800B	Front fender—right	1917-19	All Cars	5 00	Nook	7976	1
4801	Front fender—left	1910-16	All Cars	6 00	Scoul	1413C	1
4801B	Front fender—left	1917-19	All Cars	5 00	Noose	7977	1
4802D	Rear fender—right	1915-16	Tour., Runab't & Coupelet	4 00	Shanty	1416D	1
4802F	Rear fender—right	1917-19	All Cars	4 00	Norse	8850	1
4803D	Rear fender—left	1915-16	Tour., Runab't & Coupelet	4 00	Sheen	1415D	1
4803F	Rear fender—left	1917-19	All Cars	4 00	Nougat	8851	1
4804D	Rear fender iron—right and left	1913-19	Touring car	15	Smile	5405A	2 12 oz.
4804E	Rear fender iron—right	1913-19	Torpedo & Coupelet	60	Shire	5563	1 1 lb., 7 oz.
4804F	Rear fender iron—left	1913-19	Torpedo & Coupelet	60	Shrub	5390	1 1 lb., 7 oz.
4804G	Rear fender iron—right or left	1916-19	Sedan	50	Nubble	8154A	2
4804H	Rear fender iron—right or left	1918-19	Touring car	15	Shewd	5405B	1
4804K	Fender iron—right or left	1918-19	Sedan	50	Shoggle	8154B	2
4805B	Rear fender iron bolt and nut	1915-19	Touring, 3/8" x 1 1/2"	05	Signet	8161-341	6
4806	Fender eye bolt, nut and washer	1909-19	Old No. 2935	10	Blenny	1945	6 3 oz.
4808	Front fender iron bolt and nut (side)	1910-19	3/8" x 1 1/2"	05	Shovel	1323-8	2 1 oz.
4808B	Front fender iron bolt and nut (bottom)	1910-19	3/8" x 1 1/2"	05	Siren	347-8	2
4808C	Front fender apron to frame bolt and nut	1915-19	1/2" x 3/8"	05	Sickle	4088-1309	4
4809	Front fender iron—right or left	1909-19		90	Sistom	343	2 1 lb., 14 oz.

RUNNING BOARDS AND SHIELDS—56 INCH TREAD

4812	Running board—right or left	1909-19	44 1/2" long	2 00	Shrew	5418	1
4814	Running board metal shield—right	1912-16	Tour., Tor. and Coupelet	2 25	Skylark	1409C	1
4814C	Running board shield—right	1917-19	All Cars	2 70	Shrine	7986	1
4815	Running board metal shield—left	1912-16	Touring and Torpedo	2 25	Skylight	1408C	1
4815C	Running board shield—left	1917-19	All Cars	2 70	Shroud	7987	1
4816	Running board truss rod—front with nuts	1909-19		40	Skybird	5804	1 2 lb., 2 oz.
4817	Running board truss rod—rear with nuts	1909-19		40	Skyman	5805	1 2 lb., 2 oz.
4818	Running board bracket	1909-19		75	Skyhawk	336	4 1 lb., 13 oz.
4819	Run. board fender bolt and nut	1909-19	1/2" x 1 1/4"	05	Boaster	1344B-1309	8
4819B	Run board bolt and nut	1909-19	3/8" x 1 1/4"	05	Bolary	8448-341	8

FENDERS AND RUNNING BOARDS—60 INCH TREAD—BLUE

4820B	Front fender—right	1913-16	Touring and Torpedo	6 00	Table	2742	1
4821B	Front fender—left	1913-16	Touring and Torpedo	6 00	Tabula	2743	1
4822C	Rear fender—right	1915-16	Tour., Torpedo, Coupelet	5 00	Tartar	2758	1
4823E	Rear fender—left	1915-16	Tour., Torpedo, Coupelet	5 00	Tavern	2759	1
4824C	Rear fender iron—right and left	1915-16	Touring Car	40	Thatch	1723	2
4825B	Front fender iron—right and left	1915-16	Order No. 4809				
4829	Running board truss rod—front	1909-12	51" long, Tour. and Torp.	50	Bosset	1708	2
4830	Running board truss rod—rear	1909-12	Tour., Torp. and Roadster	50	Bounce	1734	1

STARTER PARTS

4900	Ammeter			2 75	Tassel	7680	1
4901	Bendix			6 00	Tattler	1883	1
4902	Bracket (battery)			1 25	Tattoo	8841	1
4902 1/2	Bracket with bushing (motor mounting)			2 50	Tawny	2037	1
4903	Block (terminal)			25	Teller	1950	1
4904	Bolt and nut (battery terminal)			15	Temple	1937-1938	2
4905	Cut-out (electric)			1 50	Tenant	7677	1
4905B	Cut-out (electric)			1 75	Tendril	7677B	1
4906	Cover (Bendix)			40	Tendon	1763	1
4907	Crank (priming bell)			30	Tenet	7691	1

Insist upon genuine Ford parts



4936



4915



4900



4913




4934



4906




4933



4902½



4914



4901



4931



4910½



4916



4920



4937



4911




4938




4932



4925




4908



4909




4910



4947

4951




4949




4939


4941




4952



4940



4946




4950

Part No.	Name of Part	Year	Specifications	Price	Code Word	Fac.No. Req. No. per Car	Mailing Weight
STARTER PARTS—Continued							
4908	Cable (battery to switch)			50	90	Tepor	1859B. 1
4908B	Cable (battery to switch)			1	00		1889C. 1
4909	Cable (ground)			70	50	Terse	1890. 1
4909B	Cable (ground)			50	50		1890B. 1
5909C	Cable (ground)			35	50		1890C. 1
4910	Cable (switch to motor)			75	100	Tether	1891. 1
4910 1/2	Extension (starting switch plunger)			10		Tetric	8793. 1
4911	Generator			22	00	Tetter	1879. 1
4912	Gasket (generator bracket)			02		Thane	1775. 1
4913	Gasket (generator head)			02		Thebe	1774. 1
4914	Gasket (motor mounting bracket)			02		Theme	1768. 1
4915	Gasket (Bendix cover)			05		Thigh	1764. 1
4916	Head (Bendix)			50		Thine	2007. 1
4917	Key (Bendix)			02		Tholl	1751. 1
4918	Keys (ignition switch)			15		Thrall	5815B. 1
4919	Knob (priming rod)			15		Thrill	8779. 1
4920	Motor (starting)			22	00	Tigris	1877. 1
4921	Nut (generator terminal)			05		Tiling	1818. 3
4922	Plate (time gear cover)			10		Tillage	1773. 1
4923	Plate (transmission cover rear)			10		Throb	1761. 1
4924	Plate (transmission cover front)			15		Throne	1758. 1
4925	Pinion (generator)			80		Throng	1752. 1
4926	Plate (priming rod) Coupe			15		Thrum	7664. 1
4927	Plate (priming rod) Sedan			15		Thrust	7665. 1
4928	Rod (priming) Sedan			10		Thule	8795B. 1
4929	Rod (priming) Coupe			10		Thumb	8796. 1
4930	Rod (carburetor priming)			05		Thunder	8797. 1
4931	Shaft and gear (Bendix)			4	50	Thurl	2026. 1
4932	Spring (Bendix)			75		Tinge	2006. 1
4933	Screw (Bendix shaft spring)			10		Tinsel	1983. 1
4934	Screw (Bendix head spring)			10		Tipple	1781. 1
4935	Screw (terminal block to dash)			01		Tocsin	2073. 2
4935 1/2	Screw (generator mounting bracket, long) Order 3182B			2	25	Tokay	7675. 1
4936	Switch (ignition)			2	25		7675E. 1
4936B	Switch (ignition)			1	50	Topaz	8792. 1
4937	Switch (starting)			05		Toper	1782. 2
4938	Washer (Bendix spring screw lock)			30		Topic	7683. 1
4939	Wire (ammeter to cut-out) Sedan			15	30		7683B. 1
4939B	Wire (ammeter to cut-out) Sedan			20		Torch	7684. 1
4940	Wire (ammeter to cut-out) Coupe			16	20		7684B. 1
4940B	Wire (ammeter to cut-out) Coupelet			10	00	Torpid	7681. 1
4941	Wire (ammeter to ignition switch)			12		Trash	7687. 1
4946	Wire (generator to cut-out)			10	05	Trench	8894B. 1
4947	Wire (terminal block to switch)			1	00	Trifle	7502B. 1
4949	Wire (commutator)			1	00	Tromp	7682B. 1
4950	Wire (lighting)			80		Troch	7685B. 1
4951	Wire (switch) Sedan			70		Truce	7686B. 1
4952	Wire (switch) Coupe						

REPAIR TOOLS

1349	Hub cap wrench	Regular equipment	20	Pacal	1349
1387	Adjustable wrench	Regular equipment	50	Pacos	1387
1902	Screw driver	Regular equipment	25	Padan	1902
1903	Pliers	Regular equipment	30	Paddy	1903
1917	Double end wrench	Regular equipment	20	Pagan	1917
2335	Spark plug and cyl. head bolt wrench	Regular equipment	50	Pavid	5893
2336	Tool roll	Regular equipment	30	Pawky	1979
2337	Oil can	Regular equipment	25	Paxos	1384
2338	Tire pump	Regular equipment	1 50	Payser	1368
2340	Tire irons, each	Regular equipment	15	Pelage	4069
2343	Jack	Regular equipment	45-40	Poser	3389
3Z-775	3/8" socket wrench	8 1/2" long	60	Pallah	
3Z-1179	Fly wheel cap screw wrench	13 1/2" long	90	Palmy	
3Z-602	Valve spring lifter	15" long	40	Palpus	
3Z-703	Tire iron (large)		50	Pathos	
3Z-604	Valve grinder		1 00	Palster	
3Z-612	Rear wheel puller assembly		1 50	Panary	
3Z-611	Cam gear puller		2 25	Pantile	
3Z-614	Transmission clutch puller		1 25	Papaw	
3Z-620	Drive shaft housing stud nut wrench for 1 1/2" nut		50	Parent	
3Z-616	Rear axle housing bolt nut wrench	7 1/2" long	50	Parvis	
3Z-617-1	Valve seat reamer	7 1/2" long	2 75	Papula	
3Z-643	3/8" T socket wrench	9 1/2" long	75	Parfit	
3Z-644	Socket wrench for crank shaft bearing bolt nut	12 1/2" long	60	Passim	
3Z-645	3/8" L socket wrench	12"	60	Pastel	

Insist upon genuine Ford parts



Part No.	Name of Part	Year	Specifications	Price	Code Word	Fac. No. Req. No. per Car	Mailing Weight
----------	--------------	------	----------------	-------	-----------	---------------------------	----------------

REPAIR TOOLS—Continued

3Z-646	$\frac{3}{8}$ " open end wrench		7 $\frac{1}{2}$ " long	\$ 0 30	Pastor		
3Z-647	Connecting rod clamp screw wrench		10 $\frac{1}{4}$ " long	75	Parrot		
3Z-1223B	$\frac{3}{8}$ " brace socket wrench		24 $\frac{3}{4}$ " long	1 00	Parsee		
3Z-652	Piston ring squeezer		3 $\frac{3}{8}$ " dia.	25	Patile		
3Z-655	Large cam gear lock nut wrench		14" long	70	Pavan		
3Z-619	Crank shaft bearing bolt wrench		Oval head	60	Pelox		
3Z-722	Crank shaft bearing bolt wrench		Square head	50	Poloy		
3Z-2034	Trans. b a n d ratchet wrench			60	Poplin		
3Z-675	Rear axle nut open end wrench			1 00	Porite		
3Z-624	Exhaust pack nut open end wrench			1 25	Potash		
3Z-627	Rear axle entering wrench			75	Potion		
3Z-673	Body bracket connecting bolt T wrench, front and center			75	Prater		
3Z-686	Body bracket connecting bolt holding open end wrench			40	Preen		
3Z-698	Cylinder water outlet connecting screw brace wrench			80	Prince		
3Z-699	Brake shoe support bolt brace wrench			50	Profile		
3Z-719	Spindle cone adjusting open end wrench			65	Proverb		
3Z-738	Body bracket connecting bolt R. & L. wrench			60	Prude		
3Z-751	Riveting bar for starting crank ratchet pin			1 00	Pulpit		
3Z-765	Rear axle nut and housing plug brace wrench			75	Pulsion		
3Z-785	Coil to dash bolt nut brace wrench			1 00	Pumice		
3Z-1173	Front radius rod ball cap screw brace wrench			1 00	Pusil		
3Z-786	Cylinder head cap screw brace wrench			1 00	Puzzle		
3Z-790	Drive shaft pinion T wrench			90	Pygmy		
3Z-783	Connecting rod T wrench			50	Quack		
3Z-2010	Connecting rod cap bolt nut L wrench (Cylinder No. 4)			40	Quince		
3Z-1955	Front wheel ball race drift			90	Quinsy		
3Z-1956	Spindle arm bushing driver						

COTTER PINS

Fac. No.

$\frac{1}{8}$ " x 1" cotter pins	421	$\frac{1}{8}$ " x $\frac{1}{2}$ " cotter pins	66
$\frac{1}{8}$ " x $\frac{3}{4}$ " cotter pins	753	$\frac{1}{8}$ " x $\frac{3}{4}$ " cotter pins	544
$\frac{1}{8}$ " x 1" cotter pins	82	$\frac{1}{8}$ " x $\frac{5}{8}$ " cotter pins	88
Price, per dozen			\$0 05
Price, per gross			25

Fac. No.

NUTS

$\frac{3}{8}$ "—24 thds.	03
This size nut used on following parts: 2514, 2722, 2729B, 3073, 3074, 3362, 3437, 3443, 2514B, 2741, 3010, 4041, 4808, 4808B	

Insist upon genuine Ford parts

Price List of Accessories and Accessory Parts


Part No.	Name of Part	Make	Year	Code	Price
ELECTRIC HORN					
6432X	Electric horn complete.			Ulcer	\$ 2 50
7915X	Electric horn terminal wire 9"			Ulna	05
7917X	Electric horn to switch wire 35 1/8"			Ultra	15
ELECTRIC HEAD LAMPS (STANDARD 1915-19)					
6511X	Head lamp assembly—8 3/8" lens, per pair.			Umpire	7 50
6511BX	Head lamp assembly—per pair (Dimmer type).	1919		Unport	8 00
6594X	Head lamp door assembly.			Union	7 40
6589X	Head lamp switch assembly—with screws.			Ural	35
8650X	Head lamp and horn switch assembly.			Urith	40
8892X	Dimmer resistance coil with wires.			Urbox	70
6572X	Head lamp Mazda bulb—8-9 volt used with magneto			Urban	50 40
6572CX	Head lamp Mazda bulb (6-8 volt single contact used with storage battery)	1919		Urcan	40
6520X	Dimmer bulb (for head and tail lamp) 6-8 volt 2 cp. single contact.	1919		Vamos	27
6578X	Head lamp door lens gasket.			Urchin	05
6576X	Head lamp door lens—8 3/8"			Urn	20
6592X	Head lamp plug—with thimble.			Urus	20
6585X	Head lamp reflector.			Urva	1 20
6585BX	Head lamp reflector (dimmer type).	1919			1 20
6577X	Head lamp door lens retainer.			Usher	05
6580X	Head lamp focusing screw.			Utas	05
6591X	Head lamp focusing screw spring.			Ute	03
6574X	Head lamp bulb socket.			Vagrant	20
6586X	Head lamp reflector spring.			Vail	10
7487X	Switch to terminal wire—11 3/4" long.			Valise	05
7489X	Lamp to lamp wire—40" long.			Vallum	15
7490X	Lamp to ground wire—10 3/4" long.			Vamp	05
SIDE OIL AND TAIL LAMPS—1915-19					
6561X	Side oil lamp, per pair.			Van	3 50
6568X	Tail lamp.			Vandal	1 75
7669X	Electric tail lamp assembly.	1919		Vanquish	1 25
6471X	Electric tail lamp red lens.	1919		Vales	15
6599X	Side oil and tail lamp fount.			Vane	50
6956X	Side oil lamp door.			Vanish	50
6957X	Tail lamp door.			Vapid	50
6966X	Tail lamp white lens and frame.			Vapor	20
6460X	Lamp burner including wick.			Varix	30
6958X	Lamp chimney case.			Varus	30
6472X	Lamp chimney.			Vase	30
6959X	Lamp chimney cover.			Vassal	25
6483X	Side oil lamp door lens.			Vat	15
6484X	Tail lamp door red lens.			Vault	15
6393X	Side oil lamp to bracket bolt nut.			Veal	03
6486X	Lamp door hinge pin.			Veer	05
6392X	Lamp wick.			Vega	02
TOURING CAR AND TORPEDO WINDSHIELDS—1915-19					
*7840X	Windshield assembly, less brackets, bolts, nuts and washers.			Vender	15 00
7818AX	Windshield hinge assembly—Right.			Venoth	45
7818BX	Windshield hinge assembly—Right.	1917-19		Vent	45
7819AX	Windshield hinge assembly—Left.			Venus	45
7819BX	Windshield hinge assembly—Left.	1917-19		Verb	45
7820AX	Windshield upper frame assembly.	1915-16		Verge	1 50
7820BX	Windshield frame assembly—upper.	1917-19		Vermin	1 50
7822AX	Windshield upper half assembly.	1915-16		Verse	6 50
7822BX	Windshield upper half assembly.	1917-19		Verst	6 50
7823X	Windshield lower half assembly.	1915-19		Vertex	8 50
7802X	Windshield lower frame only.	1915-19		Venge	1 20
7803X	Windshield lower frame filler block.	1915-19		Verve	20
7839X	Windshield frame filler block.			Verwet	15
7888X	Windshield block (frame filler)—upper.	1917		Vesper	15
7810X	Windshield hinge bolt.			Vespid	05
7845X	Windshield bracket—right.	1915-19		Vestal	75 50
7846X	Windshield bracket—left.	1915-19		Vestry	75 50
7824X	Windshield glass clamp.			Veto	05
7801X	Windshield frame—upper.	1915-16		Vial	90
7887X	Windshield frame—upper.	1917-19		Vicar	90
7804X	Windshield left hand lower hinge.			Victor	15
7890X	Windshield hinge—lower left.	1917-19		View	15
7805X	Windshield left hand upper hinge.			Viking	15
7806X	Windshield right hand lower hinge.			Villa	20
7889X	Windshield hinge—lower right.	1917-19		Vim	20
7807X	Windshield right hand upper hinge.			Vina	15
3827X	Windshield top snap loop.			Vine	05
1154X	Windshield hinge bolt nuts.			Vintage	05
2449BX	Windshield glass clamp screw.			Viol	01
2257BX	Windshield hinge to frame screw (Order 3367).				
6013X	Windshield hinge spring.			Virgin	03
7851X	Windshield upper glass stop—nickel.	1915-19		Vise	35
7852X	Windshield lower glass stop—nickel.	1915-19		Vitals	35
7808X	Windshield hinge thimble.			Vitex	05

*Order 7845X-7846X extra for 1915-16 cars.

Insist upon genuine Ford parts



6562-X



6594-X




6511-X




6585-X




6586-X



6576-X



7490-X




6578-X



7487-AX



8650-X



7489-X



6572-X



8894-X




6592-X




8892-X



6574-X



6561



6456



6568



6956



6458



6957



6472



6460



6478



6966



6490



7922



6959



6492



6958



1154



6486



6599

Part No.	Name of Part	Make	Year	Code	Price
TOURING CAR TOPS—1915-19					
7940X	Touring car top complete		1915-19	Warm	
6882X	Touring car storm curtain (R. H.)		1915-19	Warp	\$2 50
6882BX	Touring car storm curtain (R. H.)		1915-19	Warren	2 50
6883X	Touring car storm curtain (L. H.)		1915-19	Wart	2 50
6883BX	Touring car storm curtain (L. H.)		1915-19	Wash	2 50
4966BX	Touring car side curtain (R. H.)		1915-19	Wasp	3.00 2.40
4967BX	Touring car side curtain (L. H.)		1915-19	Waste	3.00 2.40
6894X	Touring car center deck complete		1915-19	Watch	5 00
6886X	Touring car center deck only 91 1/4" x 50"		1915-19	Water	1 50
6895X	Touring car side quarter (R. H.)		1915-19	Watt	1 25
6896X	Touring car side quarter (L. H.)		1915-19	Wave	1 25
6815X	Touring car side quarter pad (R. H.)		1915-19	Wax	3 00
6816X	Touring car side quarter pad (L. H.)		1915-19	Weak	75
6940X	Touring car back stay and curtain assembly		1915-19	Weapon	75
6866X	Touring car wood bow (1st)		1915-17	Web	75
3897X	Touring car wood bow (2nd and 3rd)		1913-17	Yawn	25
4957X	Touring car wood bow—rear		1914-17	Yell	25
8973X	Touring car front and rear extension rib		1918-19	Wedge	05
8974X	Touring car front and rear upright rib		1918-19	Weed	05
4596X	Touring car bow separator—male		1913-17	Whelp	05
4597X	Touring car bow separator—female		1913-17	Weep	75
6832X	Touring car bow separator		1918-19	Wealth	1 00
6860AX	Touring car front extension bow socket (R. H.)		1915-17	Weir	75
6860BX	Touring car front extension bow socket (R. H.)		1918-19	Weary	1 00
6861AX	Touring car front extension bow socket (L. H.)		1915-17	Weld	75
6861BX	Touring car front extension bow socket (L. H.)		1918-19	Wedding	1 00
3884AX	Touring car rear extension bow socket (R. H.)		1913-17	Welkin	75
3884BX	Touring car rear extension bow socket (R. H.)		1918-19	Welt	1 00
3885AX	Touring car rear extension bow socket (L. H.)		1913-17	Well	1 00
3885BX	Touring car rear extension bow socket (L. H.)		1918-19	Whig	1 00
6862AX	Touring car front upright bow socket (R. H.)		1915-17	Welsh	1 00
6862BX	Touring car front upright bow socket (R. H.)		1918-19	Whilk	1 00
6863AX	Touring car front upright bow socket (L. H.)		1915-17	West	1 00
6863BX	Touring car front upright bow socket (L. H.)		1918-19	Yauk	1 00
3882AX	Touring car rear upright bow socket (R. H.)		1913-17	Wether	1 00
3882BX	Touring car rear upright bow socket (R. H.)		1918-19	Yawl	1 00
3883AX	Touring car rear upright bow socket (L. H.)		1913-17		
3883BX	Touring car rear upright bow socket (L. H.)		1918-19		
7831X	Curtain to windshield hook		1915-19		03
7832X	Curtain to body hook		1915-19		03
6837X	Touring car key strap assembly		1913-18	Whale	05
8992X	Rib socket cotter		1918-19	Wheeze	03
3924X	Touring car top to windshield strap assembly		1915-19	Wharf	50
3629X	Touring car rear stay strap assembly complete		1913-19	Wheat	55
3631X	Touring car rear stay strap—short—lower		1913-19	Whiff	25
3632X	Touring car rear stay strap—long—upper		1913-19	Whim	30
6925X	Touring car curtain to windshield strap assembly		1915-19	Whine	10
6926X	Touring car curtain to lamp bracket strap assembly		1915-19	Whip	10
3754X	Touring car curtain glove fastener assembly		1913-19	Whist	05
6829AX	Touring car duquesne clip—upper		1914-17	Whoop	10
6829BX	Touring car extension support—upper		1918-19	Yelk	10
6830AX	Touring car duquesne clip—lower		1914-17	Wick	10
6830BX	Touring car extension support—lower		1918-19	Yeoman	05
3316X	Touring car top brass fastener—single		1913-16	Widow	05
3549X	Touring car top brass fastener—double		1913-16	Wife	05
8937X	Touring car top snap fastener—single		1917-19	Wig	05
8938X	Touring car top snap fastener—double		1917-19	Willow	06
3314X	Touring car top prop rest with strap		1913-19	Wind	60
3858X	Touring car top prop rest arm		1913-19	Wine	25
3624X	Touring car bow-socket to seat iron japanned nut		1913-19	Wing	05
3383X	Curtain celluloid 20" x 36"—.015 thick		1913-19	Wink	1 60
3383X	Curtain celluloid 10" x 18"—.015 thick		1913-19	Winter	45
6881X	Touring car top dust hood		1915-19	Wire	3 50

TORPEDO TOP PARTS—1915-19

*7941X	Torpedo top complete		1915-19	Wisdom	
4971X	Torpedo top—second and third wood bows		1914-19	Wish	50
6929X	Torpedo top—first bow		1915-19	Wisp	50
6870X	Torpedo top bow socket—upright—(R. H.)		1915-19	Witch	90
6871X	Torpedo top bow socket—upright—(L. H.)		1915-19	Witch	90
6873X	Torpedo top bow socket—front extension—(L. H.)		1915-19	Witness	80
6872	Torpedo top bow socket—front extension—(R. H.)		1915-19	Wizard	80
4907X	Torpedo top bow socket—rear extension—(R. H.)		1913-19	Wolf	80
4908X	Torpedo top bow socket—rear extension—(L. H.)		1913-19	Woman	80
6937X	Torpedo top side curtain—rear—(R. H.)		1915-19	Wood	1 60
6938X	Torpedo top side curtain—rear—(L. H.)		1915-19	Word	1 60
6935X	Torpedo top side curtain—front—(R. H.)		1915-19	Work	2 25
6935BX	Torpedo top side curtain—front—(R. H.)		1915-19	World	2 25
6936X	Torpedo top side curtain—front—(L. H.)		1915-19	Worm	3 00
6936BX	Torpedo top side curtain—front—(L. H.)		1915-19	Worry	6 00
6950X	Torpedo top back curtain assembly		1915-19	Wrap	2 80
6965X	Torpedo top center deck complete		1915-19	Wreck	1 00
6964X	Torpedo top deck only		1915-19	Wren	1 00
6962X	Torpedo top side quarter—(R. H.)		1915-19	Wrist	1 00
6963X	Torpedo top side quarter—(L. H.)		1915-19	Yacht	1 00
6806X	Torpedo top side quarter pad—(R. H.)		1914-19	Yak	3 30
6807X	Torpedo top side quarter pad—(L. H.)		1914-19	Yam	60
6939X	Torpedo top hood		1915-19		
3877X	Torpedo top prop rest with strap		1913-19		


*Inquire of Branch or Dealer for price.

Insist upon genuine Ford parts

Price List of Parts for Model T One Ton Truck

Part No.	Name of Part	Year	Price	Code Word	Model	Fac. No.	Req. per Car
REAR AXLE							
1000	Rear axle assembly	1918-19	\$200 00	Abed	TT	95	1
1001	Axle housing assembly—right	1918-19	25 00	Abyss	TT	4	1
1002	Axle housing assembly—left	1918-19	25 00	Acme	TT	5	1
1003	Axle housing bolt and nut	1918-19	10	Acorn	TT	52-T220	13
1004	Axle housing cap	1918-19	40	Actor	TT	133	1
1005	Axle housing cap gasket	1918-19	62	Acute	TT	134	1
1006	Axle housing cap screw	1918-19	15	Adder	TT	72	4
1007	Axle housing cap screw lock wire	1918-19	62	Addle	TT	140	1
1008	Axle housing gasket—upper	1918-19	62	Agate	TT	138	1
1009	Axle housing gasket—lower	1918-19	63	Agast	TT	139	1
1010	Axle brake housing plate—right	1918-19	50	Agile	TT	147	1
1011	Axle brake housing plate—left	1918-19	50	Akin	TT	148	1
1012	Axle housing drain plug	1918-19	05	Alder	TT	136	2
1013	Axle shaft and nut	1918-19	7 15	Alex	TT	48	2
1014	Axle shaft cotter	1918-19	01	Alms	TT	165	2
1015	Axle shaft nut	1918-19	15	Aloe	TT	166	2
1016	Axle shaft washer	1918-19	05	Aloft	TT	135	2
1017	Axle shaft dust cap	1918-19	05	Alpha	TT	56	2
1018	Axle shaft inner ball bearing assembly	1918-19	6 00	Alpine	TT	125	2
1019	Axle shaft outer roller bearing assembly	1918-19	2 00	Archer	TT	171	2
1020	Axle shaft outer roller bearing sleeve	1918-19	30	Arena	TT	170	4
1021	Axle shaft bearing felt	1918-19	10	Argue	TT	143	2
1022	Axle shaft bearing retainer	1918-19	15	Ark	TT	20	2
1023	Axle shaft bearing retainer washer	1918-19	05	Arson	TT	23	2
1024	Axle shaft felt retainer assembly	1918-19	20	Astral	TT	144	2
1025	Axle shaft felt retainer cup	1918-19	05	Atwist	TT	145	2
1026	Axle shaft felt retainer plate	1918-19	03	Atoll	TT	146	2
1027	Diff. gear	1918-19	3 00	Aura	TT	11	2
1028	Diff. gear case R. or L. half	1918-19	3 00	Author	TT	11	2
1029	Diff. gear case bolt	1918-19	10	Avail	TT	52	8
1030	Order T2719						
1031	Diff. gear lock ring	1918-19	05	Avoke	TT	118	2
1032	Diff. pinion	1918-19	1 00	Awake	TT	14	2
1033	Diff. pinion shaft	1918-19	40	Awry	TT	15	1
1034	Drive shaft	1918-19	10 00	Bait	TT	87	1
1036	D. S. tube assembly	1918-19	15 00	Balm	TT	153	1
1037	D. S. tube flange gasket	1918-19	02	Bandit	TT	194	1
1038	D. S. tube flange screw	Order 1006					
1039	D. S. felt	1918-19	10	Basil	TT	109	1
1040	D. S. felt container	1918-19	05	Beaver	TT	110	1
1041	D. S. to worm coupling	1918-19	1 50	Behind	TT	85	1
1042	D. S. to worm coupling pin	1918-19	03	Behold	TT	86	2
1043	Worm	1918-19	18 00	Berg	TT	16	1
1044	Worm gear	1918-19	20 00	Bible	TT	12	1
1045	Worm cotter	Order 1014					
1046	Worm roller bearing assembly	1918-19	1 50	Bight	TT	108	2
1047	Worm roller bearing retainer	1918-19	10	Bigot	TT	106	1
1048	Worm roller bearing sleeve	1918-19	1 60	Bilge	TT	107	2
1049	Worm roller bearing housing screw	1918-19	05	Birch	TT	101	2
1050	Worm thrust bearing collar	1918-19	1 50	Bird	TT	114	2
1051	Worm thrust ball and separator assembly	1918-19	1 35	Bitter	TT	123	1
1052	Worm thrust bearing plate	1918-19	15	Blaze	TT	22	1
1053	Worm thrust bearing retainer	1918-19	60	Bleach	TT	111	1
1054	Worm thrust bearing retainer nut	Order 1015					
1055	Worm thrust bearing retainer pin	1918-19	03	Blend	TT	112	1
1056	Brake shoe assembly	1918-19	50	Blind	TT	2814	2
1057	Brake shoe lining, each	1918-19	20	Blink	TT	58	4
1058	Brake shoe lining rivet	1918-19	03	Blue	TT	68	40
1059	Brake shoe spring	1918-19	05	Blunt	TT	67	2
1060	Brake shoe bolt and nut	1918-19	30	Blush	TT	59-T242	2
1061	Brake expander	1918-19	80	Bodkin	TT	61	2
1062	Brake expander lever	1918-19	20	Booth	TT	62	2
1064	Brake expander adjustment collar	1918-19	30	Brig	TT	175	2
1065	Brake expander bushing	1918-19	15	Bronze	TT	173	2
1066	Brake expander pin	1918-19	03	Brook	TT	7	2
1067	Brake expander link	1918-19	05	Broom	TT	176	4
1068	Brake expander link pin	1918-19	05	Brow	TT	177	8
1069	Brake rod	1918-19	50	Brush	TT	119	2
1070	Brake rod support—right	1918-19	10	Buck	TT	120	1
1071	Brake rod support—left	1918-19	10	Bug	TT	121	1
1072	Brake rod support bolt and nut	1918-19	05	Buoy	TT	1308-T1309	2
1073	Rear radius rod	1918-19	6 00	Burn	TT	152	2
1074	Rear radius rod bolt and nut—front	1918-19	40	Crab	TT	84-T242	1
1075	Rear radius rod bolt and nut—rear	1918-19	30	Crag	TT	83-T242	4
1076	Universal joint bushing	1918-19	75	Grape	TT	69	1
SPRING							
1077	Rear spring—right or left, each	1918-19	6 00	Cream	TT	333	2
1078	Spring leaf No. 1	1918-19	1 20	Creed	TT	361	2
1079	Spring leaf No. 2	1918-19	90	Crew	TT	362	2
1080	Spring leaf No. 3	1918-19	75	Crib	TT	363	2
1081	Spring leaf No. 4	1918-19	70	Crisp	TT	364	2
1082	Spring leaf No. 5	1918-19	65	Croak	TT	365	2
1083	Spring leaf No. 6	1918-19	55	Crop	TT	366	2
1084	Spring leaf No. 7	1918-19	50	Croup	TT	367	2
1085	Spring leaf No. 8	1918-19	40	Crow	TT	368	2
1086	Spring leaf No. 9	1918-19	35	Crowd	TT	331	2

Insist upon genuine Ford parts



Part No.	Name of Part	Year	Price	Code Word	Model No.	Fac. No.	Req. per Car
SPRING—Continued							
1087	Spring bushing	1918-19	\$ 0 20	Crumb	TT	332	2
1088	Spring clip	1918-19	50	Crush	TT	326	2
1089	Spring clip nut	1918-19	15	Cry	TT	327	4
1091	Spring clip plate	1918-19	45	Cuff	TT	329	2
1092	Spring tie bolt	1918-19	35	Cult	TT	330	2
1093	Spring tie bolt nut. Order 1089	1918-19					
1094	Spring tie bolt cotter	1918-19	01	Cure	TT	328	2
1095	Spring clamp	1918-19	10	Curl	TT	375	2
1096	Spring clamp bolt and nut	1918-19	05	Curse	TT	376-T926	2
1097	Spring perch	1918-19	1 20	Dale	TT	2804	2
1098	Spring perch nut. Order 1015	1918-19					
1099	Spring perch cotter. Order 1014	1918-19					
1100	Spring perch bushing	1918-19	30	Demon	TT	172	2
1101	Spring perch bushing spacer	1918-19	05	Dean	TT	169	4
1102	Spring hanger assembly	1918-19	40	Dike	TT	91	4

STEERING GEAR

1105	Steering gear bracket	1918-19	1 00	Dream	TT	996	1
1106	Steering gear bracket block	1918-19	05	Drift	TT	945	1
1107	Steering gear bracket dust cap	1918-19	05	Drum	TT	5044	1

WHEELS

1109	Rear wheel complete, less tire	1918-19	18 00	Duel	TT	99	2
1110	Rear wheel complete, with tire	1918-19				7645	
1111	Rear hub	1918-19	4 50	Dumb	TT	40	2
1112	Rear hub flange	1918-19	60	Dusk	TT	149	2
1113	Rear hub brake drum	1918-19	2 00	Dutch	TT	3	2
1114	Rear hub bolt and nut	1918-19	10	Dwarf	TT	28-29	12
1116	Rear hub cap	1918-19	35	Dyke	TT	150	2
1117	Rear hub key	1918-19	10	Ear	TT	26	2
1118	Rear hub felt	1918-19	05	East	TT	162	2

FRAME

1119	Frame assembly	1918-19	35 00	Eat	TT	550	1
1120	Side member—right	1918-19	12 00	Ebb	TT	301	1
1121	Side member—left	1918-19	12 00	Fish	TT	302	1
1122	Front cross member	1918-19	1 50	Flirt	TT	303	1
1123	Rear cross member	1918-19	6 00	Flock	TT	304	1
1124	Front corner bracket—right	1918-19	20	Frost	TT	305	1
1125	Front corner bracket—left	1918-19	20	Froth	TT	306	1
1125B	Front end spacer—right	1918-19	15		TT	319	1
1125C	Front end spacer—left	1918-19	15		TT	318	1
1126	Rear cross member gusset plate	1918-19	25	Ghost	TT	307	2

MOTOR

1127	Crank case arm block	1918-19	05	Grape	TT	890	2
1128	Hood board to frame bolt and nut—long	1918-19	05	Guest	TT	4073-T1309	2

RUNNING BOARD

1129	Running board	1918-19	75	Gull	TT	5418	2
1130	Board bracket	1918-19	40	Heck	TT	2926	4
1131	Board bracket brace	1918-19	15	Hedge	TT	2927	2
1132	Board bracket rear brace	1918-19	30		TT	2929	1

TRANSMISSION CONTROL

1133	Speed lever	1918-19	20	Hoe	TT	862	1
1134	Controller shaft with speed lever	1918-19	75	Hod	TT	1557	1

TOOLS

322257	Rear wheel puller assembly	1918-19	1 25	Hock	TT		1
32711	Rear axle housing bolt L socket wrench	1918-19	50	Prosy	TT		
3389X	Jack		2 50	Hog	TT		

RADIATOR PARTS

1175	Radiator support stud and nut		06	Hunch	TT	1162-T1154	
1176	Radiator support and spring thimble—upper		02	Hump	TT	1115	
1177	Radiator support and spring thimble—lower		02	Hurst	TT	1114	

Insist upon genuine Ford parts

IMPORTANT

INSIST on getting **GENUINE** Ford Parts when your Ford car needs repairing. Don't allow "bogus" or imitation Parts to go in your car.

