

Ford
PRICE LIST
of Parts and Accessories
FOR OWNERS

USE GENUINE FORD PARTS

MANUFACTURED BY

Ford Motor Company

SOLD BY

AUTHORIZED FORD DEALER

Parts Price List Index

	Page
Ammeter.....	32
Axle (Front).....	7
Axle (Rear).....	4
Drive Shaft.....	6
Universal Joint.....	6
Battery Bracket and Parts.....	35
Battery (Ford).....	35
Body Parts.....	23
Body Brackets.....	23
Dash.....	24
Floor Boards.....	23
License Brackets.....	24
Carburetor.....	29
Ford Carburetor (Model "N. H.").....	29
Kingston Carburetor (Model "L-4").....	29
Carburetor Attachments.....	29
Coil (Ford Spark).....	31
Fenders.....	30
Fenders.....	30
Fender Bolts, Nuts and Brackets.....	31
Fender Irons.....	30
Frame.....	11
Gasoline Tank.....	11
Generator and Parts.....	35
Hood.....	28
Horn (Electric).....	37
Lamps (Electric Head).....	37
Lamps (Side and Tail).....	38
Magneto and Fly Wheel.....	17
Motor.....	12
Commutator.....	16
Crank Case and Cylinder Valve Cover.....	15
Crank Shaft and Cam Shaft.....	13
Cylinder.....	12
Piston and Connecting Rod.....	13
Valves, Push Rods, Exhaust and Inlet Manifold.....	14
Muffler.....	27
Radiator Fan.....	26
Radiator—Thermo Syphon.....	26
Running Board and Shields.....	31
Spark Plugs.....	35
Specialties (Ford).....	36
Springs.....	24
Spring (Front).....	24
Spring (Rear).....	25

Prices Subject to Change Without Notice


Parts Price List Index—Continued

	Page
Starter Drive.....	33
Starter Parts.....	34
Starting Crank.....	26
Starting Motor and Parts.....	35
Steering Gear.....	21
Steering Gear Brackets.....	23
Steering Gear Throttle and Spark Rods.....	22
Steering Gear Tubing and Post.....	22
Steering Wheel and Gear Case.....	21
Switch.....	32
Tops.....	39
Roadster—1915-22.....	40
Roadster—1922-25.....	40
Roadster—1926.....	40
Touring—1915-22.....	39
Touring—1922-25.....	39
Touring—1926.....	39
Tools (Repair).....	36
Tools (Repair)—Truck.....	36
Transmission.....	17
Transmission Control.....	19
Transmission Cover.....	19
Clutch Release.....	19
Hand Brake.....	21
Pedals and Controller Shaft.....	20
Transmission Bands.....	20
Truck Parts.....	41
Axle (Rear).....	41
Brake Parts.....	43
Drive Shaft.....	42
Frame.....	46
Radius Rod.....	44
Spring (Front).....	44
Spring (Rear).....	44
Transmission Control.....	46
Wheels.....	45
Worm.....	42
Wheels.....	7
Clincher.....	7
Demountable.....	7
Demountable—Balloons.....	8
Hubs and Parts.....	9
Rim and Rim Carrier.....	10
Windshields.....	38
Touring and Roadster—1915-22.....	38
Touring and Roadster—1922-25.....	39
Touring and Roadster—1926.....	39
Wiring.....	33

Prices Subject to Change Without Notice

PRICE LIST OF PARTS FORD MODEL T 1909-1926 EFFECTIVE MAY 1, 1926

Part No.	Name of Part	Year	Each
----------	--------------	------	------



REAR AXLE

2500	Rear axle assembly	1909-25	\$55 00
2500B	Rear axle assembly	1926	55 00
2501	Axle housing—right	1915-25	9 00
2501B	Rear axle housing assembly—R.	1926	9 00
2502	Axle housing—left	1915-25	9 00
2502B	Rear axle housing assembly—L.	1926	9 00
2503E	Axle housing bolt	1913-26	03
2503F	Axle housing bolt nut	1909-26	02
2504	Rear axle case gasket	1919-26	03
2505	Axle shaft	1912-26	1 50
2506	Axle shaft washer	1909-26	02
2507	Axle shaft nut	1909-26	05
2508	Axle shaft R. B.	1909-26	65
2509	Axle shaft R. B. sleeve—R.	1909-26	15
2509B	Axle shaft R. B. sleeve—L.	1909-26	15
2510 1/2	Axle housing cap	1919-26	05
2510A	Axle outer roller bearing steel washer	1909-26	02
2510B	Axle outer roller bearing felt washer	1909-26	05
2511	Rear axle oil retainer	1926	15
2512C	Diff. case—left	1914-26	1 50
2513C	Diff. case—right	1914-26	90
2514B	Diff. case stud	1915-21	05
2514C	Diff. case bolt	1922-26	05
2515	Diff. case stud nut	1909-26	02

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

REAR AXLE—Continued

2518	Diff. drive gear	1909-26	\$2 50
2519	Diff. drive gear screw	1909-26	03
2519A	Diff. gear lock ring	1909-26	02
2520B	Diff. gear	1909-26	1 00
2521B	Diff. gear key	1911-26	05
2524C	Diff. pinion	1915-26	35
2524B	Diff. spider	1909-26	75
2528	Diff. thrust washer	1909-26	20
2529	Diff. thrust plate	1909-26	15
2531B	Diff. thrust plate pin	1917-26	02
2532	Diff. housing oil plug	1909-26	05
2545	Rear axle grease cup	1909-26	10
2547	Rear radius rod—right	1909-25	1 25
2547B	Rear radius rod—left	1909-25	1 25
2547C	Rear radius rod Assy.—R.	1926	1 25
2547D	Rear radius rod Assy.—L.	1926	1 25
2548	Radius rod nut	1909-26	05
2549	Radius rod lock nut	1909-26	05
2550	Radius rod lock washer	1909-26	02
2551	Radius rod bolt	1909-26	05
2551B	Radius rod bolt nut	1909-26	03
2557	Hub cam shaft—right	1909-25	10
2557B	Hub brake cam—R.	1926	50
2558	Hub cam shaft—left	1909-25	10
2558B	Hub brake cam—L.	1926	50
2559	Hub brake cam bushing	1909-26	05
2559B	Hub brake cam bushing	1926	10
2560	Rear axle brake housing cover Assy.—R.	1926	40
2561	Rear axle brake housing cover Assy.—L.	1926	40
2562	Cam shaft lever	1909-25	10
2562B	Hub brake cam lever	1926	10
2563	Cam shaft lever pin	1909-25	01
2563B	Hub brake cam lever pin (Order 3405)	1926	
2564	Lever clevis pin	1909-26	02
2566	Hub brake shoe	1909-25	35
2566B	Hub brake band Assy.	1926	1 50
2566D	Hub brake band lining	1926	40
2567	Brake shoe support bolt	1909-25	05
2568	Brake shoe support nut (Order 2551B)	1909-25	
2570B	Brake shoe coil spring	1913-25	02
2570C	Hub brake band spring	1926	10



Insist upon genuine Ford parts


Part No.	Name of Part	Year	Each
----------	--------------	------	------

REAR AXLE—Continued

UNIVERSAL JOINT			
2571	Universal joint assembly	1909-26	\$1 50
2577B	Univ. joint housing	1914-26	1 00
2578	Joint housing plug	1909-26	05
2579	Ball joint grease cap	1909-26	15
2580	Ball cap gasket	1909-26	05

DRIVE SHAFT

2581	Drive shaft housing front bushing	1909-26	30
2582	D. S. tubing	1911-26	7 50
2583B	D. S. bearing housing	1920-26	1 40
2584B	D. S. R. B. cap screw	1912-26	05
2584D	D. S. R. B. cap screw lock washer	1912-26	doz. 05
2587	D. S. roller bearing	1911-26	60



2591	D. S. ball thrust collar	1911-26	20
2591B	D. S. thrust ball and retainer assy.	1920-26	20
2595B	D. S. only	1911-26	3 00
2596	D. S. sleeve	1911-26	50
2597B	D. S. pinion	1911-26	1 25
2597C	D. S. pinion	1911-26	1 25
2598	D. S. castle nut	1911-26	08
2598B	D. S. pinion key	1911-26	05



†When ordered to replace malleable type housing also order 2-2591 and 1-2591B

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

FRONT AXLE

2691	Front axle only	1909-26	\$9 00
2694B	Spindle body—right	1911-25	1 50
2694C	Spindle body—R.	1926	1 50
2695B	Spindle body—left	1911-25	1 50
2695C	Spindle body—L.	1926	1 50
2696C	Spindle arm—right	1919-26	45
2696D	Spindle arm—left	1919-26	45
2697	Spindle arm nut (Order 2548)	1911-26	
2704	Stationary cone	1909-25	15
2705	Adj. cone—right thread	1909-25	15
2706	Adj. cone—left thread	1909-25	15
2707	Spindle nut—right thread	1909-26	05
2708	Spindle nut—left thread	1909-26	05
2709	Spindle washer	1909-26	02
2710	Spindle bolt with oiler	1910-26	20
2711	Spindle bolt nut (Order 2551B)	1909-26	
2713	Spindle body bushing (pair)	1909-26	20
2714	Spindle arm bushing	1909-26	05
2715D	Spindle oiler (Order 3176C)	1919-26	1 75
2717	Spindle con. rod	1909-26	15
2718	Spindle con. rod bolt with oiler	1909-26	02
2719	Spindle con. rod bolt nut	1909-26	20
2721B	Spindle con. rod yoke ball	1919-26	40
2721C	Spindle con. rod yoke	1919-26	80
2725C	Steering gear con. rod	1926	15
2728	Ball socket cap	1909-26	
2729B	Ball socket bolt and nut (Order 3362 and 2515)	1909-26	1 50
2733B	Front radius rod	1919-26	15
2736	Front radius rod ball cap	1909-26	30
2737	Front radius rod ball socket	1911-24	30
2737B	Front radius rod ball socket	1924-26	30
2741	Radius rod ball cap stud	1911-26	05
2741B	Radius rod ball cap stud nut (Order 2515)	1911-26	
2742	Radius rod ball cap spring	1911-26	03

WHEELS

WHEELS (Climcher)

2800	Front wheel—climcher	1909-25	6 00
2800D	Front wheel—climcher—less hub	1909-26	4 00
2800A1	Front wheel—climcher—30 x 3 1/2	1926	6 00
2814C	Rear wheel—climcher	1912-25	6 00
2814C2	Rear wheel—climcher—11" brake drum	1926	6 50
2814D	Rear wheel—climcher—less hub	1909-26	4 00

WHEELS (Demountable)

2800B	Front wheel—dem. less rim and bearings	1919-24	5 50
2800C	Front wheel—dem. less rim and bearings	1919-24	5 50
2800G	Front wheel—dem. less rim and bearings	1919-26	5 50

*Substitute 2733B with spring perches for 2733.

†Use with 2845 rim ‡Use with 2845C or 2845D rim.

§Use with attached clamp rim.

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

WHEELS—Continued

WHEELS (Demountable)—Continued			
†2800E...	Front and rear wheel—dem. less rim and hub	1919-24	\$3 50
†2800F...	Front and rear wheel—dem. less rim and hub	1922-23	3 50
†2800H...	Front and rear wheel—dem. less rim and hub	1924-25	3 50
†2801...	Front wheel complete R. or L.—dem.	1919-24	7 25
†2801B...	Front wheel complete R. or L.—dem.	1919-25	7 25
††2801C1...	Front wheel complete R. or L.—dem.	1922	7 25
††2801C2...	Front wheel complete—dem.	1923	7 25
†2814E...	Rear wheel complete—dem.	1919-24	7 25
†2814F...	Rear wheel complete—dem.	1919-25	7 25
†2814F2...	Rear wheel complete—dem. 30 x 3½—11" brake drum	1926	7 75
†2814G...	Rear wheel—dem. less rim	1919-24	5 50
†2814H...	Rear wheel—dem. less rim	1922-23	5 50
†2814J1...	Rear wheel complete—dem.	1922	7 25
†2814J2...	Rear wheel complete—dem.	1923	7 25
†2814K...	Rear wheel—dem.—less rim	1924-26	5 50
†2814K2...	Rear wheel—dem.—less rim 30 x 3½—11" brake drum	1926	6 00

WHEELS (Balloon Demountable)

2800I...	Frt. wheel, balloon—with hub less rim—black	1926	5 50
2800J...	Frt. wheel, balloon—with hub less rim—natural	1926	5 50
2800K...	Frt. and rear wheel—balloon—less rim and hub—black	1926	3 50
2800L...	Frt. and rear wheel—balloon—less rim and hub—natural	1926	3 50
2801D...	Front wheel complete—balloon—black	1926	7 25
2801E...	Front wheel complete—balloon—natural	1926	7 25
2814L...	Rear wheel complete—balloon—black	1925	7 00
2814L2...	Rear wheel complete—balloon—black—11" brake drum	1926	7 50
2814M...	Rear wheel complete—balloon—natural	1925	7 00
2814M2...	Rear wheel complete—balloon—natural—11" brake drum	1926	7 50
2814N...	Rear wheel—balloon—with hub less rim—black	1925	5 50
2814N2...	Rear wheel—balloon—with hub less rim—black—11" brake drum	1926	6 00

†Use with 2845 rim.

†Use with 2845C or 2845D rim.

††With 2845G rim.

††With 2845D rim.


†Use with attached clamp rim

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

WHEELS—Continued

WHEELS (Balloon Demountable)—Continued			
2814P...	Rear wheel—balloon—with hub less rim—natural	1925	\$5 50
2814P2...	Rear wheel—balloon—with hub less rim—natural 11" brake drum	1926	6 00




HUBS AND PARTS

2803...	Front hub assy.	1909-25	1 80
2803B...	Front hub with R B cups	1909-26	1 80
2804...	Outer race	1909-25	10
2805...	Inner race	1909-25	15
2806...	Outer ball retainer	1909-25	02
2807...	Inner ball retainer	1909-25	03
2808...	Dust ring	1909-26	03
2809...	Front and rear hub felt washer	1909-26	05
2810...	Large balls	1909-25	04
2811...	Small balls	1909-25	03
2815C...	REAR HUB	1912-26	1 25
2816B...	Rear hub key	1912-26	03
2818...	Rear hub brake drum	1909-25	40
2818B...	Hub brake drum	1926	1 00
2819...	Hub cap	1909-26	10
2825...	Rear hub bolt	1911-26	03
2825B...	Hub bolt nut	1911-26	02
2826...	Front hub bolt	1911-26	03
2827...	Hub flange	1911-26	20
2833...	Front hub bearing cup—inner	1919-26	50
2834...	Inside cone and roller assy.	1919-26	1 10
2836...	Front hub bearing cup—outer	1919-26	40
2837...	Outside cone and roller assy.—right thread	1919-26	75
2838...	Outside cone and roller assy.—left thread	1919-26	75
2841...	Front hub dust cap assy.	1919-26	10

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------



WHEELS—Continued

RIM AND RIM CARRIER

2845	Demountable rim only	1919-24	\$1 50
2845B	Demountable rim only	1919-26	1 50
2845C	Demountable rim only	1922	1 50
2845D	Demountable rim only	1923	1 50
2845E	Demountable rim only—balloon	1926	1 50
2846B	Demountable rim clamp	1919-24	15
2846C	Dem. rim clamp and nut assy.	1922	10
*2846D	Dem. rim clamp	1923	10
2847	Demountable rim bolt	1919-26	05
*2848	Dem. rim nut	1919-26	05
†2848B	Dem. rim nut	1919-25	05
2849	Spare rim carrier	1919-25	2 25
2849B	Spare rim carrier clamp bolt	1921-25	02
2849C	Spare rim carrier clamp support and bolt assy.	1921-24	15
2849G	Spare rim carrier clamp support and bolt assy.	1924-25	15
2849D	Spare rim carrier clamp	1921-25	10
2849E	Spare rim carrier—balloon	1925	2 25
2849F	Spare rim carrier clamp	1925-26	10
2870	Spare rim carrier bracket—R.	1919-22	50
2870B	Spare rim carrier bracket—R.	1922-25	50
†2870C	Spare rim carrier bracket—R.	1925	50
2871	Spare rim carrier bracket—L.	1919-22	50
2871B	Spare rim carrier bracket—L.	1922-25	50
†2871C	Spare rim carrier bracket—L.	1925	50
2872	Spare rim bracket and bolt assy.—Road.—Cp.	1926	1 50
2872B	Spare rim bracket and bolt assy.—T. C.—Tudor—Fordor	1926	2 75
2873	Spare rim carrier only—balloon	1926	1 25
2874	Spare rim carrier only—30" x 3 1/2"	1926	1 25
2875	Spare rim carrier bolt	1926	10
2876	Spare rim carrier bolt nut	1926	05

FRAME

2850	Frame assembly	1909-25	13	00
2850B	Frame assembly	1926	13	00
2851B	Side member—right	1914-25	4	00
2851C	Side member—R	1926	4	00
2852B	Side member—left	1914-25	4	00
2852C	Side member—L	1926	4	00
2853	Front cross member	1909-26	9	00
2854B	Rear cross member	1914-25	1	20

*Use with 2845B, 2845D and 2845E rim. †Use with 2845C rim.

‡Use with 2845 rim. §Use with 2845 rim.


††For balloon rim carrier. ***Use with 2845D rim.

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

FRAME--Continued

2854C...	Rear cross member.....	1926	\$2 00
2863....	Body bracket.....	1909-26	10



GASOLINE TANK

2900B...	Gas tank—Sedan	1916-25	6 00
2900C...	Gasoline tank	1909-25	4 00
2900D...	Gas tank—Road.—T. C.—Cp.— Tudor	1926	6 00
2901B...	Filling plug	1909-26	15
2901B...	Sediment bulb	1909-26	90
2902C...	Sediment bulb assy.—Road.—T. C.—Cp.—Tudor	1926	1 00
2908...	Peacock (Order 3079)	1909-25	
*2908B...	Sediment bulb drain plug assy.— Road.—T. C.—Cp.—Tudor (Order 6216)	1926	
2909...	Feed pipe—39 1/4"	1909-26	25
2909B...	Feed pipe—51"	1916-23	30
2909C...	Feed pipe—66 1/2"	1918-19	35
2909D...	Feed pipe—56 1/2"	1919-25	35
2909E...	Feed pipe—49 1/4"	1923-25	30
2909F...	Gas feed pipe—Road.—T. C.—Cp.— Tudor	1926	00
2910...	Feed pipe pack nut	1909-26	
2913...	Feed pipe gasket	1909-26	00
2914B...	Gas tank support—R	1920-26	20
2915B...	Gas tank support—L	1920-26	20
2916...	Feed pipe clamp	1921-26	00
2917...	Gas tank pad—upper—Road.—T. C.—Cp.—Tudor	1926	00
2918...	Gas tank pad front—Road.—T. C. —Cp.—Tudor	1926	20


*Same as S-645

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

GASOLINE TANK—Continued

2919	Gas tank support pad—Road.—T.		
	C.—Cp.—Tudor	1926	\$0 10
2921	Gas tank overflow pipe—Road.—		
	T. C.—Cp.—Tudor	1926	25
2922	Gas tank support and pad assy.	1926	50



CYLINDER MOTOR

2990B	Motor assembly—less starter	1909-26	110 00
2991B	Cylinder assembly—std.	1909-26	65 00
3000C	Cylinder	1909-26	25 00
3001	Cylinder head	1909-26	6 00
3002	Cylinder head gasket	1909-26	25
3003	Cylinder head cap screw	1909-17	05
3003B	Cylinder head cap screw	1918-26	05
3004B	Cylinder head outlet con.	1917-25	35
3004E	Cylinder head outlet conn.	1926	75
3005	Cylinder head outlet conn. gskt.	1909-26	03
3006	Cylinder head outlet hose	1909-26	15
3007	Cylinder head outlet hose clip	1909-26	05
3008	Cylinder head outlet conn. screw	1909-26	05
3009C	Cylinder front cover	1919-26	1 00
3009D	Cylinder front cover	1926	1 00
3010	Cylinder cover bolt and nut (Order 4808 and 2515)	1909-26	
3011	Cylinder cover cap screw	1909-26	03
3012	Cylinder cover felt	1909-26	05
3013B	Cylinder cover liner	1919-26	02
3014	Cylinder cover and crank case bolt and nut (Order 3362 and 2515)	1909-26	


Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

MOTOR—Continued

CYLINDER—Continued

3015	Cylinder water inlet conn.	1909-26	\$0 30
3016	Cylinder inlet conn. screw	1909-26	03
3017	Time gear cover	1919-26	90
3017C	Time gear cover gasket	1919-26	01
3017D	Time gear cover plate	1919-26	05
3017E	Time gear cover to C. G. screw	1919-26	03
3018	Cylinder water inlet gasket	1909-26	03
3019B	Cylinder water jacket plug	1914-26	02



PISTON AND CONNECTING ROD

3021R	Piston and pin (2 lbs.)	1909-26	1 30
3021S	Piston and pin—.0025" O. S. (2 lbs.)	1909-26	1 30
3021T	Piston and pin—.005" O. S. (2 lbs.)	1909-26	1 30
3021U	Piston and pin—.03125" O. S. (2 lbs.)	1909-26	1 30
3021V	Piston and pin—.033" O. S. (2 lbs.)	1909-26	1 30
3021W	Piston and pin—.010" O. S. (2 lbs.)	1909-26	1 30
3022	Piston pin	1909-26	30
*3022 1/2	Piston pin bushing (pair)	1909-23	20
†3022C	Piston pin bushing (pair)	1923-26	20
3023	Piston ring	1909-26	15
3023B	Piston ring .031" O. S.	1909-26	15
3023C	Piston ring .010" O. S.	1909-26	15
3023D	Piston ring .038" O. S.	1909-26	15
†3024	CONNECTING ROD	1909-26	1 20
3025	Connecting rod cap bolt	1909-26	05
3026	Connecting rod cap bolt nut	1909-26	03
3029	Connecting rod clamp screw	1909-26	03


CRANK SHAFT AND CAM SHAFT

3030	CRANK SHAFT	1909-26	10 00
3031	C. S. rear bearing cap	1909-26	50
3032	C. S. front bearing cap	1909-26	40
3033	C. S. center bearing cap	1909-26	40
3034	C. S. bearing bolt—center and front	1909-26	10
3035	C. S. bearing bolt nut (Order 2551B)	1909-26	
3036	C. S. rear bearing bolt	1909-26	10
3038	C. S. bearing liner—center and front	1909-26	01
3039	C. S. rear bearing liner	1909-26	01
3040B	C. S. starting pin	1920-26	03

††Connecting rods of present design requiring new bearings will be exchanged by dealers at 60c each. *O. D. .934". ††O. D. .872".

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

**MOTOR—Continued****CRANK SHAFT AND CAM SHAFT—Continued**

3041...	CAM SHAFT.....	1909-26	\$3 00
3042...	Cam shaft front bearing.....	1909-24	40
3042B...	Cam shaft front bearing.....	1924-26	40
3043...	Cam shaft center bearing.....	1909-26	40
3044...	Cam shaft rear bearing.....	1909-26	15
3045...	Cam shaft bearing ring.....	1909-26	03
3046...	Camshaft bearing set screw.....	1909-26	05
3047B...	Time gear—large.....	1909-26	90
3048B...	Time gear—small.....	1909-26	60
3049...	Cam shaft gear dowel pin.....	1909-26	03
3050B...	Cam shaft gear lock nut.....	1909-26	15
3051...	Small time gear key.....	1909-26	03

**VALVES, PUSH RODS, EXHAUST AND INLET MANIFOLDS.**

3052...	Valve.....	1909-26	15
3052B...	Valve— $\frac{1}{8}$ " O. S. stem.....	1909-26	15
3053 $\frac{1}{2}$...	Valve bushing.....	1909-26	25
3054...	Valve spring.....	1909-26	05
3056...	Valve spring seat.....	1909-26	05
3057...	Valve spring set pin.....	1909-26	05
3058...	Push rod.....	1909-26	15
3058B...	Push rod— $\frac{1}{8}$ " O. S. stem.....	1909-26	15
3059 $\frac{1}{2}$...	Push rod bushing.....	1909-26	25
3060B...	Exhaust manifold.....	1913-26	1 25
3061...	Exhaust pipe pack nut.....	1909-26	20

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

**MOTOR—Continued****VALVES, PUSH RODS, EXHAUST AND INLET MANIFOLDS—Continued**

3062...	Inlet pipe.....	1909-26	\$1 00
3063...	Inlet and exhaust pipe gasket.....	1909-26	02
3064...	Inlet and exhaust pipe gland.....	1909-26	01
3065...	Inlet and exhaust pipe clamp.....	1909-26	10
3066B...	Inlet and exhaust clamp stud nut.....	1909-26	03
*3066C...	Inlet and exhaust clamp stud— 2 $\frac{1}{2}$ ".....	1924-26	05
3068...	Breather pipe.....	1909-26	10

CRANK CASE AND CYLINDER VALVE COVER

3069C...	C. C. front end support.....	1917-24	75
3069D...	C. C. front end support.....	1924-26	75
3070B...	C. C. and cyl. gasket—L.....	1909-26	03
3071B...	C. C. and cyl. gasket—R.....	1909-26	03
3072...	C. C. and cyl. cover cap screw.....	1909-26	03
3073...	C. C. arm bolt—side.....	1909-26	05
3074...	C. C. arm bolt—top.....	1909-26	05

*When used to replace stud 3 $\frac{1}{8}$ " long also use new style 3065 clamp, reversing clamp.

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

MOTOR—Continued**CRANK CASE AND CYLINDER VALVE COVER—Contd.**

3074B...	C. C. arm bolt nut (Order 2515).....	1909-26	
3074C...	C. C. arm bolt—top (Truck).....	1918-26	\$0 03
†3075C...	C. C. front bearing and spring clip assy.....	1921-26	90
3076C...	C. C. front bearing and spring clip nut (Order 2548).....	1921-26	
†3076B2...	C. C. front bearing and spring clip.....	1921-26	70
3077...	C. C. front bearing cap.....	1909-26	15
3078...	C. C. front bearing screw.....	1909-21	05
3078B...	C. C. front bearing screw (Order 3008).....	1921-26	
3078C...	C. C. front bearing lock washer.....	1921-26	01
3079...	C. C. oil cock.....	1909-26	15
3080...	C. C. drain cup plug (Order 2532).....	1909-26	
3080B...	C. C. drain cup plug gasket.....	1909-26	02
3081...	C. C. oil tube.....	1909-26	20
3083...	C. C. arm block.....	1909-26	05
3084...	Engine pan—right.....	1909-26	30
3085...	Engine pan—left.....	1909-26	30
3088B...	Engine pan and hood board bolt.....	1909-26	03
3088C...	Engine pan and hood board bolt.....	1909-26	03
3088D...	Engine pan and hood board bolt— Truck.....	1918-26	03
3088E...	Engine pan and hood board bolt nut.....	1909-26	01
3100...	CRANK CASE.....	1912-25	11 00
3101...	Crank case lower cover.....	1912-24	35
3101B...	Crank case lower cover reinforcement.....	1912-24	25
3101C...	C. C. lower cover.....	1924-26	35
3101D...	C. C. lower cover reinforcement.....	1924-26	25
3102B...	C. C. lower cover gasket.....	1912-24	10
3102C...	C. C. lower cover gasket.....	1924-26	10
3103...	C. C. lower cover screw.....	1912-26	02



3110B...	Cylinder valve cover.....	1921-26	20
3111C...	Cylinder valve cover gasket.....	1921-26	05
3112...	Cylinder valve cover screw.....	1912-26	30
3114...	C. C. arm with rivets.....	1909-26	03

COMMUTATOR

3162B...	Com. case support bolt.....	1919-26	05
----------	-----------------------------	---------	----

†Replaces 3075B.


††Replaces 3076B. When ordered to replace 1909-20 C. C. front frame bearing also order 2-3008, 2-3076C, 2-3078C, 1-3664, 1-3810, 2-753 cotter.

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

MOTOR—Continued**COMMUTATOR—Continued**

3163...	Com. case spring.....	1912-26	\$0 05
3165...	Com. brush only.....	1912-26	20
3210...	Com. contact point nut.....	1912-26	01
3220...	Com. lock nut.....	1909-26	03
3221...	Com. case with fibre.....	1912-26	60

**MAGNETO AND FLY WHEEL**

3250D...	Magneto coil assembly.....	1915-26	6 00
3252...	Magneto spool support screw (Or- der 3371).....	1909-26	
3254...	Magnet bolt.....	1909-26	03
3255...	Magnet bolt washer.....	1911-26	01
3257...	Magnet support.....	1909-26	05
3260...	Magneto contact assy.....	1909-25	20
*3260B...	Magneto contact assy.....	1926	30
3261B...	Magneto contact nut.....	1909-26	01
3268...	Fly wheel ring gear.....	1919-26	90
3269H...	Fly wheel with ring gear and magnets assembled.....	1919-26	15 00
3270...	Fly wheel cap screw.....	1909-26	10
3276B...	Magnets (16).....	1915-26	set 4 00
3277...	Magnet clamp.....	1911-26	03
3278...	Magnet clamp screw.....	1911-26	02


TRANSMISSION

3300B...	Transmission assy.....	1919-25	30 00
----------	------------------------	---------	-------

**Same as S-303.

Insist upon genuine Ford parts

Part No. Name of Part Year Each




TRANSMISSION—Continued

3300C.	Transmission assy.	1926	\$30 00
3301	Trans. reverse plate assy.	1909-26	2 40
3304	Trans. reverse gear bushing	1909-26	40
3305	Trans. reverse and S. S. rivet	1909-26 doz.	05
3306	Trans. slow speed plate assy.	1909-26	2 30
3309	Trans. slow speed gear bushing	1909-26	30
3311	Trans. brake drum assy.	1909-25	2 60
3311B.	Trans. brake drum assy.	1926	3 00
3312	Trans. brake drum lug shoe	1926	05
3313	Trans. triple gear assy.	1909-26	1 40
3314	Trans. triple gear flanged bushing	1911-26	20
3317	Trans. driven gear	1909-26	70
3318	Trans. driven gear key	1909-26	03
3320C.	Trans. driven gear sleeve bushing	1909-26	20
3320D.	Driven gear sleeve washer	1909-26	05
3321	Trans. driving plate assy.	1909-25	3 25
3321B.	Trans. driving plate assy.	1926	3 25
3323	Trans. driving plate screw (Order 3371)	1909-25	
3323B.	Trans. driving plate screw	1926	05
*3327B.	Trans. driving plate bushing	1909-26	15
3328	Trans. clutch disc—small	1909-26	10
3329	Trans. clutch disc—large	1909-26	10
3331	Trans. gear shaft	1909-26	1 40
3332	Trans. clutch disc drum	1909-26	1 25
3333	Trans. clutch disc drum key	1909-26	05
3334	Trans. clutch disc drum set screw	1909-26	10
3336	Trans. clutch push ring	1909-26	35
3337B.	Trans. clutch finger and screw	1909-25	20
3337D.	Clutch finger and screw	1926	20
3338	Trans. clutch finger pin	1909-25	01
3340	Trans. clutch spring	1909-26	25
3341	Trans. clutch spring support	1909-26	10
3342	Trans. clutch spring thrust ring	1909-26	
	pin	1909-26	03
3344	Trans. clutch shift	1909-26	50

*When using short bushing in making repairs remove driving plate key.


Insist upon genuine Ford parts

Part No. Name of Part Year Each



TRANSMISSION COVER

3362	Trans. cover bolt	1909-26	\$0 03
3362B.	Trans. cover bolt nut (Order 2515)	1909-26	
3363	Trans. cover gasket (front)	1909-26	05
3367	Trans. cover door screw	1909-26	02
3368	Universal ball cap (rear)	1909-26	30
3369	Universal ball cap (front)	1909-26	80
3371	Universal ball cap screw	1909-26	05
3372	Universal ball cap bolt and nut (Order 3362 and 2515)	1909-26	
3375	Trans. cover screw (Order 3072)	1909-26	
3376B.	TRANS. COVER	1919-25	7 00
3376C.	Trans. cover	1926	7 00
3377B.	Trans. cover gasket	1909-26	pr. 10
3378	Trans. cover door	1911-26	15
3379B.	Trans. cover door gasket	1911-26	05
3380	Starter drive cover	1919-26	15
3381	Starter drive cover gasket	1919-26	03
3382	Trans. cover rear plate	1919-26	05
3383	Trans. cover front plate	1919-26	05
3384	Trans. cover to cylinder screw	1926	05



TRANSMISSION CONTROL

3400	Trans. clutch release ring	1909-26	20
3402D.	Clutch lever and shaft	1913-26	30
3403	Clutch lever screw (Order 3973)	1909-26	

†When ordered to replace cover on cars below 2044100 also order 3402D clutch lever and shaft.

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

TRANSMISSION CONTROL—Continued**CLUTCH RELEASE—Continued**

3403B...	Clutch lever screw nut (Order 3066B)	1909-26	\$0 01 15
3405...	Clutch lever pin	1909-26	
3406B...	Clutch release fork—R. or L.	1913-26	
3406C...	Clutch release fork pin (Order 3405)	1913-26	
3411...	Clutch lever clevis pin (Order 2564)	1909-26	

TRANSMISSION BANDS

3413B...	Trans. band assy. (detach)	1925	75
3413C...	Trans. brake band assy.	1926	1 00
3415...	Trans. band washer	1909-26	03
3416...	Trans. band lining	1909-25	25
3416B...	Trans. band lining—set of 3 including rivets—in carton	1909-25	90
3416C...	Trans. brake band lining	1926	35
3416D...	Trans. band lining—set of 3 including rivets—in carton	1926	1 00
3419...	Trans. band adj. screw	1909-25	15
*3419B...	Trans. band adj. screw	1926	15
3420...	Trans. band adj. screw nut	1909-26	05
3423B...	Trans. band brass rivet	1909-26 doz.	05
3425...	Trans. band spring	1909-26	03
3426...	Trans. band adj. nut	1909-26	05

**PEDALS AND CONTROLLER SHAFT**

3427...	Slow speed shaft	1909-25	15
*3427B...	Slow speed shaft	1926	15
3428...	Slow speed notch	1909-26	25
3429...	Slow speed notch pin	1909-26	01
3432...	Speed lever	1909-26	10
3434...	Reverse pedal	1909-25	50
3435...	Brake and reverse pedal shaft	1909-26	15
3436...	Brake and reverse pedal support	1909-26	15
3437...	Brake and reverse support bolt	1909-25	05
3437B...	Brake and reverse support bolt nut (Order 2515)	1909-26	
3437C...	Brake and reverse pedal support bolt	1926	05
3439...	Brake pedal	1909-25	50
3439B...	Brake pedal	1926	65
3440...	Clutch pedal	1909-25	50

*Used with detachable ear band.

Part No.	Name of Part	Year	Each
----------	--------------	------	------

**TRANSMISSION CONTROL—Continued****PEDALS AND CONTROLLER SHAFT—Continued**

3440B...	Clutch pedal	1926	\$0 65
3441...	Pedal pin (Order 3405)	1909-26	
3442...	Clutch pedal support	1909-26	
3443...	Clutch pedal support bolt	1909-26	
3443B...	Clutch pedal support bolt nut (Order 2515)	1909-26	
3445...	Slow speed connection	1909-26	05
3446...	Slow speed con. lock nut (Order 2503F)	1909-26	
3447...	Slow speed con. clevis	1909-26	10
3448...	Controller quadrant	1909-26	20
3449...	Con. shaft with speed lever	1909-26	60
3450...	Controller shaft bracket	1909-26	15
3452...	Controller shaft bracket bolt	1909-26	03
3452B...	Controller shaft bracket bolt nut	1909-26	02

HAND BRAKE


3455...	Hand brake lever	1909-25	1 00
3456B...	Hand brake lever pin (Order 2574)	1909-26	
3458...	Hand brake lever pawl	1909-26	05
3459...	Hand brake lever pawl pin	1909-26	01
3460...	Hand brake lever pawl rod	1909-26	10
3462...	Hand brake lever pawl lift assembly	1909-26	10
3463...	Hand brake lever pawl lift spring	1909-26	02
3465...	Hub brake lever	1909-26	15
3466...	Hub brake lever pin (Order 3405)	1909-26	
3467...	Hub brake lever clevis (Order 3447)	1909-26	
3468...	Hub brake pull rod—R.	1909-25	30
3468C...	Brake rod assembly—R.	1926	30
3469...	Hub brake pull rod—L.	1909-25	30
3469C...	Brake rod assembly—L.	1926	30
3470...	Brake rod support—R.	1909-26	10
3471...	Brake rod support—L.	1909-26	10
3472...	Brake rod support bolt	1909-26	01
3472B...	Brake rod support bolt nut (Order 3088E)	1909-26	

STEERING GEAR**STEERING WHEEL AND GEAR CASE**

3500D...	Steering gear assembly (5 to 1)	1926	10 00
3502...	Steering gear rim screw	1909-26	01
3503F...	Steering gear spider and rim (17")	1926	2 25
3504...	Steering gear cover	1909-26	30
3505...	Steering gear cover screw	1909-26	01
3507...	Steering gear internal gear case and bushing	1909-26	1 25
3509...	Steering gear quadrant	1909-26	15
3511...	Steering gear wheel nut	1909-26	10


Insist upon genuine Ford parts**Insist upon genuine Ford parts**

Part No. Name of Part Year Each



STEERING GEAR—Continued

STEERING GEAR TUBING AND POST			
3512C...	Steering gear tubing assy.	1912-26	\$4 00
3513C...	Steering tubing flange screw	1913-26	03
3514...	Steering tubing flange screw nut	1913-26	02
3516D...	Steering gear post	1921-25	1 75
3516E...	Steering gear post (5 to 1)	1926	1 75
3517...	Steering gear pinion	1909-25	15
3517B...	Steering gear pinion (5 to 1)	1926	15
3519...	Steering gear drive pinion	1909-25	30
3519B...	Steering gear drive pinion assy.	(5 to 1) 1926	45
3520...	Steering gear drive pinion key	1909-26	03
3523...	Steering gear post castle nut	(Order 2551B) 1909-26	



STEERING GEAR THROTTLE AND SPARK RODS			
3524E...	Throttle rod	1912-26	30
3525E...	Spark rod	1912-26	30
3527...	Spark and throttle rod spring	1909-26	02
3528...	Spark and throttle rod collar	1909-26	02
3529...	Spark and throttle rod pin	1909-26	01

Insist upon genuine Ford parts

Part No. Name of Part Year Each



STEERING GEAR—Continued

STEERING GEAR THROTTLE AND SPARK RODS—Contd.			
3530...	Spark rod lever	1909-26	\$0 10
3531...	Throttle rod lever	1909-26	10
3532...	Spark and throttle rod guide	1909-26	05
3534B...	Commutator pull rod	1912-25	10
3534C...	Commutator pull rod	1926	10
3535...	Carburetor pull rod	1909-25	10
3535B...	Carb. pull rod—Road.—T. C.—Cp.	—Tudor 1926	10
3535C...	Carb. pull rod—Fordor—Chassis	1926	10

STEERING GEAR BRACKET

3539B...	Steering bracket with bushing	1911-25	75
3539C...	Steering bracket with bushing—truck	1918-26	75
3539D...	Steering gear bracket assy.—Road.—T. C.—Cp.—Tudor	1926	75
3539E...	Steering gear bracket assy.—Fordor—Chassis	1926	75
3544...	Steering bracket felt washer	1909-26	02
3545...	Steering bracket bushing	1909-21	20
3545B...	Steering bracket bushing	1921-26	10
3546...	Steering bracket block	1909-25	10
3546C...	Steering gear bracket block	1926	10
3547...	Steering gear ball arm	1909-26	40
3548...	Steering gear ball arm key	1909-26	03

BODY PARTS


BODY BRACKETS			
3601B...	Body bracket on body	1910-26	10
3601C...	Body bracket—front—R.	1921-26	20
3601D...	Body bracket—front—L.	1921-26	20
3601E...	Body bracket—rear	1913-26	05
3601F...	Body bracket—rear—R.	1921-26	20
3601G...	Body bracket—rear—L.	1921-26	20
3602E...	Body bracket con. bolt	1916-26	03
3602F...	Body bracket con. bolt nut (Order 2719)	1916-26	

FLOOR BOARDS

3624E...	Front floor rubber mat	1915-24	90
3624F...	Front floor rubber mat	1924-25	90
3624G...	Floor board rubber mat and weather-strip assy.	1926	1 50
3626C...	Floor board with plate (first)	1915-25	50
3627C...	Floor board with plate (second)	1915-25	50
3628B...	Floor board with plate (third)	1915-25	65
3630...	Floor board forward plate for pedals	1909-25	10
3632...	Floor board rear plate for pedals	1909-25	10
3633...	Floor board plate for side lever	1909-25	05

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------



BODY PARTS—Continued

DASH			
3634H...	Dash—steel.....	1917-23	\$3 00
3634J...	Dash—steel.....	1923-25	3 00
3638B...	Dash shield.....	1919-22	25
3639...	Dash weatherstrip—side.....	1917-22	05
3639B...	Dash weatherstrip—top.....	1917-22	15
†3640C...	Dash bracket—left.....	1917-22	20
*3640D...	Dash bracket—left.....	1923-26	15
†3641C...	Dash bracket—right.....	1917-22	20
*3641D...	Dash bracket—right.....	1923-26	15
3642B...	Dash bracket to dash bolt.....	1917-22	03
3642C...	Dash bracket to dash nut (Order 3514).....	1917-22	
3653B...	Dash to body bracket bolt.....	1915-25	03
3653C...	Dash to body bracket nut (Order 4805C).....	1915-25	
3654...	Dash to body gasket.....	1918-25	05

LICENSE BRACKETS

§3660E...	Lamp and license bracket support assembly.....	1923-25	75
3662...	Oil tail lamp and license bracket assy.—Road.—Pick-up.....	1926	45
3662B...	Oil tail lamp and license bracket assy.—T. C.....	1926	75
3662C...	Tail lamp and license bracket support.....	1926	15
3662D...	Oil tail lamp and license bracket support.....	1923-26	30
3664...	Front license bracket.....	1921-26	15
**3664B...	Front license bracket.....	1926	15

SPRINGS**FRONT SPRING**

3800...	Front spring—seven leaf.....	1909-25	2 25
†3800B...	Front spring.....	1926	2 50
3808...	Front spring clip.....	1909-20	20
3809B...	Front spring clip nut.....	1921-26	05

†When used on 1911-16 cars, redrill frame.

*Used with steel dash.

§Used on touring car and roadster without starter and demountable rims.

**Use with nine-leaf front spring.

†Eight-leaf spring.

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

**SPRINGS—Continued****FRONT SPRING—Continued**

3810...	Front spring clip bar.....	1921-26	\$0 25
†3811...	Front spring tie bolt.....	1909-25	04
†3811C...	Front spring tie bolt.....	1926	05
3811B...	Front spring tie bolt nut.....	1909-26	02
3813B...	Front spring hanger.....	1909-26	20
3814...	Front spring hanger bar.....	1909-26	05
3815...	Spring hanger nut (Order 2719).....	1909-26	
3818B...	Front spring perch—right.....	1909-26	50
3819B...	Front spring perch—left.....	1919-26	50
3820...	Front spring perch bush.....	1909-26	05
3821B...	Front spring perch nut.....	1921-26	05
3823...	Front spring pad.....	1909-26	05

**REAR SPRING**

†3824...	REAR SPRING.....	1909-26	6 50
*3824B...	REAR SPRING.....	1922-26	6 75
3833...	Rear spring clip.....	1909-26	20
*3833B...	Rear spring clip.....	1922-26	20
3834...	Rear spring clip nut (Order 3869B).....	1909-26	
3835...	Rear spring clip bar.....	1909-26	10
3837...	Rear spring tie bolt.....	1909-26	05
3837B...	Rear spring tie bolt nut.....	1909-26	02
*3838...	Rear spring tie bolt.....	1922-26	05
3840B...	Rear spring hanger.....	1909-26	25
3841...	Rear spring hanger bar.....	1909-26	05
3842...	Rear spring pad.....	1909-26	05
3843...	Rear spring perch.....	1909-25	40
†3843B...	Rear spring perch.....	1926	40
3844...	Rear spring perch bush.....	1909-26	05
3845...	Rear spring perch nut.....	1909-25	05
3846...	Spring perch oiler.....	1917-26	05
3847B...	Front spring clamp assembly with bolt and nut.....	1916-26	10
**3848C...	Rear spring clamp assembly with bolt and nut.....	1926	10

**Replaces 3848B. †Use with 2501B or 2502B. †Eight-leaf spring.

*Nine-leaf spring for Sedan.

†Seven-leaf spring.

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

**STARTING CRANK**

3905...	Starting crank ratchet pin.....	1909-26	\$0 05
3906...	Starting crank ratchet.....	1909-26	20
3908...	Starting crank spring.....	1909-26	03
3910...	Starting crank assembly.....	1909-26	40

RADIATOR—THERMO SYPHON


3925B...	Radiator.....	1917-23	16 00
3925C...	Radiator—less shell.....	1917-23	15 00
3925D...	Radiator.....	1923-26	15 00
3925E...	Radiator—less shell.....	1923-26	14 00
3925F...	Radiator with nickel shell.....	1926	17 00
3926...	Radiator cap.....	1909-26	20
3927...	Radiator cap gasket.....	1909-26	02
3928...	Radiator pad.....	1909-19	05
3929B...	Radiator stud.....	1919-25	05
3929B2...	Radiator stud.....	1926	05
3929C...	Radiator stud nut.....	1909-26	03
3930...	Radiator stud spring (Order 2742).....	1909-26	03
3931 1/2...	Radiator stud washer nut.....	1909-26	03
3932...	Radiator rod.....	1909-23	15
3932B...	Radiator rod.....	1923	15
3932C...	Radiator rod.....	1923-25	15
3932D...	Radiator rod.....	1926	15
3934...	Radiator rod nut (Order 3066B).....	1909-26	25
3939...	Outlet connection pipe.....	1909-26	25
3940...	Outlet connection cock (Order 3079).....	1909-26	10
3944...	Outlet connection hose.....	1909-26	05
3945...	Outlet connection hose clip.....	1909-26	1 00
3947B...	Radiator shell.....	1917-23	1 00
3947C...	Radiator shell.....	1923-26	3 00
3947D...	Radiator shell (nickel).....	1926	02
3975...	Radiator stud spring upper thimble.....	1919-26	03
3976...	Radiator stud spring lower thimble.....	1919-26	35
3977...	Radiator apron.....	1923-25	75
3977C...	Rad. apron and finish strip assy.— Cp.—Tudor—Fordor.....	1926	35
3977D...	Rad. apron finish strip—Cp.— Tudor—Fordor.....	1926	40
3977E...	Radiator apron.....	1926	

RADIATOR FAN

3960...	Fan and pulley assembly.....	1909-20	1 25
3961C...	Fan blade assembly.....	1920-26	25

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

**RADIATOR FAN—Continued**

3962B...	Dr. fan pulley with bush.....	1920-26	\$0 70
3963...	Fan drive pulley.....	1909-20	30
3963B...	Fan drive pulley.....	1920-26	30
3964C...	Fan belt—26".....	1917-20	35
3964E...	Fan belt.....	1920-25	35
3964F...	Fan belt.....	1926	35
3966B...	Fan shaft.....	1920-25	20
3966C...	Fan shaft.....	1926	20
3967B...	Fan bracket.....	1917-25	30
3968...	Fan bracket bolt.....	1909-25	10
3970...	Fan grease cup.....	1909-19	10
3973...	Fan adjusting screw.....	1909-25	02
3973B...	Fan adjusting screw nut (Order 3066B).....	1909-25	15
3973C...	Fan eccentric adj. bolt.....	1926	03
3973D...	Fan eccentric adj. bolt nut.....	1926	15
3974B...	Fan driven pulley bush.....	1920-26	03
3980...	Fan pulley plug.....	1920-26	02
3981...	Fan pulley gasket.....	1920-26	02
3982...	Fan shaft cap.....	1920-26	02
3983...	Fan shaft felt washer.....	1920-26	01
3984...	Fan blade screw.....	1920-26	01
3985...	Fan blade screw washer (Order 3261C).....	1920-26	25
3986...	Fan shaft nut (Order 2719).....	1920-26	03
3987B...	Fan eccentric.....	1926	
3988...	Fan eccentric plate.....	1926	

MUFFLER

4025B...	Muffler assembly.....	1909-26	2 50
4026C...	Muffler head—front.....	1921-26	10
4027...	Muffler shell—outer.....	1909-26	25
4028...	Muffler shell—middle.....	1909-26	20
4029...	Muffler shell—inner.....	1909-26	20
4032...	Muffler head retainer.....	1921-26	02
4033...	Muffler head retainer bolt and nut (Order 4819B and 3514).....	1921-26	doz. 50
4035...	Muffler head bolt washer.....	1921-26	1 40
4037C...	Long exhaust pipe.....	1920-26	20
4040C...	Muffler head—rear.....	1921-26	

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------



MUFFLER—Continued

4041B...	Muffler head to frame bolt and nut (Order 3074 and 2515).....	1921-26	
----------	--	---------	------



HOOD

4050B...	Hood.....	1917-23	\$6 00
4050C...	Hood.....	1923-25	6 00
4050D...	Hood (black).....	1926	6 00
4050E...	Hood (Channel green).....	1926	8 00
4050F...	Hood (Winsor maroon).....	1926	9 00
4051...	Hood handle.....	1909-26	05
4052B...	Hood clip.....	1917-26	10
4053B...	Hood clip spring.....	1917-26	02
4056B...	Hood block—left.....	1917-23	30
4056C...	Hood block—left.....	1923-25	30
4056D...	Hood block—left.....	1926	40
4057B...	Hood block—right.....	1917-23	30
4057C...	Hood block—right.....	1923-25	30
4057D...	Hood block—right.....	1926	40
4060C...	Hood pad (on dash).....	1917-22	08
4060D...	Hood pad (on dash, shell).....	1917-26	15
4060E...	Hood pad (on dash).....	1923-25	08
4060F...	Hood pad (on dash).....	1926	10
4061C...	Hood clasp (on dash) screw.....	1917-23	02
4061D...	Hood clasp (on dash).....	1920-23	05
4061E...	Hood clasp (on dash).....	1923	05

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

HOOD—Continued

4061F...	Hood clasp (on dash).....	1923-25	\$0 05
4073...	Hood block support—front—R.....	1917-23	10
4073B...	Hood block support—front—R.....	1923-25	10
4073C...	Hood block support—front—R.....	1926	15
4074...	Hood block support—front—L.....	1917-23	10
4074B...	Hood block support—front—L.....	1923-25	10
4074C...	Hood block support—front—L.....	1926	15
4075...	Hood block support—rear—R.....	1917-23	10
4075B...	Hood block support—rear—R.....	1923-25	10
4075C...	Hood block support—rear—R.....	1926	05
4076...	Hood block support—rear—L.....	1917-23	10
4076B...	Hood block support—rear—L.....	1923-25	10
4076C...	Hood block support—rear—L.....	1926	05
4077...	Hood block support bracket—rear.....	1926	20

CARBURETOR

FORD CARBURETOR (Model "NH")			
46200C...	Carburetor.....	1926	3 50
6201...	Floater with lever.....	1920-26	25
6213...	Spray needle assembly.....	1920-25	15
6213B...	Carb. spray needle assembly.....	1926	30

KINGSTON CARBURETOR (Model "L-4")			
*6150B...	Carburetor.....	1926	3 50
6155...	Floater with lever.....	1921-26	40
6161...	Spray needle assembly (Order 6115).....	1921-25	45
6161B...	Spray needle assembly.....	1926	45
6175...	Gasoline valve.....	1921-26	30



CARBURETOR ATTACHMENTS

4129A...	Carburetor adjusting rod.....	1909-25	10
4129B...	Carburetor adj. rod and knob assy. —23 1/8" T.C., Road., Open Cab.....	1925	25
4129C...	Carburetor adj. rod and knob assy. —25 1/8" Cp., Tudor, Fordor.....	1925	25
4129D...	Carburetor adj. rod and knob assy. —15 1/8" T and TT Chassis.....	1926	20
4129E...	Carburetor adj. rod and knob assy. —27 1/8" Closed Cab.....	1926	25
4129F...	Carburetor adj. rod and knob assy. —Cp.—Tudor.....	1926	25

*When used on cars without instrument board adjustment replace spray needle and adj. nut with 6213 and 6208.

*When used on cars without instrument board adjustment replace spray needle with 6161.

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
CARBURETOR ATTACHMENTS—Continued			
4129G...	Carburetor adj. rod and knob assy. —Road.—T.C.—Fordor.....	1926	\$0 25
4130...	Carburetor flange bolt (Order 3072).....	1909-26	
4130B...	Carburetor flange bolt nut (Order 3066B).....	1909-26	
4131...	Carburetor adj. rod sleeve.....	1926	10
4132...	Carburetor univ. joint spider.....	1926	05
4134...	Carburetor flange gasket.....	1909-26	05
4431...	Carburetor priming rod.....	1909-26	05
4582...	Carburetor hot air pipe.....	1912-25	20
4582B...	Carburetor h. t. air pipe.....	1925-26	20
4583...	Priming bell crank.....	1919-25	19
4588D...	Priming rod—13 1/8".....	1923-25	15
4588E...	Priming rod—17 1/8".....	1923-25	15
4588F...	Priming rod—16 1/8".....	1923-25	15
4589...	Priming rod—20 1/2".....	1919-25	05
4589B...	Priming rod—14 1/2".....	1922-25	05
4589C...	Choke lever rod—7 1/8".....	1925	02
4589D...	Choke lever rod—7 1/8".....	1926	02
4590...	Priming rod bumper.....	1926	01
4591...	Priming rod lift.....	1926	05
4592...	Choke lever rod—8 3/8" T & T chassis.....	1925	02
4592B...	Choke lever rod—8 3/8" T & T chassis.....	1926	02

FENDERS**FENDERS**

4800H...	Front fender—right.....	1917-23	4 00
4800C...	Front fender—right.....	1923-25	4 00
4800D...	Front fender—right.....	1926	6 00
4801B...	Front fender—left.....	1917-23	4 00
4801C...	Front fender—left.....	1923-25	4 00
4801D...	Front fender—left.....	1926	6 00
4802F...	Rear fender—right.....	1917-25	3 50
4802C...	Rear fender—right.....	1922-25	3 75
4802H...	Rear fender—right.....	1923-25	4 00
4802J...	Rear fender—Right—T. C.— Tudor—Fordor.....	1926	4 75
4802K...	Rear fender—Right—Road—Cp.....	1926	4 75
4803F...	Rear fender—left.....	1917-25	3 50
4803G...	Rear fender—left.....	1922-25	3 75
4803H...	Rear fender—left.....	1923-25	4 00
4803J...	Rear fender—left—T. C.—Tudor— Fordor.....	1926	4 75
4803K...	Rear fender—left—Road—Cp.....	1926	4 75

FENDER IRONS

4804D...	Rear fender iron—R. & L.—T.C.....	1913-25	20
4804E...	Rear fender iron—right—Cp. & Rbt.....	1913-23	60
4804F...	Rear fender iron—left—Cp. & Rbt.....	1913-23	60
4804K...	Fender iron—R. or L.—Sedan.....	1918-25	15

*For Fordor and Tudor. †Used with steel dash.
‡For Coupe.

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
FENDERS—Continued			
FENDER IRONS—Continued			
4804L...	Rear fender iron—T. C.....	1921-25	\$0 10
4804M...	Rear fender iron—right.....	1923-25	60
4804N...	Rear fender iron—left.....	1923-25	60
4809...	Front fender iron—right or left.....	1909-25	60

FENDER BOLTS, NUTS AND BRACKETS

4805B...	Rear fender iron bolt.....	1915-25	03
4805C...	Rear fender iron bolt nut.....	1915-25	02
4806B...	Fender eye bolt.....	1909-25	05
4806C...	Fender eye bolt washer.....	1909-25	01
4806D...	Fender eye bolt nut (Order 2825B).....	1909-25	
4808...	Front fender iron bolt (side).....	1910-25	03
4808B...	Front fender iron bolt (bottom) (Order 3362).....	1910-25	
4808C...	Front fender apron to frame bolt.....	1915-25	03
4808D...	Front fender iron bolt nut (Order 2515).....	1910-25	
4808E...	Front fender apron to frame bolt nut (Order 3088E).....	1915-25	

RUNNING BOARD AND SHIELDS

4812...	Running board—R.....	1909-25	1 25
4813...	Running board—L.....	1909-25	1 25
4813B...	Running board.....	1926	1 75
4814C...	Running board shield—R.....	1917-25	2 40
4814D...	Running board shield—R.....	1922-24	2 40
4814E...	Running board shield—R.....	1924-25	2 40
4814F...	Running board shield—R.....	1926	2 75
4815C...	Running board shield—L.....	1917-25	2 40
4815D...	Running board shield—L.....	1922-24	2 40
4815E...	Running board shield—L.....	1924-25	2 40
4815F...	Running board shield—L.....	1926	2 75
4816...	R. B. truss rod—front with nuts.....	1909-21	35
4817...	R. B. truss rod—rear with nuts.....	1909-21	35
4817B...	Truss rod nut.....	1909-21	03
4818B...	Running board bracket assy.....	1921-26	1 10
4819B...	Running board to rear fender bolt.....	1921-26	03

FORD SPARK COIL

5000...	Coil (includes switch).....	1909-22	8 50
5001...	Coil.....	1909-25	7 75
5001B...	Coil.....	1926	9 00
5001C...	Coil box bracket—right.....	1926	10
5001D...	Coil box bracket—left.....	1926	10
5003...	Coil box with cover.....	1919-25	1 75
5003B...	Coil box with cover.....	1926	2 00
5004...	Coil box cover.....	1915-25	25
5004B...	Coil box cover.....	1926	60
5004C...	Coil box cover gasket.....	1926	10
5005B...	Switch cover.....	1918-22	10
5006...	Switch plug.....	1914-22	05
5007...	Coil unit.....	1914-26	1 50
5008...	Vibrator.....	1914-26	05


*For Fordor and Tudor.

†Same as S740.

‡Same as S728B.

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

**FORD SPARK COIL—Continued**

5008B...	Vibrator and lower bridge assy.	1924-26	\$0 06
5009...	Vibrator bridge	1914-26	08

**SWITCH**

5010...	Switch assembly (on coil)	1914-22	75
5012...	Ignition switch (on instrument board)	1919-25	90
5012B...	Ignition switch	1926	90
5012C...	Ignition switch	1926	1 00
5013B...	Switch key—give serial number	1919-25	10
5014...	Starting switch (on floor board)	1919-26	50
5014B...	Starting switch bracket bolt—long	1920-26	03
5014E...	Starting switch cover and plunger assembly	1923-26	20
5015...	Starting switch plunger extension	1919-25	10

**AMMETER**

5016...	Ammeter	1919-25	75
5016B...	Ammeter	1926	75
5017...	Ammeter lens and rim	1919-25	20
5017B...	Ammeter lens	1919-25	05
5017C...	Ammeter lens	1926	05
5017C2...	Ammeter lens	1926	05
5017D...	Ammeter adapter plate	1926	15

†Cars with starter. §Cars without starter.

Part No.	Name of Part	Year	Each
----------	--------------	------	------

STARTER DRIVE

5018...	Starter drive	1919-26	\$4 00
5019...	Starter drive head	1919-26	50
5020...	Starter drive key	1919-26	02
5021...	Starter drive shaft and gear	1919-26	3 50
5022...	Starter drive spring	1919-26	30
5023...	Starter drive shaft spring screw	1919-26	03
5024...	Starter drive head spring screw	1919-26	05
5025...	St. drive spring screw lock washer	1919-26	01

WIRING


5026...	Spark plug wire 14 1/2"	1909-25	10
5027...	Spark plug wire (also magneto to coil) 10 1/2"	1909-25	10
5028...	Spark plug wire 7"	1909-25	10
5029...	Spark plug wire 7 1/2"	1926	10
5029B...	Spark plug wire 5 1/2"	1926	10
5030...	Commutator wire	1909-22	80
5030B...	Commutator wire	1922-26	1 00
5031...	Commutator wire (starter type)	1919-26	1 10
5031B...	Commutator wire	1926	55
5033B...	Commutator wire term. retainer	1921-26	01
5033C...	Commutator wire clip	1919-26	01
5035...	Ammeter to cutout wire—Sedan	1919-25	20
5037...	Ammeter to cutout wire—Coupe	1919-25	15
5038...	Ammeter to ignition switch wire	1919-25	10
5038B...	Ammeter to ignition switch wire	1926	10
5040...	Terminal block to switch wire	1919-25	10
5040B...	Terminal block to horn switch wire	1926	10
**5041...	Lighting wire	1919-25	90
**5041B...	Lighting wire—Truck	1921-26	1 00
*5041C...	Lighting wire	1922-25	50
*5041D...	Lighting wire	1926	65
5041E...	Lighting wire	1926	1 50
5042...	Switch wire—Sedan	1919-25	75
5042B...	Switch wire—Road—T. C.—Cp.—Tudor	1926	75
*5043...	Switch wire	1919-25	70
5043B...	Switch wire	1922-25	40
*5043C...	Switch wire	1926	45
5043D...	Switch wire—Fordor—Com.	1926	75
5044...	Terminal block	1919-22	10
*5044C...	Terminal block	1922	10
*5044E...	Terminal block with screws	1923-26	10
*5044F...	Terminal block with screws	1923-26	10
5046...	Battery to switch cable—28 1/2"	1919-26	80
5046C...	Battery to switch cable—Truck	1921-26	80
5047B...	Battery to switch cable support—Truck	1920-26	10
5047C...	Battery to switch cable support	1920-26	10

*Used on cars without starter, with switch on instrument panel. §Used with steel dash. **When used with old style tail lamp, remove terminal from end of tail lamp wire.

†Used in 1926 on truck only.

Insist upon genuine Ford parts**Insist upon genuine Ford parts**

Part No.	Name of Part	Year	Each
----------	--------------	------	------

**WIRING—Continued**

5047D...	Battery to switch cable sup. bush.	1920-26	\$0 05
5047E...	Battery to switch cable sleeve.	1921-26	05
5049B...	Ground connector.	1919-26	30
5051...	Switch to motor cable.	1919-26	50
5051B...	Switch to motor cable sleeve.	1921-26	30
5052...	Battery cable terminal bolt.	1919-26	02
5052B...	Battery cable terminal bolt nut.	1919-26	01

STARTER PARTS

5056...	Motor mounting gasket.	1919-26	02
5057...	Gen. head gasket.	1919-26	02

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

STARTER PARTS—Continued

5058...	Gen. mounting short screw.	1919-26	\$0 03
5059...	Bendix cover screw.	1919-26	01
5060...	Term. block to wire screw (Order 5114).	1919-26	
5061...	Ammeter to plate screw.	1919-26	01
5062...	Motor mounting screw.	1919-26	02

STARTING MOTOR AND PARTS

5099...	Starting motor.	1919-26	15 00
5101...	Cover band.	1919-26	10

GENERATOR AND PARTS

5055...	Cut-out (electric).	1919-26	1 00
5119...	Generator.	1919-26	15 00

**BATTERY BRACKET AND PARTS**

5150...	Bracket assembly.	1919-23	75
5150B...	Battery bracket assembly.	1923-26	75
5151...	Clamp bolt.	1919-26	03
5151B...	Clamp bolt nut (Order 2825B).	1919-26	
5152...	Clamp.	1919-23	05
5152B...	Battery clamp.	1921-26	05
5153...	Battery support angle—truck.	1921-26	15
5154...	Battery box support—truck.	1921-26	20
5155...	Battery clamp support—rear—truck.	1921-26	20
5156...	Battery clamp support—front—truck.	1921-26	20
5158...	Battery box—less cover.	1921-26	75
5159...	Battery box cover assembly.	1921-26	60
5160...	Battery box cover door.	1921-26	10

BATTERY (FORD)

5175...	Battery.	1919-26	15 00
5184...	Filler plug with gasket.	1919-22	15
5184B...	Filler plug with gasket.	1921-23	15
5184C...	Filler plug.	1923-26	10

SPARK PLUGS

5201...	Spark plug "Ford" (Champion).	1909-26	60
5203B...	Spark plug porcelain "Ford" (Champion).	1909-26	30

Also for generator.

*Used with steel battery box or rubber case battery.

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

REPAIR TOOLS

1349...	Hub cap wrench		\$0 15
1387...	Adjustable wrench		40
1903...	Pliers		25
1917...	Double end wrench		15
2335...	Spark plug and cylinder head bolt wrench		40
2336...	Tool roll		20
2337...	Oil can		20
2338...	Tire pump		1 00
2340...	Tire irons, each		15
2343...	Jack (including handle)		1 25
2344...	Jack handle		15

REPAIR TOOLS—TRUCK

TT3389X	Jack (including handle)	2 25
TT3391X	Jack handle	20
TT4069	Tire iron (large)	40
TT5893X	Spark plug, rim nut and cylinder head bolt wrench	40



FORD SPECIALTIES

M-255F...	Dressing (top) 1 pt.	65
M-111...	Enamel (black touch-up) 1/4 pt.	1 00
M-165...	Enamel (black) air-dry—1 qt.	1 00
M-392...	Enamel (channell green) (air dry), 1 qt.	1 25
M-393...	Enamel (Windsor maroon) (air dry), 1 qt.	1 50
7962ARX...	Kit (Tire repair)	25
5761X...	Lamp (dash)	60
5773X...	Lamp (dash) cap	10
18259X...	Mirror (rear view) assy.—closed cars	90
7853X...	Mirror (rear view) assy.—open cars	90
18253X...	Mirror (rear view) only	40
M-236F...	Pollah (body) 1 qt.	65
18257X...	Wiper (windshield)	75
17343X...	Nut (windshield wiper)	02
150229X...	Wiper (windshield)	75
3101SX...	Bumper (front) assembly	7 50
3119SX...	Bumper (rear) assembly, T. C.—Fordor—Tudor	7 50
3120SX...	Bumper (rear) assembly—Roadster—Coupe	7 50
3180SX...	Lamp (stop and tail) with switch and wiring	2 50
3208SX...	Snubbing units (front and rear) all cars except T. C.	9 00
3209SX...	Snubbing units (front and rear) T. C.	9 00


†Closed cars 1924-25—Open cars 1924-26. ‡Closed cars 1926.

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------


FORD SPECIALTIES—Continued

3251BRX	Wing (W/S) assembly—R	\$3 25
3252BRX	Wing (W/S) assembly—L	3 25
3318SX...	Wiper (automatic W/S) Closed cars	5 00
3320SX...	Wiper (automatic W/S) Open cars	5 00



ELECTRIC HORN

6437DX...	Bracket (horn)	10
6432DX...	Horn—battery type	1 60
6432EX...	Horn—magneto type	1 50
8028X...	Switch (horn) assembly	30
7915X...	Wire (electric horn terminal)	05
7917BX...	Wire (electric horn to switch)—35 1/2"	10
7917CX...	Wire (horn to switch)	10



ELECTRIC HEADLAMPS

6572AX...	Bulb (headlamp) 9 volt—18 c. p.—double contact—used with magneto without dimmer	30
6572HX...	Bulb (headlamp) 6-8 volt—bright, 21 c. p., dim. 1 1/4 c. p.—double contact—double filament—used with T6576HX lens	1915-18
6572KX...	Bulb (headlamp) 6-8 volt—21 c. p.—double contact—used with dimmer T8892X without starter or dimmer T7320X with starter and T6576HX lens	1922-26

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

ELECTRIC HEADLAMPS—Continued

3178X...	Bulb (stop lamp) 6 volt—21 c. p. single contact (also for headlamps for Lincolns and other cars using single contact 6 volt bulb)		\$0 35
6594HX...	Door assembly with refracting lens		65
6594JX...	Door (head lamp) assy.—nickel		1 00
6575BRX...	Door (less lens) nickel		75
6578X...	Gasket (door lens)		03
6511HX...	Headlamp assembly	pr.	5 50
6511KX...	Headlamp assembly	pr.	5 50
†6501AX...	Headlamp assembly R.		3 25
†6502AX...	Headlamp assembly L.		3 25
6501CX...	Headlamp assembly R.		3 25
6502CX...	Headlamp assembly L.		3 25
6576HX...	Lens (headlamp) refracting—in carton—pair		50
6592X...	Plug—with thimble		10
6590AX...	Reflector assembly		75
6580X...	Screw (focusing)		03
6574X...	Socket (bulb)		15
6574BX...	Socket (headlamp plug)		15
6591X...	Spring (focusing screw)		01
6586X...	Spring (reflector)		05
6589X...	Switch assembly—with screws		30
8650X...	Switch (headlamp and horn) assembly		40
7489X...	Washer (headlamp to fender bracket bolt) (Order 4806C)		

SIDE AND TAIL LAMPS

6520X...	Bulb (tail lamp and headlamp dimmer) 6-8 volt—2 1/4 c. p.—single contact		20
6957X...	Door (tail lamp)		50
6957BX...	Door (tail lamp)		50
7669X...	Lamp (electric tail) assembly		90
8786CX...	Lamp (electric tail) and license bracket assy.—incl. lamp		1 00
6484BX...	Lens (electric tail lamp) red		15
6484CX...	Lens (electric tail lamp) red—celluloid	1923-25	03
6405CX...	Lens (electric tail lamp) white		15
TT8821X...	Wire (tail lamp to ground) assembly		15
6392X...	Wick (lamp)		03

TOURING CAR AND ROADSTER WINDSHIELDS—1915-22

7828X...	Glass (windshield) lower	1915-22	3 00
7827AX...	Glass (windshield) upper	1915-22	2 55
7840ARX...	Windshield assembly		10 00

†Cars without starter.

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

TOURING CAR AND ROADSTER WINDSHIELDS—1922-25

9066X...	Channel (windshield) center	1922-25	\$ 0 35
9534X...	Glass (windshield) lower	1922-25	2 55
7827BX...	Glass (windshield) upper	1922-25	2 35
7840BX...	Windshield assembly	1922-25	10 00
7823BX...	Windshield assembly—lower half	1922-25	4 00
7822CX...	Windshield assembly—upper half	1922-25	4 10

TOURING CAR AND ROADSTER WINDSHIELDS—1926

40324X...	Channel (windshield) center		35
40308...	Glass (windshield) lower	1926	2 30
40323...	Glass (windshield) upper	1926	2 55
40328...	Windshield assembly—lower	1926	4 15
40327...	Windshield assembly—upper	1926	4 10
40300...	Windshield assembly	1926	11 50

TOURING CAR TOPS—1915-22

6683RX...	Curtain (touring car storm) right	1913-22	1 75
6682RX...	Curtain (touring car storm) left	1913-22	1 75
6940ARX...	Curtain (back) and stay assy.	1915-22	3 00
4966BRX...	Curtain (touring car side) right	1915-22	2 00
4967BRX...	Curtain (touring car side) left	1915-22	2 00
7940ARX...	Top (touring car) complete	1915-22	27 00

TOURING CAR TOPS—1922-25

6882BX...	Curtain (front side) assembly—right	1922-25	1 75
6883BX...	Curtain (front side) assembly—left	1922-25	1 85
6940CX...	Curtain (rear) assembly	1922-25	2 50
4966DX...	Curtain (rear side) assembly—right	1922-25	1 75
4967DX...	Curtain (rear side) assembly—left	1922-25	1 75
7940BX...	Top assembly	1922-25	27 00

TOURING CAR TOPS—1926

*41100X...	Curtain (front side) assembly—right		2 25
*41101X...	Curtain (front side) assembly—left		2 25
41102X...	Curtain (center side) assembly—right		2 25
41103X...	Curtain (center side) assembly—left		2 25
41104X...	Curtain (rear side) assembly—right		1 00
41105X...	Curtain (rear side) assembly—left		1 00
41106X...	Curtain (back) assembly		3 00
*41045X...	Rod (curtain) front—right		20
*41046X...	Rod (curtain) front—left		20
41047X...	Rod (curtain) rear—right		20
41048X...	Rod (curtain) rear—left		20
41011X...	Top assembly		27 00

*Also used on 1926 Roadster Top.

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
ROADSTER TOP PARTS—1915-22			
6937AX	Curtain (side) rear—right	1915-22	\$ 1 25
6938AX	Curtain (side) rear—left	1915-22	1 25
6935AX	Curtain (side) front—right	1915-22	1 50
6936AX	Curtain (side) front—left	1915-22	1 50
6950AX	Curtain (back) assembly	1915-22	2 40
7941RX	Top complete	1915-22	22 00

ROADSTER TOPS—1922-25

6935BX	Curtain (front side) assembly—right	1922-25	1 25
6936BX	Curtain (front side) assembly—left	1922-25	1 35
6937BX	Curtain (rear side) assembly—right	1922-25	90
6938BX	Curtain (rear side) assembly—left	1922-25	90
6950BX	Curtain (rear) assembly	1922-25	2 50
7941BX	Top assembly	1922-25	22 00

***ROADSTER TOPS—1926**

41067X	Curtain (rear side) assembly—right	1 00
41068X	Curtain (rear side) assembly—left	1 00
41069X	Curtain (back) assembly	2 50
41049X	Top assembly	22 00

‡For additional 1922-25 Roadster Top parts see 1922-25 Touring Car Top parts marked with a double asterisk (**).
 For additional 1926 Roadster Top parts see 1926 Touring Car Top parts marked with an asterisk ().

Insist upon genuine Ford parts


Part No.	Name of Part	Year	Each
			

Price List of Parts for Model T One-Ton Truck**REAR AXLE**

1000	Axle assembly—rear	1918-26	\$110 00
1001	Axle housing—right	1918-26	15 00
1002	Axle housing—left	1918-26	15 00
1003	Axle housing bolt	1918-26	05
1003B	Axle housing bolt nut (Order 2719)	1918-26	
1004	Axle housing cap	1918-26	40
1005	Axle housing cap gasket	1918-26	02
1006	Axle housing cap screw	1918-26	05
1008	Axle housing gasket—upper	1918-26	02
1009	Axle housing gasket—lower	1918-26	05
1010	Axle brake housing plate—right	1918-26	35
1011	Axle brake housing plate—left	1919-26	35
1012	Axle housing drain plug	1918-26	05
1013	Axle shaft	1918-26	4 00
1014	Axle shaft cotter	1918-26	doz. 05
1015	Axle shaft nut	1918-26	10
1016	Axle shaft washer	1918-26	05
1017	Axle shaft dust cap	1918-26	03
1018	Axle shaft inner ball bearing assembly	1918-26	5 00
1019	Axle shaft outer roller bearing	1918-26	1 00
1020	Axle shaft outer R. B. sleeve—R	1918-26	35
1020B	Axle shaft outer R. B. sleeve—L	1918-26	35
1021	Axle shaft bearing felt	1918-26	15

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
REAR AXLE—Continued			
1022...	Axle shaft bearing retainer.	1918-26	\$0 05
1023...	Axle shaft bearing retainer washer.	1918-26	02
1024...	Axle shaft felt retainer assy.	1918-26	20
1025...	Axle shaft felt retainer cup.	1918-26	03
1026...	Axle shaft felt retainer plate.	1918-26	03
1026B...	Rear axle oil retainer.	1926	25
1027...	Differential gear.	1918-26	1 25
1028B...	Differential gear case—R. or L. half.	1923-26	2 50
1029...	Differential gear case bolt (Order 1003).	1918-26	02
1031...	Differential gear lock ring.	1918-26	50
1032...	Differential pinion.	1918-26	30
1033...	Differential pinion shaft.	1918-23	1 50
1033B...	Differential spider.	1923-26	



DRIVE SHAFT

1034...	Drive shaft.	1918-26	7 00
1036...	D. S. tube assembly.	1918-26	10 00
1037...	D. S. tube flange gasket.	1918-26	02
1038...	D. S. tube flange screw (Order 1006).	1918-26	
1039...	D. S. felt.	1918-26	10
1040...	D. S. felt container.	1918-26	03
1041B...	D. S. to worm coupling.	1920-26	70
1042...	D. S. to worm coupling pin.	1918-26	01

WORM


1043...	Worm—7 $\frac{1}{4}$ to 1.	1918-26	6 00
1043B...	Worm—5 $\frac{1}{2}$ to 1.	1918-26	6 00
1044...	Worm gear—7 $\frac{1}{4}$ to 1.	1918-26	10 00
1044B...	Worm gear—5 $\frac{1}{2}$ to 1.	1918-26	10 00
1045...	Worm cotter (Order 1014).	1918-26	
1046...	Worm roller bearing.	1918-26	75
1047...	Worm roller bearing retainer (Order 1023).	1918-26	
1048...	Worm roller bearing sleeve.	1918-26	1 00
1049...	Worm roller bear. housing screw.	1918-26	03
1050...	Worm thrust bearing collar.	1918-26	50
1051...	Worm thrust ball and sep. assy.	1918-26	60
1053...	Worm thrust bear. retainer.	1918-26	15

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
REAR AXLE—Continued			
1043...	Worm thrust bear. retainer nut (Order 1015).	1918-26	
1043B...	Worm thrust bear. retainer pin.	1918-26	\$0 01

WORM—Continued

1054...	Worm thrust bear. retainer nut (Order 1015).	1918-26	
1055...	Worm thrust bear. retainer pin.	1918-26	\$0 01



Part No.	Name of Part	Year	Each
----------	--------------	------	------

REAR AXLE—Continued

RADIUS ROD

1073...	Rear radius rod—right...	1918-26	\$3 00
1073B...	Rear radius rod—left	1918-26	3 00
1074...	Rear radius rod bolt—front	1918-26	10
1075...	Rear radius rod bolt—rear	1918-26	10
1075B...	Rear radius rod bolt nut	(Order 2507) 1918-26	
1076...	Universal joint bushing	1918-26	60



SPRINGS

REAR SPRING

1077...	Rear spring—right or left, each	1918-26	4 00
1087...	Spring bushing	1918-26	20
1088...	Spring clip	1918-26	45
1089...	Spring clip nut	1918-26	05
1091...	Spring clip plate	1918-26	20
1092...	Spring tie bolt	1918-26	15
1093...	Spring tie bolt nut (Order 1089)	1918-26	
1094...	Spring tie bolt cotter	1918-26	doz. 05
1095...	Spring clamp	1918-26	10
1096...	Spring clamp bolt	1918-26	03
1096B...	Spring clamp bolt nut (Order 3514)	1918-26	
1097...	Spring perch	1918-26	90
1098...	Spring perch nut (Order 1015)	1918-26	
1099...	Spring perch cotter (Order 1014)	1918-26	
1100...	Spring perch bushing	1918-26	35
1101...	Spring perch bush, spacer	1918-26	10
1102...	Spring hanger assembly	1918-26	30

FRONT SPRING (Nine-leaf)

1151...	Front spring	1926	3 00
1161...	Front spring tie bolt	1926	05
1162...	Front spring tie bolt nut (Order 3811B)	1925	
1164B...	C. C. front bearing and spring clip assembly	1926	90
1165...	Front spring clip bar	1926	25
1166...	C. C. front bearing and spring clip nut (Order 2507)	1926	

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------




WHEELS

1105B...	Rear wheel—dem.—Kelsey	1919-24	\$15 00
1105C...	Rear wheel—dem.—Hayes	1919-24	15 00
1105D...	Rear wheel—dem.—less rim and hub—Kelsey	1919-24	6 50
1105E...	Rear wheel—dem.—less rim and hub—Hayes	1919-24	6 50
1105H...	Rear wheel complete—dem.	1924-26	14 75
1105J...	Rear wheel—less rim	1924-26	10 75
1105K...	Rear wheel—less rim and hub	1924-26	6 50
1106C...	Dem. rim only—Hayes	1919-26	3 50
1106D...	Dem. rim only—Kelsey	1922-26	3 50
1106E...	Dem. rim retainer ring—Kelsey	1922-26	45
1106F...	Dem. rim and flange assy.	1924-26	2 75
1106G...	Dem. rim flange	1924-26	90
1107B...	Clamp and nut assy.—Kelsey	1919-26	15
1107C...	Clamp	1924-26	10
1108B...	Clamp bolt	1919-24	05
1108C...	Clamp bolt	1924-26	05
1108D...	Clamp nut	1924-26	05
1109...	Rear wheel complete—solid tire design—less tire	1918-26	17 50
1109B...	Rear wheel—solid tire design—less hub and tire	1919-26	13 25
1111...	Rear hub	1918-26	2 25
1112...	Rear hub flange	1918-26	40
1113...	Rear hub brake drum	1918-26	1 25
1114...	Rear hub bolt	1918-26	05
1114B...	Rear hub bolt nut	1918-25	02
1116...	Rear hub cap	1918-26	25
1117...	Rear hub key	1918-26	03
1118...	Rear hub felt	1918-26	10

130" x 5" Wheel.

Insist upon genuine Ford parts

Part No.	Name of Part	Year	Each
----------	--------------	------	------

**FRAME**

1119...	Frame assembly.....	1918-26	\$25 00
1120...	Side member—right.....	1918-26	9 00
1121...	Side member—left.....	1918-26	9 00
1122...	Front cross member.....	1918-26	1 00
1123...	Rear cross member.....	1918-26	4 00

TRANSMISSION CONTROL

1133...	Speed lever.....	1918-26	10
1134...	Control shaft with speed lever.....	1918-26	60

Insist upon genuine Ford parts

Genuine Ford parts may be ordered by mail, for shipment by parcel post, express, or freight, from the authorized *Ford dealer whose name appears on the front cover of this list.*

Order parts by part number and name, specifying how shipment is to be made.

All mail orders should be accompanied by remittance in the form of a money order to cover the price of the goods. If shipment is to be made by parcel post, include in your remittance a sufficient amount to cover postage.