

\$ 13.69

\$ ~~25.00~~
5.00

Ford

THE UNIVERSAL CAR

**WHOLESALE
PRICE LIST OF PARTS**

MODEL T

34
80
27,20

Effective January 1, 1927

Ford Motor Company
Detroit, Michigan

INDEX

Ammeter.....	36	Starter Parts.....	38
Axle (Front).....	6	Starting Crank.....	25
Axle (Rear).....	4	Starting Motor and Parts.....	38
Drive Shaft.....	5	Steering Gear.....	21
Universal Joint.....	5	Steering Gear and Gear Case.....	21
Battery Bracket and Parts.....	39	Steering Gear Bracket.....	22
Battery (Ford).....	40	Steering Gear Throttle and Spark Rods.....	22
Body Parts.....	23	Steering Gear Tubing and Post.....	22
Body Brackets.....	23	Switch.....	36
Dash.....	23	Tools (Repair).....	41
Floor Boards.....	23	Tools (Repair)—Truck.....	43
License Brackets.....	23	Tops.....	48
Carburetor.....	30	Roadster—1915-22.....	50
Ford Carburetor (Model "N. H.").....	30	Roadster—1922-25.....	50
Kingston Carburetor (Model "L-4").....	30	Roadster—1926-27.....	50
Carburetor Attachments.....	32	Touring—1915-22.....	48
Coil (Ford Spark).....	35	Touring—1922-25.....	48
Cotter Pins.....	43	Touring—1926-27.....	49
Fan.....	28	Transmission.....	17
Fenders.....	33	Transmission Control.....	18
Fender Bolts, Nuts and Brackets.....	34	Transmission Cover.....	18
Fender Irons.....	34	Clutch Release.....	18
Frame.....	10	Hand Brake.....	20
Gasoline Tank.....	10	Pedals and Controller Shaft.....	20
Generator and Parts.....	438	Transmission Bands.....	19
Hood.....	29	Truck Parts.....	51
Horn (Electric).....	45	Axle (Rear).....	51
Lamps (Electric Head).....	45	Brake Parts.....	53
Lamps (Side and Tail).....	46	Drive Shaft.....	52
Magneto and Fly Wheel.....	16	Frame.....	53
Motor.....	12	Radius Rod.....	53
Commutator.....	16	Spring (Front).....	54
Crank Case and Cylinder Valve Cover.....	14	Spring (Rear).....	53
Crank Shaft and Cam Shaft.....	13	Transmission Control.....	55
Cylinder.....	12	Wheels.....	54
Piston and Connecting Rod.....	13	Worm.....	52
Valves, Push Rods, Exhaust and Inlet Manifold.....	14	Vaporizer.....	31
Muffler.....	28	Wheels.....	7
Paints and Polishes.....	44	Clincher.....	7
Radiator—Thermo Syphon.....	25	Demountable.....	7
Running Board and Shields.....	35	Demountable—Balloon.....	7
Running Board—Truck.....	35	Hubs and Parts.....	8
Spark Plugs.....	41	Rim and Rim Carrier.....	9
Specialties (Ford).....	43	Wire.....	8
Springs.....	24	Windshields.....	47
Spring (Front).....	24	Touring and Roadster—1915-22.....	47
Spring (Rear).....	24	Touring and Roadster—1922-25.....	47
Starter Drive.....	36	Touring and Roadster—1926-27.....	48
		Wiring.....	36

Ford Motor Company

FORD FACTORIES AND BRANCHES

Ford Factory, Detroit—*Parent Plant*
 Ford Factory, Ford, Ontario, Canada
 Ford Factory, Manchester, England

AMERICAN WHOLESALE BRANCHES

Atlanta	Cleveland	Fargo	Los Angeles	Oklahoma City	St. Paul
Buffalo	Columbus	Houston	Louisville	Omaha	Salt Lake City
Cambridge	Dallas	Indianapolis	Memphis	Philadelphia	San Francisco
Charlotte	Denver	Jacksonville	Milwaukee	Pittsburgh	Seattle
Chicago	Des Moines	Kansas City, Mo.	New Orleans	Portland	Washington
Cincinnati	Detroit	Kearny, N. J.	Norfolk	St. Louis	

Instructions for Ordering Parts

- 1—Order all parts through the Authorized Ford Dealer.
- 2—Always give Catalog Number and Name of each part ordered.
- 3—Specify whether shipments are to be made by freight, express or parcel post.
- 4—Remittance by Draft or Money Order must accompany all parts orders placed for shipment from the Ford Branch.
- 5—All prices are f. o. b. Branch, Factory or Dealer.

Prices subject to change without notice.

Note:—Part numbers covering parts used at present in the production of cars are printed in bold face type. All other Part Numbers are printed in light face type.

Telegraph Code

We list below a brief General Code covering miscellaneous instructions relative to the shipment of parts.


- | | |
|--|---|
| Toperig —Ship to me (us) by express. | Topfton —When and how did you ship parts called for in my (our) telegram of — |
| Toperkleur —Ship by express to — | Topflutch —When and how will you ship parts called for in my (our) telegram of — |
| Topersteen —Ship to me (us) by freight. | Topwasser —When and how will you ship parts called for in my (our) letter of — |
| Toper —Ship to me (us) by parcel post. | |

Copyrighted 1927
 by
 Ford Motor Company
 All rights reserved.

Wholesale Price List of Parts

FORD MODEL T 1909-1927

EFFECTIVE JANUARY 1, 1927



Part No.	Name of Part	Year	Lots of 10 per lot	LIST PRICE of 100 per lot	PRICE of 1000 per lot	Each	Fac. No.	No. Req. per Car
----------	--------------	------	--------------------	---------------------------	-----------------------	------	----------	------------------

REAR AXLE

2500	Rear axle assembly	1909-25				\$50 00	95E	1
2500B	Rear axle assembly	1926-27				50 00	95B	1
2501	Axle housing—right	1915-25				8 00	7635AR	1
2501B	Rear axle housing assembly—R	1926-27				8 00	7635B	1
2502	Axle housing—left	1915-25				8 00	7636AR	1
2502B	Rear axle housing assembly—L	1926-27				8 00	7636B	1
2503E	Axle housing bolt	1913-27	\$0 15	\$1 00	\$6 00	03	2854	7
2503F	Axle housing bolt nut	1909-27	15	1 00	6 00	02	44	7
2504	Rear axle case gasket	1919-27	15	1 00	8 00	03	139	1
2505	Axle shaft	1912-27	12 50			1 40	2818	2
2506	Axle shaft washer	1909-27	10	75	5 00	02	39	1
2507	Axle shaft nut	1909-27	40	3 50	30 00	05	242	2
2508	Axle shaft R. B.	1909-27				55	253	4
2509	Axle shaft R. B. sleeve—R	1909-27	1 40	13 50		15	170	2
2509B	Axle shaft R. B. sleeve—L	1909-27	1 40	13 50		15	161	2
2510	Axle housing cap	1909-19	25	2 00		05	56AR	2
2510 1/2	Axle housing cap	1919-27	20	1 80	17 00	05	56B	2
2510A	Axle outer roller bearing steel washer	1909-27	15	1 00	7 50	02	199B	2
2510B	Axle outer roller bearing felt washer	1909-27	40	3 00	27 50	05	54	2
2511	Rear axle oil retainer	1926-27				20	198A	2
2511B	Rear axle oil retainer washer	1926-27				05	221	2
2511C	Rear axle oil retainer assembly	1926-27				25	245	2
2512C	Diff. case—left	1914-27	14 00			1 50	84	1
2513C	Diff. case—right	1914-27	8 00			90	81	1
2514B	Diff. case stud	1915-21	35	3 00		05	52BR	3
2514C	Diff. case bolt	1922-27	35	3 00	27 50	05	52C	3
2515	Diff. case stud nut	1909-27	15	1 25	10 00	02	8	3

*2511 with 2511B assembled.


Above quantity prices as well as individual prices subject to wholesale trade discount.

Ford Motor Company

Parts Price List

Page Five

Part No.	Name of Part	Year	Lots of 10 per lot	LIST PRICE of 100 per lot	PRICE of 1000 per lot	Each	Fac. No.	No. Req. per Car
2518	Diff. drive gear	1909-27	\$22 50			\$2 50	12B	1
2519	Diff. drive gear screw	1909-27	20	\$ 1 75		03	103	10
2519A	Diff. gear lock ring	1909-27	15	1 00		02	118	2
2520B	Diff. gear	1909-27	9 50			1 00	13B	2
2521B	Diff. gear key	1911-27	40	3 50	\$30 00	05	137	2
2524C	Diff. pinion	1915-27	3 00			35	14D	3
2526B	Diff. spider	1909-27				75	15D	1
2528	Diff. thrust washer	1909-27	1 75			20	30	2
2529	Diff. thrust plate	1909-27	1 25	10 00		15	31	4
2531B	Diff. housing oil plug	1917-27	10	75	5 00	02	7640	6
2532	Diff. axle housing plug	1909-26		4 00		05	817	1
2532B	Rear axle grease cup	1926-27		4 00		05	2824	1
2545	Rear axle grease cup	1909-27	60	5 00		10	76A2	2
2547	Rear radius rod—right	1909-25				1 00	152AR	1
2547B	Rear radius rod—left	1909-25				1 00	158AR	1
2547C	Rear radius rod assy.—R	1926-27				1 00	152B	1
2547D	Rear radius rod assy.—L	1926-27				1 00	158B	1
2548	Radius rod nut	1909-27	35	3 00	25 00	05	77	2
2549	Radius rod lock nut	1909-27	35	3 00	20 00	05	78	2
2550	Radius rod lock washer	1909-27	15	1 00	7 50	02	2823	2
2551	Radius rod bolt	1909-27	35	3 00	27 00	05	83	4
2551B	Radius rod bolt nut	1909-27		2 50	20 00	03	60	4
2557	Hub cam shaft—right	1909-25	75	7 00		10	92BR	1
2557B	Hub brake cam—R	1926-27				50	92C	1
2558	Hub cam shaft—left	1909-25	75	7 00		10	61BR	1
2558B	Hub brake cam—L	1926-27				50	61C	1
2559	Hub brake cam bushing	1909-25	30	2 50		05	173AR	2
2559B	Hub brake cam bushing	1926-27				10	173B	2
2560	Brake housing cover assy.—R	1926-27				40	148	1
2561	Brake housing cover assy.—L	1926-27				40	149	1
2562	Cam shaft lever	1909-25				10	62AR	2
2562B	Hub brake cam lever	1926-27				10	62B	2
2563	Cam shaft lever pin	1909-25	05	30	2 00	01	7	4
2563B	Hub brake cam lever pin	1926-27						
2564	Lever clevis pin	1909-27		1 50		02	65	4
2566	Hub brake shoe	1909-25	3 20	30 00		35	2814R	2
2566B	Hub brake band assy.	1926-27				1 25	2833	2
2566D	Hub brake band lining	1926-27	3 50			40	51	2
2567	Brake shoe support bolt	1909-25	45	4 00		05	59	2
2568	Brake shoe support nut	1909-25						
2570B	Brake shoe coil spring	1913-25	15	1 00		02	2862AR	4
2570C	Hub brake band spring	1926-27				10	2862B	2



UNIVERSAL JOINT


2571	Universal joint assembly	1909-27	14 00			1 50	151B	1
2572	Joint knuckle (male)	1909-27				50	45B	1
2573	Joint knuckle (female)	1909-27				60	46B	1
2574	Joint knuckle pin	1909-27	08	50		01	6	1
2575	Joint ring, complete	1909-27	4 00			50	49B	1
2576	Joint ring rivets	1909-27	10	50 (per set 4)		05	50	4
2577B	Univ. joint housing	1914-27				1 00	7609	1
2578	Joint housing plug	1909-27	30	2 50		05	75	2
2579	Ball joint grease cup	1909-27	1 20	10 00		15	195	1
2580	Ball cap gasket	1909-27	30	2 50	20 00	05	1518	1

DRIVE SHAFT

2581	Drive shaft housing front bushing	1909-27				30	69	1
2582	D. S. tubing	1911-27				7 50	153B	1
2583B	D. S. bearing housing	1920-27				1 40	191C	1
2584B	D. S. R. B. cap screw	1912-27	35	3 00	25 00	05	183B	6
2584C	D. S. R. B. stud nut	1912-21	25	2 00		03	184R	6
2584D	D. S. R. B. cap screw lock washer	1912-27		30	doz.	05	157	6
2585	D. S. R. B. housing set screw	1911-21	45	4 00		05	101R	1
2587	D. S. roller bearing	1911-27	5 00			60	108	1
2588	D. S. R. B. distance plate	1911-21	15	1 00		05	106R	1
2589	D. S. ball race	1911-21				25	186R	1

When ordered to replace malleable type housing also order 2-2591 and 1-2591B.

Above quantity prices as well as individual prices subject to wholesale trade discount.




Part No.	Name of Part	Year	Lots of 10 per lot	LIST PRICE Lots of 100 per lot	Lots of 1000 per lot	Each	Fac. No.	No. Req. per Car
----------	--------------	------	--------------------	-----------------------------------	----------------------	------	----------	------------------

REAR AXLE—Continued

DRIVE SHAFT—Continued

2589B...	D. S. ball bearing assy.	1911-21				\$ 0 90	185AR...	1
2590...	D. S. ball retainer	1911-21		\$ 0 20		03	190AR...	1
2591...	D. S. ball thrust collar	1911-27		1 50		20	188	2
2591B...	D. S. thrust ball and retainer assy.	1920-27		1 50	\$14 00	20	162	1
2592...	D. S. ball bearing	1911-21		Order 2811				
2593...	D. S. R. B. sleeve	1911-21				1 50	107R...	1
2595B...	D. S. only	1911-27	25	00		3 00	87D...	1
2596...	D. S. sleeve	1911-27	4	00		50	163B...	1
2597B...	D. S. pinion	1911-27	10	00		1 25	16C...	1
2597C...	D. S. pinion	1911-27	10	00		1 25	16D...	1
2598...	D. S. castle nut	1911-27	70	6 00		08	124	1
2598B...	D. S. pinion key	1911-27	40	3 00	\$27 50	05	57B...	1



FRONT AXLE

2691...	Front axle only	1909-27				9 00	202B...	1
2691H...	Spindle body—right	1911-25	13	50		1 40	280AR...	1
2694C...	Spindle body—R.	1926-27	13	50		1 40	280B...	1
2695B...	Spindle body—left	1911-25	13	50		1 40	281AR...	1
2695C...	Spindle body—L.	1926-27	13	50		1 40	281B...	1
2696...	Spindle arm—right or left	1911-19	4	00		50	7716A...	2
2696C...	Spindle arm—right	1919-27	4	00		45	7715B...	1
2696D...	Spindle arm—left	1919-27	4	00		45	7716B...	1
2697...	Spindle arm nut	1911-27		Order 2548				
2704...	Stationary cone	1909-25				15	205AR...	2
2705...	Adj. cone—right thread	1909-25				15	206AR...	1
2706...	Adj. cone—left thread	1909-25				15	207AR...	1
2707...	Spindle nut—right thread	1909-27		4 50		05	209B...	1

Part No.	Name of Part	Year	Lots of 10 per lot	LIST PRICE Lots of 100 per lot	Lots of 1000 per lot	Each	Fac. No.	No. Req. per Car
----------	--------------	------	--------------------	-----------------------------------	----------------------	------	----------	------------------

FRONT AXLE—Continued

2708...	Spindle nut—left thread	1909-27		\$4 50		\$0 05	208B...	1
2709...	Spindle washer	1909-27		\$0 15	1 00	\$6 00	02	210
2710...	Spindle bolt with oiler	1910-27		1 60	15 00		20	7708
2711...	Spindle bolt nut	1909-27		Order 2551B				
2713...	Spindle body bushing (pair)	1909-27		1 75	16 50	150 00	20	223
2714...	Spindle arm bushing	1909-27		12	1 00	9 00	05	225
2715D...	Spindle oiler	1919-27		Order 3176C				
2717...	Spindle con. rod	1909-27		12 50			1 50	264AR
2718...	Spindle con. rod bolt with oiler	1909-27		1 40	12 00		15	7706
2719...	Spindle con. rod bolt nut	1909-27			1 50	14 00	02	220
2721B...	Spindle con. rod yoke ball	1919-27		1 75			20	226B
2721C...	Spindle con. rod yoke	1919-27		3 50			40	248B
2725B...	Steering gear connecting rod	1909-25					80	289A
2725C...	Steering gear con. rod	1926-27					80	289B
2728...	Ball socket cap	1909-27		1 20	10 00		15	254B
2729B...	Ball socket bolt and nut	1909-27		Order 3362 and 2515				
*2733B...	Front radius rod	1919-27					1 50	263B
2736...	Front radius rod ball cap	1909-27		1 20	10 00		15	217
2737...	Front radius rod ball socket	1911-24					30	809BR
2737B...	Front radius rod ball socket	1924-27					30	809C
2741...	Radius rod ball cap stud	1911-27		30	2 50	22 50	05	4365
2741B...	Radius rod ball cap stud nut	1911-27		Order 2515				
2741C...	Front radius rod ball cap bolt	1924-25					05	251R
2742...	Radius rod ball cap spring	1911-27		15	1 00	8 00	03	292

WHEELS

WHEELS (Clincher)

2800...	Front wheel—clincher	1909-26				6 00	291BR...	2
2800D...	Front wheel—clincher—less hub	1909-26				4 00	295AR...	2
2800A1...	Front wheel—clincher—30 x 3 1/2	1926				6 00	291J...	2
2814C...	Rear wheel—clincher	1912-25				6 00	2815AR...	2
2814C2...	Rear wheel—clincher—11" brake drum	1926				6 50	2815KR...	2
2814D...	Rear wheel—clincher—less hub	1909-26				4 00	2816AR...	2

WHEELS (Demountable)

†2800B...	Front wheel—dem. less rim	1919-24				5 50	291DR...	2
‡2800C...	Front wheel—dem. less rim	1919-24				5 50	291ER...	2
‡2800G...	Front wheel—dem. less rim	1919-26				5 50	291GR...	2
†2800E...	Front and rear wheel—dem. less rim and hub	1919-24				3 50	293AR...	4
†2800F...	Front and rear wheel—dem. less rim and hub	1922-23				3 50	293BR...	4
‡2800H...	Front and rear wheel—dem. less rim and hub	1924-25				3 50	293D...	4
‡2801B...	Front wheel complete R. or L.—dem.	1919-26				7 00	7697B...	2
‡2814F...	Rear wheel complete—dem.—8" brake drum	1919-25				7 00	7698BR...	2
‡2814F2...	Rear wheel complete—dem. 30 x 3 1/2 —11" brake drum	1926				7 00	7698H...	2
†2814G...	Rear wheel—dem. less rim—8" brake drum	1919-24				5 50	2815BR...	2
†2814H...	Rear wheel dem. less rim—8" brake drum	1922-23				5 50	2815CR...	2
‡2814K...	Rear wheel—dem.—less rim—8" brake drum	1924-25				5 50	2815ER...	2
‡2814K2...	Rear wheel—dem.—less rim 30 x 3 1/2 —11" brake drum	1926				5 50	2815HR...	2

WHEELS (Balloon Demountable)

2800I...	Frt. wheel, balloon—with hub less rim—black	1926-27				5 50	291HR...	2
2800J...	Frt. wheel, balloon—with hub less rim—natural	1926-27				5 50	291I...	2
2800K...	Frt. & rear wheel—balloon—less rim & hub—black	1926-27				3 50	293E...	4
2800L...	Frt. & rear wheel—balloon—less rim & hub—natural	1926-27				3 50	293F...	4
2801D...	Front wheel complete—balloon—black	1926-27				7 00	7697E...	2
2801E...	Front wheel complete—balloon—natural	1926-27				7 00	7697F...	2
2814L...	Rear wheel complete—balloon—black—8" brake drum	1925				7 00	7698ER...	2
2814L2...	Rear wheel complete—balloon—black—11" brake drum	1926-27				7 00	7698G...	2
2814M...	Rear wheel complete—balloon—natural—8" brake drum	1925				7 00	7698FR...	2

*Substitute 2733B with spring perches for 2733.

†Use with 2845 rim.

‡Use with 2845C or 2845D rim.

{Use with attached clamp rim.

Above quantity prices as well as individual prices subject to wholesale trade discount.


Above quantity prices as well as individual prices subject to wholesale trade discount.

Part No.	Name of Part	Year	Lots of 10 per lot	LIST PRICE Lots of 100 per lot	Lots of 1000 per lot	Each	Fac. No.	No. Req. per Car
----------	--------------	------	--------------------------	---	----------------------------	------	-------------	---------------------------

WHEELS—Continued

WHEELS (Balloon Demountable)—Continued

2814M2.	Rear wheel complete—balloon— natural—11" brake drum.....	1926-27				\$7 00.	7698J	2
2814N...	Rr. wheel—balloon—with hub less rim—black—8" brake drum.....	1925				5 50.	2815FR	2
2814N2.	Rear wheel—balloon—with hub less rim—black—11" brake drum.....	1926-27				5 50.	2815J	2
2814P...	Rr. wheel—balloon—with hub less rim—natural—8" brake drum.....	1925				5 50.	2815GR	2
2814P2.	Rear wheel—balloon—with hub less rim—natural 11" brake drum.....	1926-27				5 50.	2815M	2




WHEELS (Wire)

2880...	Wire wheels, set of 5—specify Black, Red, Green or Straw color.....	1926-27				*35 00.		
2881...	Wire wheel, less hub—specify Black, Red, Green or Straw color.....	1926-27				7 00.	2846	5
2882...	Front hub with bolts including R. B. cups.....	1926-27				3 00.	2841	2
2883...	Front hub bolt.....	1926-27				05.	7332B	10
2884...	Front and rear hub bolt nut.....	1926-27				15.	2809	22
2885...	Front and rear hub cap.....	1926-27				30.	7727B	5
2886...	Front hub grease retainer.....	1926-27				10.	2840	2
2887...	Rear hub and brake drum with bolts.....	1926-27				3 50.	2842B	2
2888...	Rear hub bolt.....	1926-27				05.	2811	10
2889...	Hub brake drum.....	1926-27				75.	3D	2
2890...	Wire wheel locking nut.....	1926-27				30.	2852	1
2891...	Wire wheel socket wrench.....	1926-27				45.	2839	

HUBS AND PARTS

2803B...	Front hub with R B cups.....	1909-27				1 60.	219	2
2804...	Outer race.....	1909-25		\$7 50.		10.	234R	2
2805...	Inner race.....	1909-25		15.	235R	2		
2806...	Outer ball retainer.....	1909-25	\$0 15	1 00.		02.	236AR	2
2807...	Inner ball retainer.....	1909-25	15	1 25.		03.	237AR	2
2808...	Dust ring.....	1909-27	20	1 50.		03.	238	2
2809...	Front & rear hub felt washer.....	1909-27	35	3 00	\$25 00	05.	239A	4
2810...	Large balls.....	1909-25		3 00	25 00	04.	241AR	24
2811...	Small balls.....	1909-25		1 50	13 50	03.	249AR	22
2815C.	REAR HUB.....	1912-27	10 00.			1 25.	2819	2
2816B...	Rear hub key.....	1912-27	15	1 40	12 00	03.	2863	2
2818...	Hub brake drum.....	1909-25	3 00.			40.	3BR	2
2818B...	Hub brake drum.....	1926-27				75.	3C	2
2819...	Hub cap.....	1909-27				10.	7727A	4
2825...	Rear hub bolt.....	1911-27	15	1 00	8 00	03.	28B	12
2825B...	Hub bolt nut.....	1911-27	10	90	6 00	02.	29	24
2826...	Front hub bolt.....	1911-27	15	1 00	8 00	03.	27A	12
2827...	Hub flange.....	1911-27	1 75	15 00.		20.	233B	4

*Not subject to regular discount.
Above quantity prices as well as individual prices subject to wholesale trade discount.




Part No.	Name of Part	Year	Lots of 10 per lot	LIST PRICE Lots of 100 per lot	Lots of 1000 per lot	Each	Fac. No.	No. Req. per Car
----------	--------------	------	--------------------------	---	----------------------------	------	-------------	---------------------------

HUBS AND PARTS—Continued

2833...	Front hub bear. cup inner.....	1919-27		\$3 50.		\$0 50.	2955	2
2834...	Inside cone & roller assy.....	1919-27		9 00.		1 10.	205B	2
2836...	Front hub bearing cup—outer.....	1919-27		3 00		40.	2956	2
2837...	Outside cone and roller assy.—right thread.....	1919-27		6 00		75.	206B	1
2838...	Outside cone and roller assy.—left thread.....	1919-27		6 00		75.	207B	2
2841...	Front hub dust cap assy.....	1919-27		75	\$7 00 \$60 00	10.	350	2

RIM AND RIM CARRIER

2843...	Demountable rim only.....	1919-24		13 00.		1 50.	8774AR	4
*2845B...	Demountable rim only.....	1919-26		13 00.		1 50.	8774BR	4
2843C...	Demountable rim only.....	1922		13 00.		1 50.	8774CR	4
2843D...	Demountable rim only.....	1923		13 00.		1 50.	8774DR	4
2845E...	Demountable rim only—balloon.....	1926-27		13 00.		1 50.	8774E	
*2846B...	Demountable rim clamp.....	1919-24		50	4 00 32 50	10.	8831BR	16
*2846C...	Dem. rim clamp and nut assy.....	1922		1 30	12 00	15.	8807	16
*2846D...	Dem. rim clamp.....	1923		50	4 25	10.	8831FR	
2847...	Demountable rim bolt.....	1919-27		30	2 50 23 00	05.	8832A	16
*2848...	Dem. rim nut.....	1919-27		30	2 50 23 00	05.	8834B	16
*2848B...	Dem. rim nut.....	1919-25		30	2 50 23 00	35.	8834A	16
2849...	Spare rim carrier.....	1919-25				2 25.	8848C	1
2849B...	Spare rim carrier clamp bolt.....	1921-25				02.	7509B	1
†2849B2...	Spare rim carrier clamp bolt.....	1925-27				02.	7509CR	
*2849B3...	Spare rim carrier clamp bolt.....	1926-27				02.	7509D	
2849C...	Spare rim carrier clamp support and bolt assy.....	1921-24		13 50.		15.	7511AR	1
2849G...	Spare rim carrier clamp support and bolt assy.....	1924-25		12 00.		15.	7511BR	



‡Use with 2845 rim. †Use with 2845C rim. **Use with 2845D rim. *Attached clamp.
‡Square shoulder. ‡Round shoulder.
*Use with 2845B, 2845D and 2845E rim.


Above quantity prices as well as individual prices subject to wholesale trade discount.

Part No.	Name of Part	Year	LIST PRICE			Each	Fac. No.	No. Req. per Car
			Lots of 10	Lots of 100	Lots of 1000			
			per lot	per lot	per lot			

WHEELS—Continued

RIM AND RIM CARRIER—Continued

2849D...	Spare rim carrier clamp—Road.—Cp.	1921-25		\$7 50		\$0 10	.7312CR	1
2849E...	Spare rim carrier—balloon	1925				2 25	.8848ER	1
2849F...	Spare rim carrier clamp	1925-27	\$0 75	5 00		10	.7312D	1
2870...	Spare rim carrier bracket—R.	1919-22				50	.8824AR	1
2870B...	Spare rim carrier bracket—R.	1922-25				50	.8824BR	1
2870C...	Spare rim carrier bracket—R.	1925				50	.8824CR	1
2871...	Spare rim carrier bracket—L.	1919-22				50	.8825AR	1
2871B...	Spare rim carrier bracket—L.	1922-25				50	.8825BR	1
2871C...	Spare rim carrier bracket—L.	1925				50	.8825CR	1
2872...	Spare rim bracket and bolt assy.—Road.—Cp.	1926-27				1 50	.7317A	1
2872B...	Spare rim bracket and bolt assy.—T. C.—Tudor—Fordor	1926-27				2 75	.7333A	1
2873...	Spare rim carrier only—balloon	1926-27				1 25	.7336A	1
2874...	Spare rim carrier only—30" x 3 1/2"	1926-27				1 25	.7336BR	1
2875...	Spare rim carrier bolt	1926-27						3
2875B...	Spare rim carrier bolt	1926-27				10	.7339	1
2876...	Spare rim carrier bolt nut	1926-27				05	.7338	3
2877...	Demountable rim hinge pin	1926-27				05	.8646	1
2877B...	Demountable rim lock screw	1926-27				05	.179B	1



FRAME

2850...	Frame assembly	1909-25				13 00	.2916AR	1
2850B...	Frame assembly	1926-27				13 00	.2916B	1
2851B...	Side member—R.	1914-25				4 00	.2914AR	1
2851C...	Side member—R.	1926-27				4 00	.2914P	1
2852B...	Side member—L.	1914-25				4 00	.2915AR	1
2852C...	Side member—L.	1926-27				4 00	.2915B	1
2853...	Front cross member	1909-27	8 00	70 00		90	.303	1
2854B...	Rear cross member	1914-25				1 20	.2913AR	1
2854C...	Rear cross member	1926-27				2 00	.2913B	1
2855...	Front corner bracket—R.	1909-27				15	.305	1
2856...	Front corner bracket—L.	1909-27				15	.306	1
2857...	Rear corner bracket—R.	1909-25				15	.307AR	1
2857B...	Rear corner bracket—R.	1926-27				15	.307B	1
2858...	Rear corner bracket—L.	1909-25				15	.308AR	1
2858B...	Rear corner bracket—L.	1926-27				15	.308B	1
2859...	Front end spacer—L.	1909-25				10	.318B	1
2859B...	Front fender bracket to frame support—L.	1926-27				15	.318C	1
2860...	Front end spacer—R.	1909-25				10	.319B	1
2860B...	Front fender bracket to frame support—R.	1926-27				15	.319C	1
2863...	Body bracket	1909-27				10	.344	3


GASOLINE TANK

GASOLINE TANK

2900B...	Gas tank—Sedan	1916-25				6 00	.7950R	1
2900C...	Gasoline tank	1909-25				4 00	.1303B	1
2900D...	Gas tank—Road.—T. C.—Cp.—Tudor	1926-27				6 00	.45070	1
2901B...	Filling plug	1909-27	1 40	12 00		15	.1317	1
2902B...	Sediment bulb	1909-27				90	.2088	1
2902C...	Sediment bulb assy.—Road.—T. C.—Cp.—Tudor	1926-27				1 00	.2053	1

††For balloon rim carrier.

Above quantity prices as well as individual prices subject to wholesale trade discount.




Part No.	Name of Part	Year	LIST PRICE			Each	Fac. No.	No. Req. per Car
			Lots of 10	Lots of 100	Lots of 1000			
			per lot	per lot	per lot			

GASOLINE TANK—Continued

2903...	Filling plug gasket	1909-27				\$0 02	.1306	1
2904...	Sediment bulb flange	1909-27				25	.2051	1
2905...	Sediment bulb flange gasket	1909-27				03	.2094	1
2908...	Pet cock	1909-25						1
2908B...	Sediment bulb drain plug assy.—Road.—T. C.—Cp.—Tudor	1926-27						1
2909...	Feed pipe—39 1/4"	1909-26				25	.1364AR	1
*2909A2...	Feed pipe—Fordor—T. Comm.—T. T.	1926				25	.1364BR	1
*2909A3...	Feed pipe assy.—T. Comm.—T. T.—Fordor	1926-27				40	.1375	1
2909B...	Feed pipe—51"	1916-23	2 50			30	.7965AR	1
2909C...	Feed pipe—66 1/2"	1918-19				35	.9775R	1
2909D...	Feed pipe—56 1/2"	1919-25	2 75			35	.8690R	1
2909E...	Feed pipe—49 1/4"	1923-25				30	.7965BR	1
2909F...	Feed pipe—Road.—T. C.—Cp.—Tudor	1926				15	.1373AR	1
*2909F2...	Feed pipe—Road.—T. C.—Cp.—Tudor	1926				15	.1373BR	1
*2909F3...	Feed pipe assy.—Road.—T. C.—Cp.—Tudor	1926-27				30	.1358	1
2910...	Feed pipe pack nut	1909-26	40	\$3 00		05	.1374A	2
2911...	Feed pipe—78"	1915				60	.1394R	1
2913...	Feed pipe gasket	1909-26	15	1 00		02	.5892	1
2914...	Gas tank support—R.	1917-20	1 75			20	.2132AR	1
2914B...	Gas tank support—R.	1920-27	1 75			20	.2132B	1
2915...	Gas tank support—L.	1917-20	1 75			20	.2133AR	1
2915B...	Gas tank support—L.	1920-27	1 75			20	.2133B	1
2916...	Feed pipe clamp	1921-27		75		01	.2118	1
2917...	Gas tank pad—upper—Road.—T. C.—Cp.—Tudor	1926-27	40			05	.45147	1
2918...	Gas tank pad front—Road.—T. C.—Cp.—Tudor	1926-27				30	.45154	1
2919...	Gas tank support pad—Road.—T. C.—Cp.—Tudor	1926-27				10	.40190	2
2920...	Stop and pad assy.—Road.—T. C.—Cp.—Tudor	1926-27	80			75	.45153	2
2921...	Gas tank overflow pipe—Road.—T. C.—Cp.—Tudor	1926-27				25	.45117	1
2922...	Gas tank support and pad assy.	1926-27				50	.40158	1

*Used with vaporizer


Above quantity prices as well as individual prices subject to wholesale trade discount.




Part No.	Name of Part	Year	LIST PRICE Lots of 10 per lot	LIST PRICE Lots of 100 per lot	LIST PRICE Lots of 1000 per lot	Each	Fac. No.	No. Req. per Car
CYLINDER								
2990B...	Motor assembly—less starter	1909-27				\$100 00	532D...	1
2990C...	Motor assembly—with starter	1919-27				125 00	532E...	1
*2991...	Cylinder assembly—oversize	1909-27				45 00	449AR...	1
2991B...	Cylinder assembly—std.	1909-27				60 00	449B...	1
3000C...	Cylinder	1909-27				20 00	400D...	1
3001...	Cylinder head	1909-27				5 00	401C...	1
3002...	Cylinder head gasket	1909-27		\$24 00		25	402B...	15
3003...	Cylinder head cap screw	1909-17	\$0 30	2 50			05 484	
3003B...	Cylinder head cap screw	1918-27	25	2 00	\$17 00		05 483C2...	1
3004...	Cylinder head outlet conn.	1909-16					35 446CR...	1
3004B...	Cylinder head outlet con.	1917-25					35 8719AR...	1
3004E...	Cylinder head outlet conn.	1926-27					75 8719C...	1
3005...	Cylinder head outlet conn. gasket	1909-27	25	2 00			03 445B...	1
3006...	Cylinder head outlet hose	1909-27	1 35	12 50			15 448B...	1
3007...	Cylinder head outlet hose clip	1909-27	35	3 00			05 607B...	2
3008...	Cylinder head outlet conn. screw	1909-27	20	1 50	12 50		05 550C...	2
3008B...	Cylinder head outlet connection screw (nickel head)	1926-27					05 403	
3009B...	Cylinder front cover	1909-19				1 00	690BR...	1
3009C...	Cylinder front cover	1919-26	8 50			1 00	690C...	1
3009D...	Cylinder front cover	1926-27	8 50			1 00	690D...	1
3010...	Cylinder cover bolt and nut	1909-27	Order 4808 and 2515					
3011...	Cylinder cover cap screw	1909-27	20	1 50	10 00		03 432	3
3011B...	Cylinder cover to cylinder screw	1926-27		2 50			03 436	1
3012B...	Cylinder cover gasket	1909-27	45	4 00			05 504	2
3013...	Cylinder cover liner	1909-19	15	1 00	7 50		02 505B...	1
3013B...	Cylinder cover liner	1919-27	10	65	6 00		02 505C...	1
3014...	Cylinder cover and crank case bolt and nut	1909-27	Order 3362 and 2515					
3015...	Cylinder water inlet conn.	1909-27				30	442B...	1
3016...	Cylinder inlet conn. screw	1909-26	25	2 00	17 50		03 597R...	2

†Not subject to regular discount. *Supplied only when available at Branches.
Above quantity prices as well as individual prices subject to wholesale trade discount.

Part No.	Name of Part	Year	LIST PRICE Lots of 10 per lot	LIST PRICE Lots of 100 per lot	LIST PRICE Lots of 1000 per lot	Each	Fac. No.	No. Req. per Car
CYLINDER—Continued								
3016B...	Cylinder head inlet connection screw (nickel head)	1926-27				\$0 05	443	
3017...	Time gear cover	1919-27				90	1754B	1
†3017B...	Time gear cover	1919-21				90	1754AR	1
3017C...	Time gear cover gasket	1919-27		\$0 60	\$4 00	01	1775	1
3017D...	Time gear cover plate	1919-27	\$0 40			05	1773	1
3017E...	Time gear cover to C. C. screw	1919-27		2 00		03	830	1
3018...	Cylinder water inlet gasket	1909-27	20	1 50		03	596	1
3019B...	Cylinder water jacket plug	1914-27	10	50		02	5919	2


**PISTON AND CONNECTING ROD**

3021R...	Piston and pin (2 lbs.)	1909-27	11 00			1 25	4473H	
3021S...	Piston and pin—.0025" O. S. (2 lbs.)	1909-27	11 00			1 25	4473IR	
3021T...	Piston and pin—.005" O. S. (2 lbs.)	1909-27	11 00			1 25	4473JR	
3021U...	Piston and pin—.03125" O. S. (2 lbs.)	1909-27	11 00			1 25	4473KR	
3021V...	Piston and pin—.033" O. S. (2 lbs.)	1909-27	11 00			1 25	4473LR	
3021W...	Piston and pin—.010" O. S. (2 lbs.)	1909-27	11 00			1 25	4473MR	4
3022...	Piston pin	1909-27	2 50			30	419B	4
*3022½...	Piston pin bushing (pair)	1909-23	1 80	17 00		20	668AR	4
†3022C...	Piston pin bushing (pair)	1923-27	1 80	17 00		20	668B	4
3023...	Piston ring	1909-27	1 35	12 00		15	422C	12
3023B...	Piston ring .031" O. S.	1909-27	1 35	12 00		15	422ER	12
3023C...	Piston ring .010" O. S.	1909-27	1 35	12 00		15	422DR	12
3023D...	Piston ring .038" O. S.	1909-27	1 35	12 00		15	422FR	12
†3024...	CONNECTING ROD	1909-27	11 00			1 20	641B	4
*3024B...	Connecting rod	1909-25	11 00			1 20	641AR	4
3025...	Connecting rod cap bolt	1909-27	30	2 50	20 00	05	489B	8
3026...	Connecting rod cap bolt nut	1909-27	20	1 50	12 00	03	490	8
3029...	Connecting rod clamp screw	1909-27	25	2 00		03	578	4

**CRANK SHAFT AND CAM SHAFT**

3030...	CRANK SHAFT	1909-27				8 50	498B	1
3031...	C. S. rear bearing cap	1909-27	4 50			50	405AR	1
†3031B...	C. S. rear bearing cap	1909-27	4 50			50	405AR	1
3032...	C. S. front bearing cap	1909-27	3 50			40	406B	1
†3032B...	C. S. front bearing cap	1909-27	3 50			40	406B	1
3033...	C. S. center bearing cap	1909-27	3 50			40	407B	1
†3033B...	C. S. center bearing cap	1909-27	3 50			40	407B	1
3034...	C. S. bearing bolt—center and front	1909-27	90	7 50		10	408	4
3035...	C. S. bearing bolt nut	1909-27						

†Connecting rods of present design requiring new bearings will be exchanged by dealers at 60c each.
**Special rod for crankshafts worn .025" undersize. *O. D. .934". †O. D. .872".
†Rough Babbitted. †Used with 3000C cylinder on cars not equipped with starter.
Above quantity prices as well as individual prices subject to wholesale trade discount.



Part No.	Name of Part	Year	Lots of 10 per lot	LIST PRICE Lots of 100 per lot	Lots of 1000 per lot	Each	Fac. No.	No. Req. per Car
----------	--------------	------	--------------------	-----------------------------------	----------------------	------	----------	------------------

MOTOR—Continued

CRANK SHAFT AND CAM SHAFT—Continued

CAM SHAFT—Continued							
3036	C. S. rear bearing bolt	1909-27	\$0 90	\$7 50	\$0 10	478	2
3038	C. S. bearing liner—center and front	1909-27	05	30	\$2 00	01	502B..... 8
3039	C. S. rear bearing liner	1909-27	05	30	2 00	01	503B..... 1
3040	C. S. starting pin	1909-20	30	2 00		05	529BR..... 1
3040B	C. S. starting pin	1920-27	20	1 50		03	529C..... 1
3041	CAM SHAFT	1909-27				3 00	410..... 1
3042	Cam shaft front bearing	1909-24	3 00			40	411AR..... 1
3042B	Cam shaft front bearing	1924-27	3 00			40	411B..... 1
3043	Cam shaft center bearing	1909-27	3 00			40	412B..... 1
3044	Cam shaft rear bearing	1909-27	1 25			15	413..... 1
3045	Cam shaft bearing ring	1909-27	15	1 00	7 50	03	534..... 2
3046	Camshaft bearing set screw	1909-27	35	3 00	25 00	05	414..... 2
3047B	Time gear—large	1909-27	6 50			75	415B..... 1
3048B	Time gear—small	1909-27	5 50			60	416B..... 1
3049	Cam shaft gear dowel pin	1909-27	20	1 50		03	417..... 2
3050B	Cam shaft gear lock nut	1909-27	1 25	11 00		15	4453..... 1
3051	Small time gear key	1909-27	20	1 50	12 00	03	477..... 1

VALVES, PUSH RODS, EXHAUST AND INLET MANIFOLDS

3052	Valve	1909-27	1 35	11 00		15	424B	8	
3052B	Valve— $\frac{1}{2}$ " O. S. stem	1909-27	1 35	11 00		15	424AR	8	
3053 $\frac{1}{2}$	Valve bushing	1909-27				25	428	8	
3054	Valve spring	1909-27				05	431	8	
3056	Valve spring seat	1909-27	40	3 50	30 00	set of 8	05	425	8
3057	Valve spring seat pin	1909-27		25	2 00		05	429	8
3058	Push rod	1909-27	1 20	10 00			15	426B	8
3058B	Push rod— $\frac{1}{2}$ " O. S. stem	1909-27	1 20	10 00			15	426AR	8
3059 $\frac{1}{2}$	Push rod bushing	1909-27					25	427	8
3060B	Exhaust manifold	1913-26					1 25	4483AR	1
3061	Exhaust pipe pack nut	1909-27	1 80	17 00			20	518	1
3062	Inlet pipe	1909-26					1 00	512BR	1
3063	Inlet and exh. pipe gasket	1909-27	10	80			02	513	6
3064	Inlet and exh. pipe gland	1909-27		75	6 00		01	514	6
3065	Inlet and exh. pipe clamp	1909-27					10	515	4
3066B	Inlet and exh. clamp stud nut	1909-27	20	1 25	7 50		03	517	4
*3066C1	Inlet and exhaust clamp stud— $2\frac{3}{8}$ "	1924-26	30	2 50			05	516BR	4
3066C2	Inlet and exhaust manifold clamp stud (nickel head)	1926-27					05	4482	
3068	Breather pipe	1909-27	80	6 00			10	4468	1


CRANK CASE AND CYLINDER VALVE COVER

3069B	C. C. front end support	1911-17				1 00	801CR	1
3069C	C. C. front end support	1917-24				75	801DR	1
3069D	C. C. front end support	1924-27	5 00			75	801E	1
3070B	C. C. & cyl. gasket—L	1909-27		2 25		03	886	1
3071B	C. C. & cyl. gasket—R	1909-27		2 25		03	887	1
3072	C. C. & cyl. cover cap screw	1909-27	20	1 50	10 00	03	1388	2
3073	C. C. arm bolt—side	1909-27	30	2 50	22 50	05	479	2
3074	C. C. arm bolt—top	1909-27	20	1 75	15 00	03	940	2
3074B	C. C. arm bolt nut	1909-27						
3074C	C. C. arm bolt—top (Truck)	1918-27	Order 2515					
3075C	C. C. front bearing and spring clip	1921-27		2 50		03	TT940	2
assy.						90	2921C	

*When used to replace stud $3\frac{1}{8}$ " long also use new style 3065 clamp, reversing clamp.

†Replaces 3075B.

Above quantity prices as well as individual prices subject to wholesale trade discount.



Part No.	Name of Part	Year	Lots of 10 per lot	LIST PRICE Lots of 100 per lot	Lots of 1000 per lot	Each	Fac. No.	No. Req. per Car
----------	--------------	------	--------------------	-----------------------------------	----------------------	------	----------	------------------

CRANK CASE AND CYLINDER VALVE COVER—Continued

3076C	C. C. front bearing and spring clip nut	1921-27						
†3076B2	C. C. frt. bearing and spring clip	1921-27						
3077	C. C. front bearing cap	1909-27	\$1 25			\$0 70	320D	1
3078	C. C. front bearing screw	1909-21	40	\$3 50		15	321	1
3078B	C. C. front bearing screw	1921-27				05	322	2
3078C	C. C. front bearing lock washer	1921-27						
3079	C. C. oil cock	1909-27	1 35	12 00		01	5636	2
3080	C. C. drain cup plug	1909-27				15	1515	2
3080B	C. C. drain cup plug gasket	1909-27		1 50	10 00			
3081	C. C. oil tube	1909-27	1 50			02	4339	1
3083	C. C. arm block	1909-27				20	543B	1
3084	Engine pan—right	1909-27	2 50			05	890	2
3085	Engine pan—left	1909-27	2 50			30	1330	1
3088B	Engine pan and hood board bolt	1909-27	15	1 20	10 00	03	4074	1
3088C	Engine pan and hood board bolt	1909-27	15	1 20	10 00	03	4073	2
3088D	Engine pan and hood board bolt—Truck	1918-27	20	1 50		03	TT4073	2

††Replaces 3076B. When ordered to replace 1909-20 C. C. front frame bearing also order 2-3008, 2-3076C, 2-3078C, 1-3664, 1-3810, 2-753 cotter.


Above quantity prices as well as individual prices subject to wholesale trade discount.

Part No.	Name of Part	Year	LIST PRICE			Each	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			

MOTOR—Continued

CRANK CASE AND CYLINDER VALVE COVER—Continued

3088E	Engine pan and hood board bolt nut	1909-27	\$0 07	\$0 60	\$5 00	\$0 01	1309	1
3100	CRANK CASE	1912-25				11 00	1526E	1
3101	Crank case lower cover	1912-24				35	1582AR	1
3102	Crank case lower cover reinforcement	1912-24				25	4378AR	1
3103	C. C. lower cover	1924-27				35	4379AR	1
3104	C. C. lower cover reinforcement	1924-27				25	1582B	1
3105	C. C. lower cover gasket	1912-24	70	6 00		10	4378B	1
3106	C. C. lower cover gasket	1924-27	85	7 50		10	1586AR	1
3107	C. C. lower cover screw	1912-27	15	1 00	6 00	02	4328	17
3108	Cylinder valve cover	1912-21				15	656AR	1
3109	Cylinder valve cover	1921-26	1 75	15 00		20	656PR	2
3110	Cylinder valve cover	1926-27	1 75	15 00		20	656C	2
3111	Cyl. valve cover gasket	1912-21		2 00		05	660AR	1
3112	Cyl. valve cover gasket	1921-27		3 50		05	660B	2
3113	Cyl. valve cover screw	1912-27	25	2 60		03	654	1
3114	C. C. arm with rivets	1909-27	2 50	2 60		30	815B	2
3115	C. C. arm rivet	1909-27				05	312	1
3116	Brace (crankcase arm support to transmission cover)—R	1926-27				10	786	1
3117	Brace (crankcase arm support to transmission cover)—L	1926-27				19	787	1
3118	C. C. flange reinforcement—R	1924-27				10	824	1
3119	C. C. flange reinforcement—L	1924-27				10	825	1



COMMUTATOR


3162	Com. case support bolt	1912-19				05	4441	1
3162B	Com. case support bolt	1919-27				05	4756	1
3163	Com. case spring	1912-27				05	689	1
3165	Com. brush only	1912-27	1 50	13 50		20	4481	1
3176C	Com. oiler	1919-27	40	2 50		05	480C	1
3177	Com. felt ring	1912-27	15	1 00		02	5930	1
3206	Com. brush cap	1909-27	15	1 00		02	468B	1
3207	Com. brush cap pin	1909-27		50		01	466	1
3210	Com. contact point nut	1910-27		50		01	472B	8
3220	Com. lock nut	1909-27	25	2 60		03	471	1
3221	Com. case with fibre	1912-27	5 50			60	5908	1
3222	Com. shield	1912-27	15	1 25		02	5923	1

MAGNETO AND FLY WHEEL

3250D	Magneto coil assembly	1915-27				6 00	5941B	1
3252	Magneto spool support screw	1909-27				03	537B	16
3254	Magnet bolt	1909-27	25	2 00	15 00	01	624	10
3255	Magnet bolt washer	1911-27		50		05	555C	16
3257	Magneto support	1909-27	25	2 00		29	1545AR	1
3260	Magneto contact assy.	1909-25				39	1545B	1
3260B	Magneto contact assy.	1926-27	2 00			01	1508	2
3261B	Magneto contact nut	1909-27		50		01	1565	1
3261C	Magneto contact screw washer	1909-27		50		15	1510R	1
3263	Magneto contact spacer	1909-25				01	1565	1
3266	Magneto contact fibre screw	1909-27		50		03	4382	1
3267	Magneto primary insulating block	1915-27				05	1503BR	1
3267B	Magneto contact insulator	1919-25	45	4 25		03	8611	1
3267C	Magneto contact insulator shell	1919-25				90	1885	1
3268	Fly wheel ring gear	1919-27	8 00					
3269	Fly wheel	1911-19						
3269C	Fly wheel	1919-27						
3269H	Fly wheel with ring gear and magnets assembled	1919-27				5 00	701C	1
3270	Fly wheel cap screw	1909-27	80	7 00		15 00	5946B	1
3271	Flywheel dowel pin	1909-27	45	4 25		10	721	4
3272B	Mag. coil support steel shim—small (.025" thick)	1909-27				05	722	2
				75		01	584B	4

*Same as S-303. When used to replace 3260 also purchase 3263.

Above quantity prices as well as individual prices subject to wholesale trade discount.




Part No.	Name of Part	Year	LIST PRICE			Each	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			
3274	Mag. coil support paper shim—large	1909-27		\$0 50		\$0 01	589	1
3275	Mag. coil support paper shim—small	1909-27		25		01	4487	1
3276B	Magnets (16)	1915-27			set	4 00	5933	16
3277	Magnet clamp	1911-27	\$0 20	1 60		03	623	16
3278	Magnet clamp screw	1911-27		1 50	\$14 00	02	625	16
3279	Magneto contact washer	1909-27		75		01	560	1

TRANSMISSION

3300B	Transmission assy.	1919-25				33 00	744C	1
3300C	Transmission assy.	1926-27				30 00	744D	1
3301	Trans. reverse plate assy.	1909-27	22 50			2 40	747	1
3304	Trans. reverse gear bushing	1909-27	3 50			40	705	1
3305	Trans. reverse and S. S. rivet	1909-27			doz.	05	708	8
3306	Trans. slow speed plate assy.	1909-27	22 00			2 30	748	1
3309	Trans. slow speed gear bushing	1909-27	2 50			30	745	1
3310	Trans. brake drum rivet	1909-27			doz.	05	711	8
3311	Trans. brake drum assy.	1909-25	24 00			2 60	750AR	1
3311B	Trans. brake drum assy.	1926-27				3 00	750B	1
3312	Trans. brake drum lug shoe	1926-27				05	754	6
3313	Trans. triple gear assy.	1909-27	13 00			1 40	751B	3
3314	Trans. triple gear flanged bushing	1911-27	1 80			20	716B	3
3315	Trans. triple gear shaft	1909-27				15	715AR	3
3317	Trans. driven gear	1909-27	6 00			70	713	1
3318	Trans. driven gear key	1909-27		2 50		03	714	2
3320C	Trans. driven gear sleeve bushing	1909-27	1 50			20	712	2
3320D	Driven gear sleeve washer	1909-27	40	3 50		05	776	3
3321	Trans. driving plate assy.	1909-25	30 00			3 25	749AR	1
3321B	Trans. driving plate assy.	1926-27	30 00			3 25	749B	1
3323	Trans. driving plate screw	1909-25			Order 3371			
3323B	Trans. driving plate screw	1926-27				05	742	6
3324B	Trans. driving plate sleeve plug	1909-27				01	775	1
3325	Trans. driving plate rivet	1909-27			doz.	05	736	8
*3327B	Trans. driving plate bushing	1909-27				15	772	1
3328	Trans. clutch disc—small	1909-27	90	7 50		10	727	12

*When using short bushing in making repairs remove driving plate key.

Above quantity prices as well as individual prices subject to wholesale trade discount.



Part No.	Name of Part	Year	LIST PRICE			Each	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			
TRANSMISSION—Continued								
3329	Trans. clutch disc—large	1909-27	\$0 90	\$7 50		\$0 10	728B	13
3331	Trans. gear shaft	1909-27				1 25	723B	1
3332	Trans. clutch disc drum	1909-27				1 10	725B	1
3333	Trans. clutch disc drum key	1909-27	45	3 50		05	726B	1
3334	Trans. clutch disc drum set screw	1909-27	85	7 00		10	752	1
3336	Trans. clutch push ring	1909-27	3 00			35	770	1
3337 1/2	Trans. clutch finger screw	1909-25	40	3 00		05	756AR	3
3337B	Trans. clutch finger and screw	1909-25				20	765AR	3
3337D	Clutch finger and screw	1926-27				20	765B	3
3337E	Clutch finger screw	1926-27	40	3 00		05	756B	3
3338	Trans. clutch finger pin	1909-25				01	735AR	3
3338B	Clutch finger pin	1926-27				01	735B	3
3340	Trans. clutch spring	1909-27				25	737	1
3341	Trans. clutch spring support	1909-27				10	738	1
3342	Trans. clutch spring thrust ring pin	1909-27	25	1 50		03	739	1
3344	Trans. clutch shift	1909-27				50	733	1


TRANSMISSION COVER

3362	Trans. cover bolt	1909-27	25	2 00	\$15 00	03	79	
3362B	Trans. cover bolt nut	1909-27	Order 2515					
3363	Trans. cover gasket (front)	1909-27	30	2 50		05	872B	
3367	Trans. cover door screw	1909-27	15	1 00	7 50	02	430	6
3368	Universal ball cap (rear)	1909-27				30	813	1
3369	Universal ball cap (front)	1909-27	7 50			80	819D	1
3371	Universal ball cap screw	1909-27	30	2 50	18 00	05	731	2
3372	Universal ball cap bolt and nut	1909-27	Order 3362 and 2515					
3375	Trans. cover screw	1909-27	Order 3072					
3376B	TRANS. COVER	1919-25				7 00	826ER	1
3376C	Trans. cover	1926-27				7 00	826F	1
3377B	Trans. cover gasket	1909-27	70	6 00		10	885B	1
3378	Trans. cover door	1911-27				15	1546D	1
3379B	Trans. cover door gasket	1911-27	35	3 00		05	1547C	1
3380	Starter drive cover	1919-27				15	1763	1
3381	Starter drive cover gasket	1919-27	20	1 50		03	1764	1
3382	Trans. cover rear plate	1919-27	30			05	1761	1
3383	Trans. cover front plate	1919-27	40			05	1758	1
3384	Trans. cover to cylinder screw	1926-27				05	793	1
3385	Trans. cover to cylinder shim—.025" thick	1926-27		50		01	827	1
3386	Trans. cover to cylinder shim—.015" thick	1926-27		50		01	829	1


TRANSMISSION CONTROL**CLUTCH RELEASE**

3400	Trans. clutch release ring	1909-27				20	741	1
3402D	Clutch lever and shaft	1913-27				30	1548	

*When ordered to replace cover on cars below 2,044,100 also order 3402D clutch lever and shaft.
Above quantity prices as well as individual prices subject to wholesale trade discount.




Part No.	Name of Part	Year	LIST PRICE			Each	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			
3403	Clutch lever screw	1909-27						
3403B	Clutch lever screw nut	1909-27						
3405	Clutch lever pin	1909-27						
3406B	Clutch release fork—R. or L.	1913-27						
3406C	Clutch release fork pin	1913-27						
3411	Clutch lever clevis pin	1909-27						

**TRANSMISSION BANDS**

3413B	Trans. band assy. (detach.)	1909-26	\$5 50			60	838B	2
3413C	Trans. brake band assy.	1926-27	8 00			90	861	1
3414C	Trans. band ear—detachable	1926-27				15	850B	3
3415	Trans. band washer	1909-27	15	1 25		03	840	2
3416	Trans. band lining	1909-27	1 80	17 00		25	1562A	3
3416B	Trans. band lining—set of 3 including rivets—in carton	1909-25	7 50	70 00		90	1564AR	1
3416C	Trans. brake band lining	1926-27	3 00	27 50		35	857	1
3416D	Trans. band lining—set of 3 including rivets—in carton	1926-27	8 50	80 00		1 00	1564B	1
3419	Trans. band adj. screw	1909-25	1 25	10 00		15	1533AR	1
*3419B	Trans. band adj. screw	1926-27	1 25	10 00		15	1533B	1
3420	Trans. band adj. screw nut	1909-27	30	2 50		05	1532	1
3421B	Trans. band ear iron rivet	1909-27			\$2 00	dz. 05	843	9
3421C	Trans. band ear iron rivet	1926-27			2 00	dz. 05	846	6
3422B	Trans. band brass rivet	1909-17			3 60	dz. 05	844B	6
3423B	Trans. band brass rivet	1909-27			2 50	dz. 05	845B	24
3425	Trans. band spring	1909-27	15	1 25		03	841B	3
3426	Trans. band adj. nut	1909-27	25	2 00		05	851	2

*Used with detachable ear band.
Above quantity prices as well as individual prices subject to wholesale trade discount.



Part No.	Name of Part	Year	Lots of 10 per lot	LIST PRICE Lots of 100 per lot	Lots of 1000 per lot	Each	Fac. No.	No. Req. per Car
----------	--------------	------	--------------------	-----------------------------------	----------------------	------	----------	------------------


TRANSMISSION CONTROL—Continued

PEDALS AND CONTROLLER SHAFT

3427...	Slow speed shaft	1909-25				\$0 15..	848BR...	1
*3427B...	Slow speed shaft	1926-27				15..	848C...	1
3428...	Slow speed notch	1909-27				25..	4327...	1
3429...	Slow speed notch pin	1909-27		\$0 60		01..	1560...	1
3432...	Speed lever	1909-27				10..	862B...	1
3434...	Reverse pedal	1909-25				50..	4324...	1
3435...	Brake and reverse pedal shaft	1909-27				15..	849B...	2
3436...	Brake and reverse pedal support	1909-27				15..	4325...	2
3437...	Brake and reverse support bolt	1909-25	\$0 30	2 50		05..	1534...	2
3437B...	Brake and reverse support bolt nut	1909-27	Order 2515					
3437C...	Brake and reverse pedal support bolt	1926-27				05..	1549...	1
3439...	Brake pedal	1909-25				50..	4323AR...	1
3439B...	Brake pedal	1926-27				65..	4323B...	1
3440...	Clutch pedal	1909-25				50..	854BR...	1
3440B...	Clutch pedal	1926-27				65..	854C...	1
3441...	Pedal pin	1909-27	Order 3405					
3442...	Clutch pedal support	1909-27				15..	4326...	1
3443...	Clutch pedal support bolt	1909-27	25	2 00		05..	1536...	1
3443B...	Clutch pedal support bolt nut	1909-27	Order 2515					
3445...	Slow speed connection	1909-27	40	3 50		05..	1540...	1
3446...	Slow speed con. lock nut	1909-27	Order 2503F					
3447...	Slow speed con. clevis	1909-27	60	5 00		10..	802...	1
3448...	Controller quadrant	1909-27	1 50			20..	309B...	1
3449...	Con. shaft with speed lever	1909-27				60..	1557...	1
3450...	Controller shaft bracket	1909-27				15..	311...	2
3452...	Controller shaft bracket bolt	1909-27	25	2 00	17 50	03..	315...	4
3452B...	Controller shaft bracket bolt nut	1909-27	15	1 25	9 00	02..	316...	4

HAND BRAKE

3455...	Hand brake lever	1909-25				1 00..	1550...	1
3456B...	Hand brake lever pin	1909-27	Order 2574					
3458...	Hand brake lever pawl	1909-27				05..	875...	1
3459...	Hand brake lever pawl pin	1909-27		50		01..	876...	1
3460...	Hand brake lever pawl rod	1909-27				10..	877...	1
3462...	Hand brake lever pawl lift assembly	1909-27				10..	4363...	1



3463...	Hand brake lever pawl lift spring	1909-27				02..	888...	1
3465...	Hub brake lever	1909-27				15..	864...	1
3466...	Hub brake lever pin	1909-27	Order 3405					
3467...	Hub brake lever clevis	1909-27	Order 3447					


*Used with detachable ear band.

Above quantity prices as well as individual prices subject to wholesale trade discount.

Part No.	Name of Part	Year	Lots of 10 per lot	LIST PRICE Lots of 100 per lot	Lots of 1000 per lot	Each	Fac. No.	No. Req. per Car
----------	--------------	------	--------------------	-----------------------------------	----------------------	------	----------	------------------

HAND BRAKE—Continued


3468...	Hub brake pull rod—R	1909-25		\$2 50		\$0 30..	891BR...	1
3468C...	Brake rod assembly—R & L	1926-27				30..	891C...	2
3469...	Hub brake pull rod—L	1909-25	2 50			30..	1513BR...	1
3470...	Brake rod support—R	1909-27	60	\$5 00		10..	1367C...	1
3471...	Brake rod support—L	1909-27	60	\$5 00		10..	1398C...	1
3472...	Brake rod support bolt	1909-27		75	\$5 00	01..	1308...	2
3472B...	Brake rod support bolt nut	1909-27	Order 3088E					



STEERING GEAR

STEERING GEAR AND GEAR CASE

*3500E2..	Steering gear assy. (less wheel and bracket) 5 to 1.....	1909-27.....				7 00..	5042C.....	1		
3501C...	Steering gear rim (17").....	1920-27.....				1 65..	901C.....	1		
3502...	St. gear rim screw.....	1909-27.....			65	01..	6849.....	4		
3503D...	St. gear spider (17").....	1920-27.....				60..	902C.....	1		
3503F...	St. gear spider and rim (17").....	1926-27.....				2 25..	995B.....	1		
3504...	St. gear cover.....	1909-27.....				30..	5039.....	1		
3505...	St. gear cover screw.....	1909-27.....			50	01..	910.....	1		
3506...	St. gear cover bushing.....	1909-27.....				15..	914.....	1		
3506B...	St. gr. driv. pinion washer.....	1909-27.....				05..	5026.....	1		
3507...	St. gr. int. gear case and bushing.....	1909-27.....				1 25..	5036.....	1		
3509...	St. gear quadrant.....	1909-27.....				15..	906B.....	1		
3510...	St. gear quadrant rivet.....	1909-27.....				01..	5041A.....	2		
3511...	St. gear wheel nut.....	1909-27.....			80	7 00	10..	913.....	1	
3512C...	St. gear tubing assy.....	1912-27.....				4 00..	5016.....	1		
3513C...	St. tubing flange bolt.....	1913-27.....			Order 4805B					
3514...	St. tub. flange screw nut.....	1913-27.....			10	65	4 00	02..	926.....	4
3515...	St. gear to dash cover—Road.—T.C.—									
	Cp.—Tudor.....	1926-27.....						10..	40161.....	1



3515B...	St. gear to dash cover—Fordor	1926-27				20 54084	
3516C...	St. gear post	1912-21				1 75	5043AR
3516D...	St. gear post	1921-25				1 75	5043B
3516E...	St. gear post (5 to 1)	1926-27				1 75	5043C

*When used on cars equipped with carburetor add 3531


Above quantity prices as well as individual prices subject to wholesale trade discount.

Part No.	Name of Part	Year	LIST PRICE			Each	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			

STEERING GEAR—Continued


STEERING GEAR TUBING AND POST

3517...	St. gear pinion.....	1909-25				\$0 15.	916AR	3
3517B...	St. gear pinion (5 to 1).....	1926-27				15.	916B	
3518...	St. gear pinion pin—short.....	1909-27				02.	917	2
3518B...	St. gear pinion pin—long.....	1921-27				02.	918	1
3519...	St. gear drive pinion.....	1909-25				30.	911	1
3519B...	St. gear drive pinion assy. (5 to 1).....	1926-27				45.	915	
3520...	St. gear drive pinion key.....	1909-27	\$0 20	\$1 00.		03.	909	1
3523...	St. gear post castle nut.....	1909-27	Order 2551B					



STEERING GEAR THROTTLE AND SPARK RODS

3524E...	Throttle rod.....	1912-27				30.	5038	1
3525E...	Spark rod.....	1912-27				30.	5037	1
3527...	Spark and throttle rod spring.....	1909-27	15	1 00.		02.	935	2
3528...	Spark and throttle rod collar.....	1909-27	15	1 00.		02.	936	5
3529...	Spark and throttle rod pin.....	1909-27		50.		01.	937	2
3530...	Spark rod lever.....	1909-27	80	6 00.		10.	946	1
3531...	Throttle rod lever.....	1909-26	80	6 00.		10.	947AR	1
3531B...	Throttle rod lever (vaporizer).....	1926-27	80	6 00.		10.	947B	1
3532...	Spark and throttle rod guide.....	1909-27				05.	938	1
3534B...	Commutator pull rod.....	1912-25	75			10.	2082AR	1
3534C...	Commutator pull rod.....	1926				10.	2082B	1
3535...	Carburetor pull rod.....	1909-25	75	6 00.		10.	1329AR	1
3535B...	Carb. pull rod—Road—T.C.—Cp.—Tudor.....	1926	70	6 00.		10.	1329CR	1
3535C...	Carb. pull rod—Fordor—Chassis.....	1926	70	6 00.		10.	1332R	1



STEERING GEAR BRACKET

3539B...	St. brkt. with bushing.....	1911-25	6 00.			75.	996AR	1
3539C...	St. brkt. with bushing—truck.....	1918-27	6 00.			75	TT996	1
3539D...	Steering gear bracket assy.—Road—T.C.—Cp.—Tudor.....	1926-27				75.	996B	1
3539E...	Steering gear bracket assy.—Fordor—Chassis.....	1926-27				75.	997	1
3540...	Brkt. bolt and nut—long.....	1909-27	Order 3073 and 2515					
3541...	Brkt. bolt and nut—short.....	1911-27	Order 3074 and 2515					
3544...	St. brkt. felt washer.....	1909-27	15	1 00.		02.	943R	1
3545...	St. brkt. bushing.....	1909-21				20.	944-5027	1
3545B1...	St. brkt. bushing.....	1921-25				10.	944AR	1
3545B2...	Steering bracket bushing.....	1926-27				10.	944B	1
3546...	St. brkt. block.....	1909-25				10.	945AR	1
3546B...	St. brkt. block—Truck.....	1918-27				10.	TT945	1
3546C...	Steering gear bracket block.....	1926-27				10.	4635	1
3546C2...	Steering gear bracket block.....	1926-27				10.	945B	1
3547...	St. gear ball arm.....	1909-27				40.	929C	1
3548...	St. gear ball arm key.....	1909-27	20	1 50	\$12 00	03.	930	1
3549...	Sr. brkt. dust cap—Truck.....	1918-27				05	TT5044	1

Part No.	Name of Part	Year	LIST PRICE			Each	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			

BODY PARTS

BODY BRACKETS


3601B...	Body bracket on body.....	1910-25				\$0 10.	1624R	6
3601C...	Body bracket—front—R.....	1921-25				20.	7267BR	1
3601D...	Body bracket—front—L.....	1921-25				20.	7268BR	1
3601E...	Body bracket—rear.....	1913-25				05.	5650R	2
3601F...	Body bracket—rear—R.....	1921-25				20.	7137C	1
3601G...	Body bracket—rear—L.....	1921-25				20.	8001B	1
3602E...	Body bracket con. bolt.....	1916-25				03.	2431	6
3602F...	Body bracket con. bolt nut.....	1916-25	\$2 00.					
			Order 2719					

FLOOR BOARDS

3624E...	Front floor rubber mat.....	1915-24	\$8 50.			90.	7299AR	1
3624F...	Front floor rubber mat.....	1924-25	8 50.			90.	7299BR	1
3624G...	Front floor mat and weatherstrip assy.....	1926-27				1 50.	45592	1
3626C...	Rear floor rubber mat.....	1911-25				60.	1606CR	1
3626C1...	Floor board with plate (first).....	1915-25				50.	4200AR	1
3626C2...	Floor board and plate assy. No. 1.....	1915-25				50.	4200BR	1
3627C1...	Floor board with plate (second).....	1915-25				50.	4201AR	1
3627C2...	Floor board and plate assy. No. 2.....	1915-25				50.	4201BR	1
3628B...	Floor board with plate (third).....	1915-25				65.	7104R	1
3630...	Floor board forward plate for pedals.....	1909-25				10.	1400C	1
3632...	Floor board rear plate for pedals.....	1909-25				10.	1095C	1
3633...	Floor board plate for side lever.....	1909-25				05.	1094B	1

DASH

3634H...	Dash—steel.....	1917-23				3 00.	8754BR	1
3634J...	Dash—steel.....	1923-25				3 00.	8754C	1
3634L...	Dash—chassis.....	1926-27				3 50.	40007	1
3638B...	Dash shield.....	1919-22				25.	5432B	2
3639...	Dash weatherstrip—side.....	1917-22				05.	8747R	1
3640C...	Dash bracket—left.....	1917-22				20.	8722AR	1
3640D...	Dash bracket—left.....	1923-27	1 25.			15.	8722B	1
3641C...	Dash bracket—right.....	1917-22				20.	8721AR	1
3641D...	Dash bracket—right.....	1923-27	1 25.			15.	8721B	1
3642B...	Dash bracket to dash bolt.....	1917-22	25	1 50	\$10 00	03.	8740R	4
3642C...	Dash bracket to dash nut.....	1917-22	Order 3514					
3643C...	Dash to body bracket bolt.....	1915-25	15	1 00.		03.	4248	2
3643C...	Dash to body bracket nut.....	1915-25	Order 4805C					
3644...	Dash to body gasket.....	1918-25	35	2 50.		05.	8769	1



LICENSE BRACKETS

3660C...	Lamp and license brkt. assy.....	1915-21	2 00.			25.	7506AR	1
3660D...	Lamp and license brkt. assy.....	1915-21	2 00.			25.	7505	1
3662...	Oil tail lamp and license brkt. assy.—Road—Pick-up.....	1926				45.	8923R	1
3662B...	Oil tail lamp and license brkt. assy.—T.C.....	1923-26				75.	7506CR	1

†Used with engine having wide pedals.

††When used on 1911-16 cars redrill frame. *Used with steel dash.

‡Used on Touring Car and Roadster without starter and demountable rims.

Above quantity prices as well as individual prices subject to wholesale trade discount.


Above quantity prices as well as individual prices subject to wholesale trade discount.

Part No.	Name of Part	Year	LIST PRICE			Each	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			

BODY PARTS—Continued

LICENSE BRACKETS—Continued

3662C...	Tail lamp and license brkt. support	1926				\$0 15.	8767D	1
3662D...	Oil tail lamp and license brkt. sup.	1923-26				30.	8767ER	1
3664...	Front license bracket	1921-27				15.	493	1
**3664B...	Front license bracket	1926-27				15	TT493	1
††3665...	Front license clip	1926-27				05.	6516	1
3666...	Front license clip bolt	1926-27				01.	4691	1
3667...	Front license clip bolt nut	1909-27				01.	2908	1
3668...	Front license clip bolt washer					\$0 75		
			Order 4868.					



SPRINGS


FRONT SPRING

3800...	Front spring—seven-leaf	1909-25				2 25.	332AR	1
3800B...	Front spring—eight-leaf	1926-27				2 25.	332B	1
†3801...	First leaf (main leaf)	1909-25	\$ 5 50.			60.	2943AR	1
†3801B...	First leaf (main leaf)	1926-27	5 50.			60.	2943B	1
†3802B...	Second leaf	1909-25	4 00.			45.	2935AR	1
†3802C...	Second leaf	1926-27	4 00.			45.	2935B	1
†3803B...	Third leaf	1916-25	3 00.			35.	2936AR	1
†3803C...	Third leaf	1926-27	3 00.			35.	2936B	1
†3804B...	Fourth leaf	1916-25	2 50.			30.	2937AR	1
†3804C...	Fourth leaf	1926-27	2 50.			30.	2937B	1
†3805B...	Fifth leaf	1916-25	2 00.			25.	2938AR	1
†3805C...	Fifth leaf	1926-27	2 00.			25.	2938B	1
†3806B...	Sixth leaf	1916-25	1 50.			20.	2939AR	1
†3806C...	Sixth leaf	1926-27	1 50.			20.	2939B	1
†3807B...	Seventh leaf	1916-25	1 25.			15.	2947AR	1
†3807C...	Seventh leaf	1926-27	1 25.			15.	2947B	1
†3807D...	Eighth leaf	1926-27	1 20.			15.	2949	1
3808...	Front spring clip	1909-20				20.	325C	2
3809...	Front spring clip nut	1909-20		\$2 50	20 00	03	119	
3809B...	Front spring clip nut	1921-27	40	3 00	25 00	05	120	
3810...	Front spring clip bar	1921-27	2 30			25.	342	1
†3811...	Front spring tie bolt	1909-25	20	1 50	14 00	04.	1362AR	1
†3811C...	Front spring tie bolt	1926-27	20	1 50.		05.	1362B	1
3811B...	Front spring tie bolt nut	1909-27	15	1 00.		02.	1363	1
3813B...	Front spring hanger	1909-27	1 75	15 00.		20.	246C	2
3814...	Front spring hanger bar	1909-27	40	3 00.		05.	7648	2
3815...	Spring hanger nut	1909-27						
3818...	Front spring perch—right	1909-19				80.	274AR	1
3818B...	Front spring perch—right	1909-27	4 00.			50.	274B	1
3819...	Front spring perch—left	1909-19				80.	275AR	1
3819B...	Front spring perch—left	1919-27	4 00.			50.	275B	1
3820...	Front spring perch bush	1909-27	25	2 00	15 00	05.	230	4
3821...	Front spring perch nut	1909-21						
3821B...	Front spring perch nut	1921-27	45	4 00.		05.	240	1
3823...	Front spring pad	1909-27	45	4 00.		05.	262	1

REAR SPRING

†3824...	REAR SPRING	1909-27				6 50.	333	1
*3824B...	REAR SPRING	1922-27				6 75.	388	1
†3825B...	First leaf (main leaf)	1918-27				1 35.	355	1
*3825C...	First leaf (main leaf)	1922-27				1 35.	389	1
†3826B...	Second leaf	1918-27	10 00.			1 10.	362B	1
*3826C...	Second leaf	1922-27	10 00.			1 10.	391	1
†3827B...	Third leaf	1918-27	8 50.			95.	363B	1
*3827C...	Third leaf	1922-27	8 50.			95.	392	1
†3828B...	Fourth leaf	1918-27	7 50.			85.	364B	1
*3828C...	Fourth leaf	1922-27	7 50.			85.	393	1
†3829B...	Fifth leaf	1918-27	6 50.			75.	365B	1
*3829C...	Fifth leaf	1922-27	6 50.			75.	394	1
†3830B...	Sixth leaf	1918-27	5 00.			60.	366B	1


††Used on headlamp tie rod. *Nine-leaf spring.
 **Use with nine-leaf front spring. †Seven-leaf spring. †Eight-leaf spring.
 Above quantity prices as well as individual prices subject to wholesale trade discount.



Part No.	Name of Part	Year	LIST PRICE			Each	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			

REAR SPRING—Continued

*3830C...	Sixth leaf	1922-27	\$5 00.			\$0 60.	395	1
†3831B...	Seventh leaf	1918-27	3 50.			45.	367B	1
*3831C...	Seventh leaf	1922-27	3 50.			45.	396	1
†3832B...	Eighth leaf	1909-27	3 00.			35.	368B	1
*3832C...	Eighth leaf	1922-27	3 00.			35.	397	1
*3832D...	Ninth leaf	1922-27	2 50.			30.	398	1
†3833...	Rear spring clip	1909-27				20.	326	2
*3833B...	Rear spring clip nut	1922-27				20.	1737	2
3834...	Rear spring clip bar	1909-27						
3835...	Rear spring tie bolt	1909-27	20	\$1 50	\$14 00	05.	1352	1
†3837...	Rear spring tie bolt nut	1909-27	15	1 00	9 00	02.	1353	1
3837B...	Rear spring tie bolt nut	1922-27	35	2 00.		05.	1355	1
*3838...	Rear spring tie bolt	1909-27	2 25	20 00	170 00	25.	91½C	2
3840B...	Rear spring hanger	1909-27	40			05.	7649	2
3841...	Rear spring hanger bar	1909-27				05.	94	1
3842...	Rear spring pad	1909-25	3 50.			40.	2804AR	2
3843...	Rear spring perch	1926-27				40.	2804B	2
†3843B...	Rear spring perch	1909-27	35	3 00.		05.	172	4
3844...	Rear spring perch bush	1909-25	45	4 00.		05.	174	2
3845...	Rear spring perch nut	1917-27	35	3 00.		05.	2944A	4
3846...	Spring perch roller							
3847B...	Front spring clamp assembly with bolt and nut	1916-27	75	6 00.		10.	2953	2
3848...	Rear spring clamp assembly with bolt and nut	1909-17	75	6 00.		10.	376AR	2
3848B...	Rear spring clamp assembly with bolt and nut	1918-27	75	6 00.		10.	378B	2



STARTING CRANK

3901...	Starting crank handle	1909-22				15.	520A	1
3902...	Starting crank handle bolt	1909-22	75	6 00		10.	521	1
3903...	Starting crank sleeve	1909-22	75			10.	523	1
3905...	Starting crank ratchet pin	1909-27	25	2 00	15 00	05.	4491	1
3906...	Starting crank ratchet	1909-27	1 50.			20.	528B	1
3908...	Starting crank spring	1909-27	20	1 00		03.	626	1
3909...	Starting crank handle spring	1915-22	15	1 00		02.	5911	1
3910...	Starting crank assembly	1909-27				40.	5931	

†RADIATOR—THERMO SYPHON

3925B...	Radiator—with shell	1917-23				16 00.	8700BR	1
3925C...	Radiator—less shell	1917-23				15 00.	8736CR	1
3925D2...	Radiator—with shell	1923-27				14 00.	8700J	1
3925E2...	Radiator—less shell	1923-27				13 00.	8736H	1
3925F2...	Radiator with nickel shell	1926-27				16 00.	8700H	1

†Service Dealers discount applies on radiator parts to Radiator Repair Shops.
 ††Use with 2501B or 2502B. †Eight-leaf spring. *Nine-leaf spring.
 Above quantity prices as well as individual prices subject to wholesale trade discount.

Part No.	Name of Part	Year	LIST PRICE			Each	Fac. No.	No. Req. Per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			
RADIATOR—THERMO SYPHON—Continued								
3926...	Radiator cap	1909-27	\$1 60	\$15 00		\$0 20	8714	1
3927...	Radiator cap gasket	1909-26	15	1 00		02	1117AR	1
3927B...	Radiator filler cap gasket (cork)	1926-27	25	2 00		03	1117B	1
3928...	Radiator pad	1909-19				05	1105R	2
3929...	Radiator stud	1909-19				05	1162AR	2
3929B...	Radiator stud	1919-25	45	4 00	\$35 00	05	1162B	2
3929B2...	Radiator stud	1926-27				05	1162C	2
3929C...	Radiator stud nut	1909-27	15	1 40	12 00	03	1154	2
3930...	Radiator stud spring	1909-27	Order 2742					
3931...	Radiator stud washer nut	1909-27	0 15	1 40	12 00	03	1161	2
3932...	Radiator rod	1909-23	1 00			15	1111B	1
3932B...	Radiator rod	1923	1 00			15	1111CR	1
3932C...	Radiator rod	1923-25	1 00			15	1111D	1
3932D...	Radiator rod	1926-27				15	1111E	1
3934...	Radiator rod nut	1909-27	Order 3066B					
3939...	Outlet connection pipe	1909-27	2 00			25	1121	1
3940...	Outlet connection cock	1909-27	Order 3079					
3944...	Outlet connection hose	1909-27	80	7 50		19	507B	2
3945...	Outlet connection hose clip	1909-27	30	2 50		05	554B	4
3947B...	Radiator shell	1917-23				1 00	8737ER	1
3947C...	Radiator shell	1923-27				1 00	8737C	1
3947D...	Radiator shell (nickel)	1926-27				3 00	8737D	1
3975...	Radiator stud spring upper thimble	1919-27	15	1 25		02	1115	1
3976...	Radiator stud spring lower thimble	1919-27	25	2 00		03	1114	1
3977...	Radiator apron	1923-25				35	8016AR	1
3977C...	Rad. apron and finish strip assy.— Cp.—Tudor—Fordor	1926-27				75	40113	1
3977D...	Rad. apron finish strip—Cp.—Tudor —Fordor	1926-27				35	8665	1
3977E...	Radiator apron	1926-27				40	40110R	1
4000...	Bracket (rod on rad.)	1909-27				10	1125B	1
4001...	Bottom (up. tank)	1917-26				65	8706AR	1
4001B...	Bottom (up. tank)	1924-26				65	8706BR	1
4001C1...	Bottom (upper tank)	1926-26				65	8706CR	1
4001C2...	Bottom (upper tank)	1926-27				65	8706D	1
4002...	Clasp (hood on rad.)—black	1909-27				02	1109B	1
4002B...	Clasp (hood on rad.) tinned	1926-27				02	1109C	1
4003...	Con. (inlet)	1917-23	1 50			20	8712AR	1
4003B...	Con. (inlet)	1923-27	2 50			30	8712C	1
4004...	Con. (outlet)	1910-27				25	1104B	1
4005...	Cover (lower tank)	1909-26				30	1134BR	1
4005B...	Cover (lower tank)	1924-26				30	1134CR	1
4005C1...	Cover (lower tank)	1926-26				30	1134DR	1
4005C2...	Radiator lower tank cover	1926-27				30	1134E	1
4006...	Fin	1909-26	75	5 00		10	1143A	1
4006B...	Fin	1924-26	75	5 00		10	1143BR	1
4006C1...	Fin	1926-26	75	5 00		10	1143CR	1
4006C2...	Radiator fin	1926-27	75	5 00		10	1143D	1
4007...	Flange (filler)	1917-27				25	8713	1
4007B...	Pipe (overflow)	1917-23				20	8718AR	1
4008...	Overflow pipe	1923-27				20	8718CR	1
4008B...	Overflow pipe	1924-26				20	8718D	1
4009...	Plate (splash)	1916-27				10	8709	1
4010B1...	Support	1920-26				25	1126CR	1
4010B2...	Radiator support	1926-27				25	1126D	1
4011...	Support (lower tank)	1909-19				05	1190A	1
4011C...	Support (lower tank)	1924-26				10	1190C	1
4012B...	Support (upper tank) assy.—R	1923-27				20	8829A	1
4012C...	Support (upper tank) assy.—R	1924-26				20	8829BR	1
4012D...	Support (upper tank) R	1917-23				20	8829D	1
4012E...	Support (upper tank) assy. R	1924-26				20	8829CR	1
4013B...	Support (upper tank) assy.—L	1923-27				20	8830A	1
4013C...	Support (upper tank) assy.—L	1924-26				20	8830BR	1
4013D...	Support (upper tank) L	1917-23				20	8830D	1
4013E...	Support (upper tank) assy. L	1924-26				20	8830CR	1
4015...	Tank (lower)	1916-27				50	1137B	1
4016...	Top (upper tank) less filler flange	1917-23				40	8705	1
4017...	Tube	1924-26				05	8717AR	1
4017B1...	Tube	1923-27				10	8717DR	1
4017B2...	Radiator tube (round)	1923-27				05	8717C	1
4018...	Wall (upper tank front)	1917-27				25	8707	1
4019...	Wall (upper tank rear)	1917-27				25	8708	1
4020...	Wall assembly (rear)	1917-27				50	8872	1


†Flat tube design radiator.


*3 tube design.

**4 tube design.

\$4 or 5 tube.

Above quantity prices as well as individual prices subject to wholesale trade discount.






Part No.	Name of Part	Year	LIST PRICE			Each	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			

RADIATOR FAN

3960...	Fan and pulley assembly	1909-20				\$1 25	619R	1
3961...	Fan blade	1909-20				10	611	4
3961B...	Fan blade rivets	1909-20				05	1566	16
3961C...	Fan blade assembly	1920-27	\$2 00			25	620	1
3962B...	Dr. fan pulley with bush	1920-26	6 00			70	618BR	1
3962C...	Driven fan pulley assembly	1926-27	6 00			70	618C	1
3963...	Fan drive pulley	1909-20				30	602A	1
3963B...	Fan drive pulley	1920-27	2 50			30	602B	1
3964...	Fan belt—23"	1909-16	3 00	\$28 00		40	609AR	1
3964C...	Fan belt—26"	1917-20	3 00	28 00		40	609BR	1
3964E...	Fan belt	1920-25	3 00	28 00		40	609CR	1
3964F...	Fan belt	1926-27	3 00	28 00		40	609D	1
3966...	Fan shaft	1909-20				25	606A	1
3966C...	Fan shaft	1920-25				20	606C	1
3967...	Fan bracket	1909-16	3 00			40	604AR	1
3967B...	Fan bracket	1917-25	2 50			30	604BR	1
3968...	Fan bracket bolt	1909-25				10	605R	1
3970...	Fan grease cup	1909-19	75	6 00		10	601R	1
3973...	Fan adjusting screw	1909-25	15	1 00		02	645	1
3973B...	Fan adjusting screw nut	1909-25						
3973C...	Fan eccentric adj. bolt	1926-27	Order 3066B			15	647	1
3973D...	Fan eccentric adj. bolt nut	1926-27				03	648	1
3974...	Fan driven pulley bush	1917-20				15	8757A	1
3974B...	Fan driven pulley bush	1920-27	1 00			15	8757B	2
3980...	Fan pulley plug	1920-27	25	2 00		03	633	1
3981...	Fan pulley gasket	1920-27	10	80		02	634	1
3982...	Fan shaft cap	1920-27	10	90		02	635	1
3983...	Fan shaft felt washer	1920-27	15	1 00		02	637	1
3984...	Fan blade screw	1920-27		60	5 00	01	652	4
3985...	Fan blade screw washer	1920-27						
3986...	Fan shaft nut	1920-27	Order 3261C					
3987B...	Fan eccentric	1926-27	Order 2719			25	630	1
3988...	Fan eccentric plate	1926-27				03	638	1

MUFFLER


4025B...	Muffler assembly	1909-27	20 00			2 50	1200C	1
4026B...	Muffler head—front	1917-20				35	1202CR	1
4026C...	Muffler head—front	1921-27				10	1202D	1
4027...	Muffler shell—outer	1909-27				25	1203	1
4028...	Muffler shell—middle	1909-27				20	1204	1
4029...	Muffler shell—inner	1909-27				20	1205	1
4030B...	Muffler rod	1917-20				10	1206BR	1
4031...	Muffler rod nut	1909-20						
4032...	Muffler head retainer	1921-27	Order 2503F			02	1210	1
4033...	Muffler head retainer bolt and nut	1921-27	Order 4819B and 3514					
4035...	Muffler head bolt washer	1921-27				05	925	1
4037C...	Long exhaust pipe	1920-27				40	1214B	1
4040B...	Muffler head—rear	1917-21				35	1201DR	1
4040D...	Muffler head—rear	1921-27				20	1209	1
4041B...	Muffler head to frame bolt and nut	1921-27	Order 3074 and 2515					



Part No.	Name of Part	Year	LIST PRICE			Each	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			

HOOD

4050B...	Hood	1917-23				\$6 00	8726AR	1
4050C...	Hood	1923-25				6 00	8726B	1
4050D...	Hood (black)	1926-27				6 00	40009	1
4050E...	Hood (specify color—as Channel Green, Drake Green, etc.)	1926-27				8 00	40009	1
4050E3...	Hood—unpainted	1926-27				4 00	40009	1
4051...	Hood handle	1909-27				05	1314	2
4052B...	Hood clip	1917-27		\$6 00		10	8731	4
4053B...	Hood clip spring	1917-27	\$0 15	1 00		02	8734	4
4054...	Hood corner pad	1926-27				02	40037	2
4056B...	Hood block—left	1917-23	2 50			30	8742AR	1
4056C...	Hood block—left	1923-25	2 50			30	8742B	1
4056D...	Hood block—left	1926-27				40	40017	1
4056E...	Hood block—right	1917-23	2 50			30	8741AR	1
4057C...	Hood block—right	1923-25	2 50			30	8741B	1
4057D...	Hood block—right	1926-27				40	40016	1
	Hood block to frame bolt—long	1926-27						
	Hood block to frame bolt—short	1926-27						
	Hood block to support brkt. bolt	1926-27						
*4060C...	Hood pad (on dash)	1917-22	70	5 00		08	8711AR	2
*4060D...	Hood pad (on rad. shell)	1917-27	1 35	10 00		15	8710	1
*4060E...	Hood pad (on dash)	1923-25	70	5 00		08	8711B	2
*4060F...	Hood pad (on dash)	1926-27				10	8673	1




4061B...	Hood clasp (on dash)	1917-20	40	3 50		05	8720AR	1
4061C...	Hood clasp (on dash) screw	1917-23				02	8763R	2
4061D...	Hood clasp (on dash)	1920-23	35	2 50		05	8720BR	1
4061E...	Hood clasp (on dash)	1923	35	2 50		05	8720CR	1
4061F...	Hood clasp (on dash)	1923-25	35	2 50		05	8720DR	1
4073...	Hood block support—front—R	1917-23	75			10	8743AR	1
4073B...	Hood block support—front—R	1923-25	75			10	8743B	1


1Quantity prices will apply on any assortment of these four belts.
Above quantity prices as well as individual prices subject to wholesale trade discount

*Less than 100 yards .08 per yard—100 yards or more .06 per yard.
Above quantity prices as well as individual prices subject to wholesale trade discount.

Part No.	Name of Part	Year	Lots of 10 per lot	LIST PRICE Lots of 100 per lot	Lots of 1000 per lot	Each	Fac. No.	No. Req. per Car
HOOD—Continued								
4073C.	Hood block support—front—R.	1926-27				\$0 15.	40022	1
4074.	Hood block support—front—L.	1917-23	\$0 75			10.	8744AR	1
4074B.	Hood block support—front—L.	1923-25	75			10.	8744B	1
4074C.	Hood block support—front—L.	1926-27				15.	40023	1
4075.	Hood block support—rear—R.	1917-23	75			10.	8745AR	31
4075B.	Hood block support—rear—R.	1923-25	75			10.	8745B	1
4075C.	Hood block support—rear—R.	1926-27				05.	40028	1
4076.	Hood block support—rear—L.	1917-23	75			10.	8746AR	1
4076B.	Hood block support—rear—L.	1923-25	75			10.	8746B	1
4076C.	Hood block support—rear—L.	1926-27				05.	40029	1
4077.	Hood block support bracket—rear.	1926-27				20.	40008	1

**CARBURETOR****FORD CARBURETOR MODEL ("NH")**

6200C.	Carburetor	1926	25 00.		3 00.	553B2R	1
6201.	Float with lever	1920-26	2 00.		25.	6333B	1
6202B.	Float chamber and bushing assy.	1920-25			50.	6318B	
6202C.	Float chamber	1923-26			30.	4802F	
6203.	Float chamber gasket	1920-26		\$0 50	05.	555B	
6204.	Spray nozzle gasket	1920-26			01.	4820B	
6205.	Mixer chamber gasket	1920-26			02.	6367B	
6206.	Throttle lever	1914-26			10.	4836BR	
6206A2.	Throttle lever—oversize.	1914-26			10.	4836AR	
6206B.	Aux. throttle lever	1914-26			15.	6327AR	
6207B.	Mixer chamber	1920-26			1 50.	6343R	
6208.	Adj. needle clamp nut	1920-25			05.	4812BR	
6208B.	Carb. spray needle adj. nut	1926-26			05.	4812DR	
6209.	Throttle plate	1920-26			02.	4517B	
6210.	Float lever pin	1920-26			01.	6320B	
6211.	Float chamber screw	1920-26			05.	6284R	
6212.	Float valve seat	1920-26	40.		05.	6321B	
6213.	Spray needle assembly	1920-25	1 00.		15.	6335BR	
6213B.	Carb. spray needle assembly	1926-26			30.	6335ER	
6214B.	Spray nozzle	1920-26	1 50.		20.	6341CR	
6215.	Air passage vent plug	1920-26			10.	6273R	
6216.	Drain valve plug assembly	1916-26			10.	6329A	
6217.	Throttle lever stop screw	1911-26			02.	4520A	
6218.	Aux. throttle lever spring	1914-26			02.	6342AR	
6219.	Float valve seat gasket	1920-26			01.	6322C	
6220.	Gasoline inlet needle	1920-26	1 00.		15.	6324A	
6221.	Drain valve body	1923-26			15.	6328DR	

**KINGSTON CARBURETOR (Model "L-4")**


*6150B.	Carburetor	1926-26	25 00.		3 00.	553B1R	
6151.	Drain valve body	1921-26			15.	6328CR	
6152.	Float chamber	1921-23			50.	4802ER	

†When used on cars without instrument board adjustment replace spray needle and adj. nut with 6213 and 6208. ‡Use with mixing chamber having slots at bottom.

§When used on cars without instrument board adjustment replace spray needle with 6161. Above quantity prices as well as individual prices subject to wholesale trade discount.

Part No.	Name of Part	Year	Lots of 10 per lot	LIST PRICE Lots of 100 per lot	Lots of 1000 per lot	Each	Fac. No.	No. Req. per Car
KINGSTON CARBURETOR (Model "L-4")—Continued								
6152B.	Float chamber	1924-26				\$0 50.	4802GR	
6153.	Mixing chamber	1921-23				1 50.	6340GR	
6153B.	Mixing chamber	1924-26				1 50.	6340HR	1
6154.	Carb. inlet elbow	1913-26	\$ 1 00.			15.	4859	
6155.	Float with lever	1921-26	3 00.			40.	6333GR	1
6156.	Float chamber gasket	1921-26				05.	555DR	
6157.	Mixing chamber gasket	1921-23				05.	6367ER	
6157B.	Mixing chamber gasket	1924-26				05.	6367FR	
6158.	Float valve seat gasket	1921-26				03.	6322FR	
6159.	Constant air supply lever assy.	1921-26				30.	6327DR	
6160.	Throttle lever assy.	1921-26				30.	4836DR	
6161.	Spray needle assembly	1910-25				40.	6335DR	
6161B.	Spray needle assembly	1926-26				45.	6335FR	
6162.	Drain valve body clamp nut	1921-26				05.	6395R	
6163.	Mixing chamber nut	1921-23				10.	4810CR	
6163B.	Mixing chamber nut	1924-26				10.	4810DR	
6164.	Constant air supply spring	1913-26				05.	6342CR	
6165.	Spray needle sleeve	1915-26				20.	4812CR	
6166.	Float lever pin	1915-26				02.	6320CR	
6167.	Constant air supply plate	1921-26				10.	4517AR	
6168.	Throttle plate	1921-26						
6169.	Drain valve plug assembly	1915-26				10.	6329BR	
6170.	Throttle lever adj. screw	1913-26				03.	4520BR	
6171.	Air valve stop assembly	1921-26				15.	6397R	
6172.	Float valve seat	1921-26				20.	6321ER	
6173.	Air valve shaft assembly	1921-26				20.	6381BR	
6174.	Air valve	1921-26				30.	6355BR	
6175.	Gasoline valve	1921-26	2 00.			30.	6324DR	1


Order 6209

**VAPORIZER**

6250.	Vaporizer assembly—with fittings.	1926-27				9 00.	2201S	
6250B.	Vaporizer assembly—less fittings.	1926-27				7 50.	2245	
6251.	Intake manifold	1926-27				65.	512D	
6253.	Inlet and Exhaust manifold gasket	1926-27						
6253.	Mixing chamber to intake manifold gasket	1926-27				02.	2210	
6254.	Mixing chamber complete assembly	1926-27				2 00.	2202	
6255.	Mixing chamber to intake manifold screw	1926-27						
6256.	Choke lever assembly	1926-27				02.	2237	
6257.	Choke plate	1926-27				30.	6327E	
6258.	Choke lever spring	1926-27				02.	2220	
6259.	Throttle lever and rod assembly	1926-27				02.	6342D	
6259.	Throttle plate	1926-27				20.	4836E	

Above quantity prices as well as individual prices subject to wholesale trade discount.

Part No.	Name of Part	Year	LIST PRICE Lots of 10 of 100 of 1000 per lot	Each	Fac. No.	No. Req. per Car
VAPORIZER—Continued						
6261	Throat	1926-27		\$ 0 10	2243	
6262	Air valve	1926-27		25	6355C	
6263	Air valve shaft assembly	1926-27		10	6381C	
6264	Air valve shaft screw	1926-27		05	2234	
6265	Air valve stop screw	1926-27	Order 6217			
6266	Air valve stop screw lock washer	1926-27		01	7696	
6267	Vapor outlet tube screw	1926-27		02	2236	
6268	Choke lever (inner)	1926-27		10	2212	
6269	Vapor outlet tube	1926-27		20	2241	
6270	Vapor outlet tube gasket	1926-27		02	2209	
6271	Vapor outlet tube nut	1926-27		10	2216	
6272	Exhaust manifold	1926-27		1 75	4483C	
6272B	Exhaust manifold and cover assembly	1926-27		4 25	2215	
6273	Vapor heating plate	1926-27		15	2221	
6274	Manifold cover and float bracket assembly	1926-27		1 75	2250	
6275	Exhaust manifold cover screw	1926-27		03	2233	
6276	Primary air tube	1926-27		25	2242	
6277	Vapor heating plate support	1926-27		02	2240	
6278	Adjusting needle nut	1926-27		05	4812F	
6279	Adjusting needle and head assembly	1926-27		20	6335G	
	Float valve seat gasket	1926-27	Order 6219			
	Float valve seat	1926-27	Order 6212			
	Float valve assembly	1926-27	Order 6220			
6283	Adjusting needle seat	1926-27		10	2231	
	Float and lever assembly	1926-27	Order 6201			
	Float lever pin	1926-27	Order 6210			
6286	Spray nozzle	1926-27	\$1 50	20	6341D	
	Float chamber gasket	1926-27	Order 6203			
	Spray nozzle gasket	1926-27	Order 6204			
	Float chamber	1926-27	Order 6202C			
	Drain valve body gasket	1926-27	Order 6205			
6291	Drain valve body	1926-27		10	6328E	
	Drain valve plug assembly	1926-27	Order 6216			
	Feed pipe gasket	1926-27	Order 2913			
	Gasoline inlet pack nut	1926-27	Order 2910			
6295	Gasoline inlet elbow (cars previous to 1926)	1926-27		50	2208	
	Gasoline inlet elbow	1926-27	Order 6154			
6297	Steering post throttle lever	1926-27		10	2213R	
6297B	Steering post throttle lever bolt	1926-27		02	2239S	
6297C	Steering post throttle lever bolt nut	1926-27		01	3198S	
6298	Vaporizer pull rod all cars 1925, TT chassis 1926	1926-27		10	2225	
6299	Vaporizer pull rod, Road., T. C., Cp., Tudor	1926-27		10	2223	
6300	Vaporizer pull rod, Fordor, T. Chassis	1926-27		10	2248	
6302B1	Vaporizer choke rod	1926-27		02	8797F	
6302B2	Vaporizer choke rod	1926-27		02	TT8797B	
6303	Adjusting rod collar	1926-27		03	2206R	
6304	Adjusting rod collar set screw	1926-27		01	2238R	

**CARBURETOR ATTACHMENTS**


4127A	Carburetor adj. rod bracket	1909-22		05	1357R	1
4129A	Carburetor adjusting rod	1909-25		10	7920R	1
4129B	Carburetor adj. rod and knob assy.	1925	\$ 2 00	25	6101R	1
4129C	Carburetor adj. rod and knob assy.—24 1/8" T. C., Road., Open Cab	1925		25	6102R	1
4129D1	Carburetor adj. rod and knob assy.—25 3/4" Cp., Tudor, Fordor	1925	2 00	25	6103AR	1
4129D2	Carburetor adj. rod and knob assy.—18 1/4" T and TT Chassis	1926	1 50	20	6103B	1
4129E	Carburetor adj. rod and knob assy.—T. Comm. and T. T. 18 1/4"	1926-27	1 50	20	TT6101	1
4129F	Carburetor adj. rod and knob assy.—28 1/8" Closed Cab	1926	2 00	25		

Above quantity prices as well as individual prices subject to wholesale trade discount.

Part No.	Name of Part	Year	LIST PRICE Lots of 10 of 100 of 1000 per lot	Each	Fac. No.	No. Req. per Car
CARBURETOR ATTACHMENTS—Continued						
4129F	Carburetor adj. rod and knob assy.—Cp.—Tudor—27 1/8"	1926		\$0 25	6123AR	1
4129G	Carburetor adj. rod and knob assy.—Road.—T. C.—Fordor—26 1/4"	1926		25	6124AR	1
4129H	Vaporizer adj. rod, Cp., Tudor, Closed Cab—31 1/8"	1926-27		25	6123B	
4129I	Vaporizer adj. rod Road, T. C., Fordor—29 1/8"	1926-27		25	6124B	
4129J	Vaporizer adj. rod and knob assy.—Cp., Tudor, Fordor—28 1/8"	1925		25	6128AR	
4129K	Vaporizer adj. rod and knob assy.—Road., T. C.—27 5/8"	1925		25	6130AR	
	Vaporizer adj. rod, Open Cab	1926-27	Order 4129G			
	Vaporizer adj. rod, T and TT chassis	1926-27	Order 4129D1			
4130	Carburetor flange bolt	1909-26	Order 3072			
4130B	Carburetor flange bolt nut	1909-26	Order 3066B			
4131	Carburetor and vaporizer adj. rod sleeve	1926-27		10	6114	
4132	Carburetor and vaporizer univ. joint spider	1926-27	\$0 30		05	6113
4134	Carburetor flange gasket	1909-26	20	\$1 50	05	1380BR
4431	Carburetor priming rod	1909-26	45	3 50	05	2000AR
4431B	Priming rod (on radiator) use with vaporizer	1926-27	45	3 50	05	2000B
4582	Carburetor hot air pipe	1912-25	1 75	15 00	20	686AR
4582B	Carburetor hot air pipe	1925-26	1 75	15 00	20	686CR
4583	Priming bell crank	1919-25			10	7691R
4587B	Priming rod—17 1/8"	1919-22	1 25		15	6629BR
4588B	Priming rod—13 1/8"	1919-22	1 25		15	6627AR
4588D	Priming rod—13 1/8"	1923-25	1 25		15	6627BR
4588E	Priming rod—17 1/8"	1923-25	1 25		15	6629CR
4588F	Priming rod—16 1/8"	1923-25	1 25		15	6630BR
4589	Priming rod—20 1/2"	1919-25	25		05	8797AR
4589B	Priming rod—14 1/2"	1922-25	25		05	8797BR
4589C	Choke lever rod—7 1/8"	1925	10		02	8797CR
4589D	Choke lever rod—7 1/8"	1926	10		02	8797DR
4590	Priming rod bumper	1926-27			01	6115
4591	Vaporizer choke rod sleeve	1926-27			03	6116
4592	Choke lever rod, 8 3/8" T & TT chassis	1925			02	6117AR
4592B	Choke lever rod, 8 3/8" T & TT chassis	1926			02	6117BR
*4593	Carb. adj. rod anti-rattler	1925-26			05	6104
†4594	Carb. adj. rod anti-rattler	1926			10	45293


FENDERS

4800B	Front fender—right	1917-23		4 00	7976AR	1
4800C	Front fender—right	1923-25		4 00	7976B	1
4800D	Front fender—right	1926-27		5 00	40108	1
4801B	Front fender—left	1917-23		4 00	7977AR	1
4801C	Front fender—left	1923-25		4 00	7977B	1
4801D	Front fender—left	1926-27		5 00	40109	1
4802F	Rear fender—right	1917-25		3 50	8850AR	1
*4802G	Rear fender—right	1922-25		3 75	7730R	1
†4802H	Rear fender—right	1923-25		4 00	8850BR	1
4802J	Rear fender—right—T. C.—Tudor—Fordor	1926-27		4 00	40123	1



4802K	Rear fender—right—Road.—Cp.	1926-27		4 00	40130	1
4802F	Rear fender—left	1917-25		3 50	8851AR	1
*4802G	Rear fender—left	1922-25		3 75	7731R	1
†4802H	Rear fender—left	1923-25		4 00	8851BR	1
4803J	Rear fender—left—T. C.—Tudor—Fordor	1926-27		4 00	40124	1
4803K	Rear fender—left—Road.—Cp.	1926-27		4 00	40131	1

*For Fordor and Tudor. †For Coupe.
 **Road. and T. C.—1925—Open and Closed Cab 1925-26. ††Road., T. C., Tudor, Coupe—1926.
 Above quantity prices as well as individual prices subject to wholesale trade discount.



Part No.	Name of Part	Year	Lots of 10 per lot	LIST PRICE of 100 per lot	Lots of 1000 per lot	Each	Fac. No.	No. Req. per Car
----------	--------------	------	--------------------	------------------------------	----------------------	------	----------	------------------

FENDERS—Continued

FENDER IRONS

4804D.	Rear fender iron—R. & L.—T.C.	1913-25	\$ 1 50		\$0 20	5405		2
4804E.	Rear fender iron—right—Cp. & Rbt.	1913-23			60	5563AR		1
4804F.	Rear fender iron—left—Cp. & Rbt.	1913-23			60	5390AR		1
4804G.	Rear fender iron—R. or L.—Sedan	1916-17			40	8154AR		2
4804K.	Fender iron—R. or L.—Sedan	1918-25			15	8154BR		2
4804L.	Rear fender iron—T.C.	1921-25			10	7395R		21
4804M.	Rear fender iron—right	1923-25			60	5563BR		1
4804N.	Rear fender iron—left	1923-25			60	5390BR		1
4809.	Front fender iron—right or left	1909-25	5 50		60	343B		2

FENDER BOLTS, NUTS AND BRACKETS

4805B.	Rear fender iron bolt	1915-25	15	\$ 1 20	\$ 9 00	03	7171	6
4805C.	Rear fender iron bolt nut	1915-25	10		80 6 00	02	341	
4806B.	Fender eye bolt	1909-25	45	4 25	40 00	05	1942	4
4806C.	Fender eye bolt washer	1909-25		50	2 50	01	1943	4
4806D.	Fender eye bolt nut	1909-25		Order 2825B				
4808.	Front fender iron bolt (side)	1910-25	25	2 00	15 00	03	1323	2
4808B.	Front fender iron bolt (bottom)	1910-25		Order 3362				
4808C.	Front fender apron to frame bolt	1915-25	15	1 25	8 00	03	4088	4
4808D.	Front fender iron bolt nut	1910-25		Order 2515				
4808E.	Front fender apron to frame bolt nut	1915-25		Order 3088E				
4850.	Front fender apron brkt.—right	1917-25			10	8854		1
4851.	Front fender apron brkt.—left	1917-25			10	8855		1
4852.	Front fender iron brkt.—left	1915-25			15	7984		1
4853.	Front fender iron brkt.—right	1915-25			15	7998		1
4854.	Rear fender iron bracket	1915-25			20	7483R		2
4855.	Rear fender to R. B. shield brkt.	1915-25			05	7994AR		2
4856.	Rear fender iron brkt.—R.—Coupe	1924-25			20	7484R		1
4857.	Rear fender iron brkt.—L.—Coupe	1924-25			20	7486R		1
4858.	Front fender bracket	1926-27			45	40106		2
	Front fender brkt. bolt	1926-27		Order 3074				
	Front fender brkt. bolt nut	1926-27		Order 3939C				
	Front fender brkt. bolt lock washer	1926-27		Order 4806C				
	Fender to R. B. bolt	1926-27		Order 4805B				
	Fender to R. B. bolt nut	1926-27		Order 4805C				
4864.	Fender to R. B. bolt lock washer	1926-27	25		doz. 05	1599		
4865.	Fender to R. B. shield bolt	1926-27	50		02	7431		
4866.	Fender to R. B. shield bolt nut	1926-27	50		01	1068		
4867.	Fender to R. B. shield plain washer	1926-27	50		01	1034		
4868.	Fender to R. B. shield lock washer	1926-27	25		doz. 05	1966		
4869.	Rear fender to body bolt	1926-27			01	7089		
	Rear fender to body bolt nut	1926-27		Order 2503F				
	Rear fender to body plain washer	1926-27		Order 4035				
4872.	Rear fender to body lock washer	1926-27	50		01	7254		
4873.	Rear fender brkt. to body bolt	1926-27			02	8147		
4874.	Rear fender brkt. to body bolt nut	1926-27			03	45131		
	Rear fender brkt. to body lock washer	1926-27		Order 4872				
†	Rear fender and flange reinforcement to body bolt	1926-27		Order 4805B				
†	Rear fender and flange reinforcement to body bolt nut	1926-27		Order 3514				
†	Rear fender and flange reinforcement to body plain washer	1926-27		Order 4035				
†	Rear fender and flange reinforcement to body lock washer	1926-27		Order 4872				
4880.	R. B. shield to sill filler block screw	1926-27			01	1465		
4881.	R. B. shield to sill filler block washer	1926-27	50		01	7593		

†Tudor only.

Above quantity prices as well as individual prices subject to wholesale trade discount.


Part No.	Name of Part	Year	Lots of 10 per lot	LIST PRICE of 100 per lot	Lots of 1000 per lot	Each	Fac. No.	No. Req. per Car
----------	--------------	------	--------------------	------------------------------	----------------------	------	----------	------------------

RUNNING BOARD AND SHIELDS

4812.	Running board—R.	1909-25			\$1 25	5418AR		1
4813.	Running board—L.	1909-25			1 25	5480R		1
4813B.	Running board	1926-27			1 50	5418B		1
4814C.	Running board shield—R.	1917-25			2 40	7986R		1
4814D.	Running board shield—R.	1922-24			2 40	7747AR		1
*4814E.	Running board shield—R.	1924-25			2 40	7747BR		1
4814F.	Running board shield—R.	1926-27			2 75	40127		1
4815C.	Running board shield—L.	1917-25			2 40	7987R		1
4815D.	Running board shield—L.	1922-24			2 40	7748AR		1
*4815E.	Running board shield—L.	1924-25			2 40	7748BR		1
4815F.	Running board shield—L.	1926-27			2 75	40128		1
4816.	R. B. truss rod—front with nuts	1909-21			35	5804R		1
4817.	R. B. truss rod—rear with nuts	1909-21			35	5805R		1
4817B.	Truss rod nut	1921-27			03	339		4
4818B.	Running board bracket assy.	1909-20			1 00	2926		2
4819.	Running board to rear fender bolt	1921-27	15	1 25		03	1344B	4
4819B.	Running board to rear fender bolt	1909-25	15	1 25	\$9 00	03	8161	4
4819C.	Running board to rear fender nut	1909-25			Order 3088E			
4819D.	R. B. to rear fender nut	1909-20			Order 3514			
4820.	R. B. to front fender bolt and nut	1921-25			Order 4808C and 3088E			
4820C.	R. B. to front fender bolt	1919-25			Order 4805B			
4821.	R. B. to shield clamp	1909-25			05	5478R		4
4822A1.	Running board block	1926-27			05	1921AR		4
4822A2.	Running board block	1926-27			05	1921B		4

RUNNING BOARD—TRUCK

4830B.	Running board—right	1926-27			60	TT5418		1
4830C.	Running board—left	1926-27			60	TT5480		1
4831.	R. B. bracket	1918-27			35	TT2926		4
4832.	R. B. bracket and brace	1918-27			15	TT2927		2
4833.	R. B. bracket and brace	1918-27			30	TT2929		1
4834.	R. B. bracket—rear	1918-27			35	TT2925		1
4835.	R. B. bracket and brace assy.—front	1918-27			50	TT2928		1
4836.	R. B. bracket and brace assy.—rear	1918-27			1 10	TT2930		1



FORD SPARK COIL

5000.	Coil (includes switch)	1909-22			8 50	1383AR		1
5001.	Coil	1909-25			7 75	1383BR		1
5001B.	Coil	1926-27			7 75	1383D		1
5001C.	Coil box bracket—front	1926-27			10	5889		1
5001D.	Coil box bracket—rear	1926-27			10	5890		1
5002.	Coil box with cover (includes switch)	1914-22			2 50	5858AR		1
5003.	Coil box with cover	1919-25	16 50		1 75	5858BR		1
5003B.	Coil box with cover	1926-27			1 75	5858D		1
5004.	Coil box cover	1915-25			25	7910AR		1
5004B.	Coil box cover	1926-27			50	7910B		1
5004C.	Coil box cover gasket	1926-27			10	5897		1
5005.	Coil box terminal bolt tube	1915-26			03	5810		9
5006.	Switch plug	1914-22	20	1 50		05	5815AR	1
5007.	Coil unit	1914-27	14 00		1 50	5845		4
5008.	Vibrator	1914-27	40	3 50	30 00	05	6797	4
5008B.	Vibrator and lower bridge assy.	1924-27	50	4 75	45 00	06	6737B	4
5009.	Vibrator bridge	1914-27	65	6 00	55 00	08	6702	4


‡Same as S728B.

†Same as S740.

‡Length 21 3/4.

*For Fordor and Tudor.

Above quantity prices as well as individual prices subject to wholesale trade discount.



Part No.	Name of Part	Year	LIST PRICE			Each	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			
SWITCH								
5010	Switch assembly (on coil)	1914-22				\$0 80.	5873R	1
5012	Ignition switch (on instrument bd.)	1919-25				75.	7675ER	1
*5012B	Ignition switch	1926-27				75.	7675F	1
5012C	Ignition switch	1926-27				75.	7676	1
5013B	Switch key—give serial number	1919-25	\$0 50	\$4 50	\$40 00	10.	5815C	1
5014	Starting switch (on floor board)	1919-27	4 00			50.	8792A3	1
5014B	Starting switch bracket bolt—long	1920-27	25	2 00		03.	8760	1
5015	Starting switch plunger extension	1919-25	80			10.	8793R	1

**AMMETER**

5016B...	Ammeter.....	1926-27	6 00	55 00.		75.	7680B	1
5017...	Ammeter lens and rim.....	1919-25	1 50.			20.	8105	1
5017B...	Ammeter lens.....	1919-25	40	3 00.		05.	8121	1
5017C...	Ammeter lens.....	1926-27	40	3 00.		05.	8121B	1
5017C2...	Ammeter lens.....	1926-27	40	3 00.		05.	8121C	1
5017D...	Ammeter adapter plate.....	1919-25	1 25	10 00.		15.	6665R	1

STARTER DRIVE

5018...	Starter drive.....	1919-27	36 00.			4 00.	1883	1
5019...	Starter drive head.....	1919-27	4 00.			50.	2007	1
5020...	Starter drive key.....	1919-27	15	1 00	7 50	02.	1751	1
5021...	Starter drive shaft and gear.....	1919-27				3 50.	2026	1
5022...	Starter drive spring.....	1919-27	2 50	21 00.		30.	2006	1
5023...	Starter drive shaft spring screw.....	1919-27	25	2 25	20 00	03.	1983	1
5024...	Starter drive head spring screw.....	1919-27	40	3 50	32 00	05.	1781	1
5025...	St. drive spring screw lock washer.....	1919-27		50	4 00	01.	1782	2

WIRING

5026...	Spark plug wire 14 1/8".....	1909-25	70	6 50.		10.	1365R	1
5027...	Spark plug wire (also magneto to coil) 10 1/2".....	1909-25	65	6 00.		10.	1366R	1
5028...	Spark plug wire 7".....	1909-25	60	5 00.		10.	1376R	2
5029...	Spark plug wire 7 1/4".....	1926-27	60	5 00.		10.	1360	2
5029B...	Spark plug wire 5 1/2".....	1926-27	60	5 00.		10.	1359	2
5030...	Commutator wire.....	1909-22	7 50	70 00.		80.	7502AR	1
*5030B...	Commutator wire.....	1922-27	9 00.			1 00.	7502CR	1
*5031...	Commutator wire (starter type).....	1919-27	10 50.			1 10.	7502BR	2
5031B...	Commutator wire.....	1926-27	4 50.			50.	7502D	1
5033B...	Commutator wire term. retainer.....	1921-27				01.	2124A	2
5033C...	Commutator wire clip.....	1919-27				01.	7688	7
5035...	Ammeter to cutout wire—Sedan 49".....	1919-25	1 80.			20.	7683B	1
5036...	Ammeter to cutout wire—Coupe 23".....	1919				15.	7684A	1
5037...	Ammeter to cutout wire—Coupe 41".....	1919-25	1 25.			15.	7684B	1
5038...	Ammeter to ignition switch wire.....	1919-25	80.			10.	7681AR	1
5038B...	Ammeter to ignition switch wire.....	1926-27				10.	7681B	1
5040...	Terminal block to switch wire.....	1919-25	60.			10.	8894BR	1
5040B...	Terminal block to horn switch wire.....	1926-27				10.	8894C	1
*5041...	Lighting wire.....	1919-25				90.	7682CR	1
*5041B...	Lighting wire—Truck.....	1921-27				1 00	T7682B	1
*5041C...	Lighting wire.....	1922-25	4 50.			50.	7661A	1


*Used on cars without starter, with switch on instrument panel.

†Used in 1926-27 on truck only. †Cars with starter.

**When used with old style tail lamp remove terminal from end of tail lamp wire.

Above quantity prices as well as individual prices subject to wholesale trade discount.

*5041D...	Lighting wire.....	1926		\$0 65.	7661B.....	1	
5041E...	Lighting wire.....	1926-27		1 50.	7682D.....	1	
5042...	Switch wire—Sedan.....	1919-25	\$7 00.		75.	7685B.....	1
5042B...	Switch wire—Rd.—T.C.—Cp.—Tudor.....	1926-27			75.	7685D.....	1
5043...	Switch wire.....	1919-25	6 00.		70.	7686B.....	1
*5043B...	Switch wire.....	1922-25	3 50.		40.	7660AR.....	1



*Used on cars without starter, with switch on instrument panel.


Part No.	Name of Part	Year	Lots of 10 per lot	LIST PRICE Lots of 100 per lot	Lots of 1000 per lot	Each	Fac. No.	No. Req. per Car
WIRING—Continued								
*5043C...	Switch wire.....	1926-27					50 45..	7660BR...1
5043D...	Switch wire—Fordor—Com. Chassis.....	1926-27					75..	7686D...1
5044...	Terminal block.....	1919-22	\$0 75	\$6 50			10..	1950AR...1
*5044C...	Terminal block.....	1922	75	6 50			10..	1951AR...1
*5044E...	Terminal block with screws.....	1923-27					10..	1954...1
*5044F...	Terminal block with screws.....	1923-27					10..	1955...1
5046...	Battery to switch cable—28 1/4".....	1919-27	7 50				80..	1889B...1
5046C...	Battery to switch cable—Truck.....	1921-27	7 00				80 TT1889...	1
5047...	Battery to switch cable—34".....	1920					75..	1889C...1
5047B...	Battery to switch cable sup.—Truck.....	1920-27	75				10..	2116...1
5047C...	Battery to switch cable support.....	1920-27	75				10..	2112...1
5047D...	Battery to switch cable sup. bush.....	1920-27					05..	2113...1
5047E...	Battery to switch cable sleeve.....	1921-27					05..	2120...1
5049B...	Ground connector.....	1919-27	2 50				30..	1890B...1
5051...	Switch to motor cable.....	1919-27					50..	1891...1
5051B...	Switch to motor cable sleeve.....	1921-27	2 50				30..	2119...1
5052...	Battery cable terminal bolt.....	1919-27	15	1 25			02..	1937...2
5052H...	Battery cable terminal bolt nut.....	1919-27		75			01..	1938...2

STARTER PARTS

5056...	Motor mounting gasket.....	1919-27	15	1 20	\$11 00		02..	1768.....
5057...	Gen. head gasket.....	1919-27	10	60	3 50		02..	1774.....
5058...	Gen. mounting short screw.....	1919-27	20	1 50	12 00		03..	1755.....
5059...	Starter drive cover screw.....	1919-27		50	4 00		01..	1765.....
5059B...	Starter drive cover screw washer.....	1919-27		30		doz	05..	2076.....
5060...	Term. block to wire screw.....	1919-27						
5062...	Motor mounting screw.....	1919-27	15	1 00	7 50		02..	5510.....

STARTING MOTOR AND PARTS

5099...	Starting motor.....	1919-27					12 50..	1877.....
5100...	Armature.....	1919-27	45 00				5 00..	1940.....
5101...	Cover band.....	1919-27	75	5 00			10..	1801C.....
5102...	Brush end bracket.....	1919-27					25..	1868.....
5103...	Bracket assy. mounting.....	1919-27					1 30..	2037.....
5104...	Brush.....	1919-27	1 40	13 00			15..	1806.....
5105...	Shaft rear bushing.....	1919-27					35..	1759.....
5106...	Shaft front bushing.....	1919-27		7 50			10..	1789.....
5107...	Field coil assembly.....	1919-27					2 50..	1871.....
5108...	Brush holder assembly.....	1919-27	4 00				45..	1864B.....
5109...	Terminal outer insulator.....	1919-27	15	1 00	7 50		02..	1795.....
5110...	Terminal inner insulator.....	1919-27		50	3 50		01..	1794.....
5112...	Terminal nut.....	1919-27	20	1 50	12 00		03..	1791.....
5113...	Field screw.....	1919-27	15	1 00	8 00		02..	1788.....
5114...	Brush end bracket to yoke screw.....	1919-27		75	4 00		01..	1808.....
5115...	Brush tension spring.....	1919-27	25	2 00			05..	1809.....
5116...	Terminal washer.....	1919-27		50			01..	1792.....
5117...	Terminal inner steel washer.....	1919-27		50			01..	1798.....
5118...	Motor yoke assembly.....	1919-27					3 50..	1852.....


**GENERATOR AND PARTS**

5055...	Cut-out (electric).....	1919-27	8 00	70 00			1 00..	7677B...1
5119...	Generator.....	1919-27					12 50..	1879.....
5120...	Armature (less bearings).....	1919-27	35 00				4 00..	1925.....
5121...	Small bearing.....	1919-27	9 50	90 00			1 00..	1838.....
5122...	Large bearing.....	1919-27	11 00	105 00			1 15..	1841.....
5123...	Terminal bolt.....	1919-27	40	3 50			05..	1836.....
5124...	Brush end bracket.....	1919-27					30..	1894.....

*Used on cars without starter, with switch on instrument panel.

§Used with steel dash. †Also for generator.

Above quantity prices as well as individual prices subject to wholesale trade discount.




Part No.	Name of Part	Year	Lots of 10 per lot	LIST PRICE Lots of 100 per lot	Lots of 1000 per lot	Each	Fac. No.	No. Req. per Car
5125...	Large brush.....	1919-27	\$1 35	\$12 00	\$110 00	\$0 15	1844.....	
5126...	Small brush.....	1919-27	1 35	11 50	100 00	15	1845.....	
5127...	Large bearing disc.....	1919-27	25	2 00		03..	1847.....	
5128...	Small bearing felt.....	1919-27	15	1 00		02..	2033.....	
5130...	Head.....	1919-27				50	2044.....	
5131B...	Small brush holder.....	1919-27	90	8 00	70 00	10	1821.....	
5132B...	Brush holder ring.....	1919-27				03..	1996.....	
5132C...	Brush holder assembly.....	1919-27		37 50		40..	1865.....	
5132D...	Brush holder assembly less small brush holder.....	1919-27		27 50		30..	1920.....	
5133...	Terminal outer insulator.....	1919-27	15	1 00	8 00	03..	1827.....	
5134...	Terminal nut.....	1919-27	15	1 00	8 00	03..	1818.....	
5134B...	Brush holder stud nut.....	1919-27		75	5 00	01..	6754.....	
5135...	Oiler.....	1919-27	45	4 00		05..	1837.....	
5136...	Pinion to shaft pin.....	1919-27		50	4 00	01..	1750.....	
5137...	Pinion.....	1919-27	3 00			35..	1752.....	
5138...	Small bearing felt retainer.....	1919-27	15	1 00		02..	1832.....	
5139...	Brush spring.....	1919-27	30	2 50	20 00	05..	1967.....	
5140...	Small brush spring.....	1919-27	30	2 50	20 00	05..	1988R.....	
5141B...	Small brush holder stud.....	1919-27	10	80	7 00	02..	1823C.....	
5142...	Terminal washer.....	1919-27		50		01..	1831.....	
5142B...	Small brush holder stud washer.....	1919-27		30	2 00	01..	2058.....	
5143...	Field winding assembly.....	1919-27	14 00			1 50	1978.....	
5144...	Brush to terminal wire.....	1919-27	40	3 00		05..	1851.....	
5145...	Generator yoke assembly.....	1919-27				3 00	1887.....	

BATTERY BRACKET AND PARTS

5150...	Bracket assembly.....	1919-23					75..	8841AR...1
*5150B...	Battery bracket assembly.....	1923-27					75..	8841B...1
5151...	Clamp bolt.....	1919-27	25	2 00	10 00		03..	8346.....
5151B...	Clamp bolt nut.....	1919-27						


Order 2825B



*Used with steel battery box or rubber case battery.

Above quantity prices as well as individual prices subject to wholesale trade discount.

Part No.	Name of Part	Year	LIST PRICE			Each	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			
BATTERY BRACKET AND PARTS—Continued								
5152	Clamp	1919-23				\$0 05	8844AR	2
5152B	Battery clamp	1921-27	\$ 0 40			05	8844B	2
5153	Battery support angle—truck	1921-27	1 25			15	TT8816	1
5154	Battery box support—truck	1921-27	1 75			20	TT8817	1
5155	Battery clamp support—rear—trk.	1921-27	1 75			20	TT8818	1
5156	Battery clamp support—front—trk.	1921-27	1 75			20	TT8819	1
5158	Battery box—less cover	1921-27				75	7671	1
5159	Battery box cover assembly	1921-27	5 00			60	5491	1
5160	Battery box cover door	1921-27				10	5493	1

***BATTERY (FORD)**

5175	Battery	1919-26				12 00	7670	1
5176	Battery case (wood)	1919-27	11 00			1 25	5434A	1
5176B	Battery case (rubber)	1926-27				2 25	5434B	1
5177	Cell connector	1919-27	85			10	5435	1
5178	Cell cover	1919-22				30	5436AR	1
5178B	Cell cover	1921-27	1 75			20	5436B	1
5178C	Cell cover	1923-27	1 60			20	5436C	3
5179B	Terminal post gasket	1921-27		\$0 60		01	5437B	3
5179C	Terminal post gasket	1923-27		60		01	5437C	3
5180	Rubber jar	1919-27	5 50			60	5438	1
5181	Terminal post nut	1919-22				05	5439AR	1
5181B	Terminal post nut	1921-27	30	2 50	\$20 00	05	5439B	1
5182	Negative group assembly	1919-22				2 00	5440AR	1
5182B	Negative group assembly	1921-27	17 50			1 85	5440B	1
5183	Positive group assembly	1919-22				2 00	5441AR	1
5183B	Positive group assembly	1921-27	17 00			1 80	5441B	1
5184	Filler plug with gasket	1919-22				15	5444AR	1
5184B	Filler plug with gasket	1921-23	1 00	9 00		15	5444B	1
5184C	Filler plug	1923-27	75	5 00	45 00	10	5442C	1
5185	Plate separator	1919-27		2 00	17 00	05	5445	1
5186	Positive plate	1919-22	2 50	23 50		30	5427AR	1
5187	Negative plate	1919-22				30	5427B	1
5187B	Negative plate	1921-27	2 50	23 50		30	5428AR	1
5188	Negative terminal post	1919-22				20	5425AR	1
5188B	Negative terminal post	1921-27	1 25			15	5425B	1
5189	Positive terminal post	1919-22				20	5426AR	1
5189B	Positive terminal post	1921-27	1 25			15	5426B	1
5190	Terminal—negative	1919-27	1 20	10 00		15	1929B	1
5191	Terminal—positive	1919-27	1 20	10 00		15	2049	1
M6022	Battery sealing compound (10 lb. carton)					13		
M1051	Electrolyte							

†Used with steel battery box or rubber case battery. †Not subject to regular discount.

*Service Dealer's discount applies on battery parts to Battery Service Stations.

Above quantity prices as well as individual prices subject to wholesale trade discount.


Part No.	Name of Part	Year	LIST PRICE			Each	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			
SPARK PLUGS								
5201	Spark plug "Ford" (Champion)	1909-27	\$4.50 net	\$40.00 net		\$0 60	1386A3	4
5203B	Sp. plug porcelain "Ford" (Champ.)	1909-27	2.20 net	20.00 net		30	3760C	4

REPAIR TOOLS

Part No.	Name of Part	LIST PRICE			Each	Fac. No.	No. Req. per Car
		Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			
1349	Hub cap wrench	\$1 00			\$0 15	1349	
1387	Adjustable wrench	3 50			40	1387	
1903	Pliers				25	1903	
1917	Double end wrench	1 35	\$12 00		15	1917	
2335	Spark plug and cylinder head bolt wrench	3 50			40	5893	
2336	Tool roll				20	1979A	
2337	Oil can	1 50			20	1384	
2338	Tire pump	9 00			1 00	1368	
2340	Tire irons, each				15	4069	
2343	Jack (including handle)				1 00	3389	
2344	Jack handle				15	3391	
5Z-152	Rear axle housing bolt nut wrench				30		
5Z-153	Socket wrench for crank shaft bearing bolt nut				40		
5Z-154	Body bracket con. bolt R. & L. wrench				30		
5Z-155	3/4" L socket wrench				35		
5Z-156	Crank shaft bearing bolt wrench				35		
5Z-157	Con. rod cap bolt nut L wrench (Cyl. No. 4)				30		
5Z-158	D S housing stud nut wrench for 3/8" nut				30		
5Z-159	Connecting rod T wrench				45		
5Z-160	3/4" T socket wrench				45		
5Z-161	Body bracket connecting bolt T wrench—front and center				40		
5Z-165	Drive shaft pinion T wrench				35		
5Z-193	Spindle cone adjusting open end wrench				35		
5Z-195	3/4" open end wrench				20		
5Z-196	Rear axle entering wrench				35		
5Z-197	Rear spring perch open end wrench				1 00		
5Z-204	Exhaust pack nut open end wrench				80		
5Z-209	Connecting rod clamp screw wrench				40		
5Z-210	Fly wheel cap screw wrench				55		
5Z-212-1	Body bracket connecting bolt holding open end wrench 3/8"				25		
5Z-212-2	Body bracket connecting bolt holding open end wrench 1/2"				25		
5Z-232	Spindle arm bushing driver				35		
5Z-248	Rear axle nut wrench				1 25		
5Z-280	Valve grinder				50		
5Z-285	3/4" hex. brace wrench				50		
5Z-289-1	Trans. cover bolt and nut brace wrench				50		
5Z-289-2	Rad. stud and C. C. to cyl. nut brace socket wrench				55		
5Z-289-3	Universal ball cap bolt brace wrench				60		
5Z-290	Piston ring squeezer				30		
5Z-314	Transmission clutch disc drum puller				55		
5Z-319	Valve spring lifter				30		
5Z-320	Small time gear puller				75		
5Z-323	Bendix shaft head puller				50		
5Z-325	Con. rod cap bolt nut T wrench with universal joint for No. 4 connecting rod				1 50		
5Z-326	Trans. driven gear puller				1 50		
5Z-361	Large time gear puller				6 00		
5Z-362	Cam gear puller (3-spoke design)				6 00		
5Z-445	Transmission band clamp				15		
5Z-457	Valve seat reamer				2 90		
5Z-806	Generator third brush adj. wrench—double end				10		
5Z-815	C. S. center bearing bolt T socket wrench				50		
5Z-817	Carburetor to flange and generator to cyl. block double end socket wrench				45		
2Z-821	Large time gear nut open end wrench				50		
5Z-829	Trans. band, diff. housing oil plug and C. C. drain plug double end ratchet wrench				40		
5Z-1080	Front spring perch nut L socket wrench				65		
5Z-1156	Headlamp bracket bending iron				1 25		
5Z-1157	Bar for assembling hub brake spring				40		
5Z-1497	Rear wheel puller assembly (replaces 5Z-1176)				2 25		
5Z-1172	Rear wire wheel puller assembly				1 75		
20Z-340-1	Valve seat reamer cutter				1 40		
21Z-356	Valve seat reamer handle				1 50		

†Not subject to regular discount.

Above quantity prices as well as individual prices subject to wholesale trade discount.



Part No.

Name of Part

LIST PRICE	Each
Lots of 10	Lots of 100
per lot	per lot

REPAIR TOOLS—TRUCK

5Z-591	Rear axle nut wrench	\$1 50
5Z-1498	Rear wheel puller assembly (replaces 5 Z 1171)	2 25
TT3389BX	Jack (including handle)	1 75
TT3391X	Jack handle	20
TT4069	Tire iron (large)	40
TT5893X	Spark plug, rim nut and cylinder head bolt wrench	35

COTTER PINS

Fac. No.		
$\frac{3}{8}$ " x 1" cotter pins	421	$\frac{3}{8}$ " x $\frac{1}{2}$ " cotter pins
$\frac{3}{8}$ " x $\frac{3}{4}$ " cotter pins	753	$\frac{3}{8}$ " x $\frac{1}{2}$ " cotter pins
$\frac{1}{2}$ " x 1" cotter pins	82	$\frac{3}{8}$ " x $\frac{5}{8}$ " cotter pins
Price, per dozen		\$0 03
Price per gross		20
Price, per thousand		50

FORD SPECIALTIES

3144SX	Bumper (front) assembly, with fittings	5 7 50
3145SX	Bumper (rear) assembly, with fittings, Roadster	7 50
3146SX	Bumper (rear) assembly, with fittings, Coupe	7 50
3147BSX	Bumper (rear) assembly, with fittings, Tudor, T. C.	7 50
3148SX	Bumper (rear) assembly, with fittings, Fordor	7 50
3102SX	Arm (front bumper) and bracket assy.—R	1 10
3105SX	Arm (front bumper) and bracket assy.—L	1 10
3123SX	Arm (rear bumper) reinforcement and bracket assy.—R, Road., Cp	1 25
3127SX	Arm (rear bumper) reinforcement and bracket assy.—L, Road., Cp	1 25
3134SX	Arm (rear bumper) reinforcement and bracket assy.—R, Tudor, Tc., Fordor	1 25
3135SX	Arm (rear bumper) reinforcement and bracket assy.—L, Tudor, T. C., Fordor	1 25
526X	Bolt (front bumper arm bracket to frame)	03
526X	Bolt (rear bumper arm bracket to frame cross member)	03
526X	Bolt (rear bumper arm reinforcement to cross member)	03
2431X	Bolt (front and rear bumper arm to frame) (order 3602E)	
2431X	Bolt (front and rear bumper arm bracket to frame bolt, rear) (order 3602E)	
3111SX	Bolt (bumper rail end clamp)	05
3140SX	Bolt (rear bumper arm spacer) Road	10
3136SX	Bolt (rear bumper arm spacer) Coupe	10
3143SX	Bolt (rear bumper arm spacer) Tudor, T. C.	05
3141SX	Bolt (rear bumper arm spacer) Fordor	10
3113SX	Clamp (bumper rail center) assy.	25
3114SX	Clamp (bumper rail center) inner	05
3109SX	Clamp (bumper rail end) outer	30
3110SX	Clamp (bumper rail end) inner	15
926X	Nut (bumper rail center clamp bolt) (order 3518)	
78X	Nut (bumper rail end clamp bolt) (order 2549)	
339X	Nut (front bumper arm bracket to frame bolt) rear (order 4817B)	
339X	Nut (front and rear bumper arm to frame bolt) (order 4817B)	
339X	Nut (rear bumper arm spacer bolt) (order 4817B)	
517X	Nut (rear bumper arm bracket to cross member bolt) (order 3066B)	
517X	Nut (rear bumper arm reinforcement to cross member bolt) (order 3066B)	
3139SX	Plate (rear bumper arm spacer) Roadster	05
3142SX	Plate (rear bumper arm spacer) Fordor	02
3112SX	Rail (bumper)	1 75
3138SX	Spacer (rear bumper arm) Roadster, Tudor, T. C., Fordor	04
3137SX	Spacer (rear bumper arm) Coupe	04
1599X	Washer (bumper rail center clamp bolt lock) (order 4864)	
2823X	Washer (bumper rail end clamp bolt lock) (order 2550)	
1943X	Washer (rear bumper arm spacer bolt lock) (order 4806C)	
1943X	Washer (rear bumper arm reinforcement to cross member bolt) (order 4806C)	
2372X	Washer (rear bumper arm spacer bolt plain) Tudor, T. C.	1 00
5636X	Washer (front bumper arm bracket to frame bolt) rear (order 3078C)	02
5636X	Washer (front and rear bumper arm to frame bolt) (order 3078C)	
5636X	Washer (rear bumper arm spacer bolt lock) (order 3078C)	
5773X	Cap (dash lamp)	10
7962ARX	Kit (Tire repair)	2 25
5761X	Lamp (dash)	5 50
3180SX	Lamp (stop and tail) with switch and wiring	50 00
5314X	Bolt (stop lamp switch clamp)	75
6520X	Bulb (tail lamp) 6-8 volt—3 cp—single contact	1 60
3178X	Bulb (stop lamp) 6 volt—21 cp—single contact (also for headlamps for Lincoln and other cars using single contact 6 volt bulb)	15 00
3198SX	Nut (tail and stop lamp to bracket)	2 80
3200SX	Lens (tail and stop lamp—red) and cover assy.	27 00
3164BSX	Lens (tail and stop lamp—white)	01
472BX	Nut (stop lamp switch clamp bolt) order 3210	50
6029X	Nut (stop lamp switch terminal bolt)	10
6592X	Plug (tail and stop lamp) and thimble	01
910X	Screw (tail and stop lamp white lens retainer) (order 3505)	80

Above quantity prices as well as individual prices subject to wholesale trade discount.

Part No.	Name of Part	Year	LIST PRICE		Each
			Lots of 10	Lots of 100	

FORD SPECIALTIES—Continued

3222SX	Screw (tail and stop lamp cover)		\$0 75	\$0 01	
3158SX	Switch (stop lamp) assy.			40	
1565X	Washer (tail and stop lamp to bracket) (order 3261C)				
7696X	Washer (stop lamp switch terminal bolt lock) (order 6266)				
3184SX	Wire (stop lamp switch to lamp) assy.			25	
3182SX	Wire (stop lamp switch to terminal block) assy.			10	
18259X	Mirror (rear view) assy.—closed cars		**\$6 00	75	
7853X	Mirror (rear view) assy.—open cars		**6 00	75	
18253X	Mirror (rear view) only		3 50	30 00	40
17442SX	Mirror bracket bolt and nut assy.			10	
17343X	Nut (windshield wiper)			02	
3251BRX	Wing (W. S.) assembly—R			3 25	
3252BRX	Wing (W. S.) assembly—L			3 25	
50229X	Wiper (windshield)		*4 00	50	
18257X	Wiper (windshield)		*4 00	50	
3318SX	Wiper (automatic W. S.)—closed cars		26 50	250 00	3 50
3320SX	Wiper (automatic W. S.)—open cars		26 50	250 00	3 50
3331SX	Arm (automatic windshield wiper) assy.			20	
3332SX	Blade (automatic windshield wiper) assy.			30	
3325SX	Connection (automatic windshield wiper hose)			03	
3329SX	Screw (automatic windshield wiper blade attachment)			01	
3319SX	Tube (automatic windshield wiper rubber)			35	



FORD PAINTS AND POLISHES

M-255	Dressing (top) 1 pt.	6 00	65
M-165	Enamel (black) 1 qt.	9 00	1 00
M-136	Enamel (casino) ½ pt.		35
M-392	Enamel (channel green) 1 qt.		1 25
M-140	Enamel (emerald green) ½ pt.		35
M-393	Enamel (Windsor maroon) 1 qt.		1 75
M-639	Glaze (pyroxylin) ½ pt.		65
M-626	Ground (royal maroon pyroxylin) 1 gal.		7 75
M-230	Polish (body) 12 oz. bottle.		75
M-216	Polish (nickel) 1 lb.		50
M-638	Primer (pyroxylin) 1 gal.		5 75
M-632	Pyroxylin (black) (old No. M-127) 1 gal.		7 25
M-628	Pyroxylin (casino red—for wire wheels) 1 pt.		1 20
M-608	Pyroxylin (commercial green) 1 gal.		7 25
M-637	Pyroxylin (drake green) (old No. M-123) 1 gal.		7 25
M-629	Pyroxylin (emerald green—for wire wheels) 1 pt.		1 20
M-631	Pyroxylin (gunmetal blue) 1 gal.		7 25
M-633	Pyroxylin (highland green) 1 gal.		7 25
M-635	Pyroxylin (fawn gray) 1 gal.		7 25
M-640	Pyroxylin (moleskin) (old No. M-125) 1 gal.		7 25
M-634	Pyroxylin (phoenix brown) 1 gal.		7 25
M-636	Pyroxylin (royal maroon) 1 gal.		9 00
M-627	Pyroxylin (straw—for wire wheels) 1 pt.		1 20
M-644	Striping (champagne) (old No. M-118) ½ pt.		65
M-643	Striping (cream pyroxylin) ½ pt.		75
M-642	Striping (emerald green pyroxylin) (old No. M-109) ½ pt.		65

†Closed cars 1924-25—Open cars 1924-27.

‡Closed cars 1926-27.


*Quantity prices apply to any assortment of 18257X and 50229X totalling required amount.

**Quantity prices apply to any assortment of 18259X and 7853X totalling required amount.

†For wire wheels.

†Quantity prices apply to any assortment of 3318SX and 3320SX totalling required amount.

Above quantity prices as well as individual prices subject to wholesale trade discount.




Part No.	Name of Part	Year	LIST PRICE		Each
			Lots of 10	Lots of 100	

FORD PAINTS AND POLISHES—Continued

M-641	Striping (orange pyroxylin) ½ pt.			\$ 0 65	
M-646	Striping (vermillion pyroxylin) ½ pt.			65	
M-640	Surfacer (pyroxylin) 1 qt.			1 60	
M-647S	Thinner (pyroxylin) 5 gal.			17 50	
M-111	Touch-up (black) ½ pt.		\$9 00	1 00	
M-193	Touch-up (drake green pyroxylin) ½ pt.			55	
M-194	Touch-up (moleskin pyroxylin) ½ pt.			55	
M-430	Varnish (spar) 1 qt.			1 00	
M-401	Varnish (tack rag) 1 pt.			55	

ELECTRIC HORN

6437DX	Bracket (horn)	1915-27		10
6432DX	Horn—battery type	1915-27	13 50	1 50
6432EX	Horn—magneto type	1915-27	13 50	1 50
8028X	Switch (horn) assembly	1915-27	2 50	30
7917BRX	Wire (electric horn to switch)—35 ½"	1917-27		10
7917CX	Wire (horn to switch)	1926-27		10




ELECTRIC HEADLAMPS

6504X	Bolt (headlamp bracket swivel)	1926-27	\$0 03	
8846X	Bolt (headlamp to fender bracket)	1926-27	Order 5151	
6572AX	Bulb (headlamp) 9 volt—18 c. p.—double contact—used with magneto without dimmer	1915-18	27 50	30
6572HX	Bulb (headlamp) 6-8 volt—bright, 21 c. p. dim. 1½ c. p.—double contact—double filament—used with T6576HX lens.	1919-27	3 40	31 00
6572KX	Bulb (headlamp) 6-8 volt—21 c. p.—double contact—used with dimmer T8892X without starter or dimmer T7320X with starter and T6576HX lens.	1917-27	2 80	27 00
3178X	Bulb (stop lamp) 6 volt—21 c. p. single contact (also for headlamps for Lincolns and other cars using single contact 6 volt bulb)	1926-27	2 80	27 00
9122X	Bushing (headlamp wire)			03
4082X	Bushing (headlamp and tail lamp wire)			01
8892ARX	Coil (dimmer resistance) with wires.	1918-22		50

Above quantity prices as well as individual prices subject to wholesale trade discount.

Part No.	Name of Part	Year	LIST PRICE Lots of 10 per lot	LIST PRICE Lots of 100 per lot	Each
ELECTRIC HEADLAMPS—Continued					
*889RXX	Cover (dimmer)	1922-27			\$ 0 10
*8892BX	Dimmer assembly	1922-27			50
8892CX	Dimmer assembly	1926-27			50
6594HX	Door assembly with refracting lens	1922-27	\$5 50		65
6594JX	Door (head lamp) assy.—nickel	1926-27			1 00
6575AX	Door (less lens)	1915-25	3 10	\$28 50	40
6575BX	Door (less lens) nickel	1926-27			75
6578X	Gasket (door lens)	1915-25			03
6511HX	Headlamp assembly—R or L—cars with starter	1915-26		pr.	5 50
6511KX	Headlamp assembly—R or L—cars without starter	1915-26		pr.	5 50
6501ARX	Headlamp assembly—R	1926			3 25
6501CRX	Headlamp assembly—L	1926			25
6511MX	Headlamp assembly—R or L—cars with starter	1926-27		pr.	00
6511NRX	Headlamp assembly—R or L—cars without starter	1926-27		pr.	00
6576HX	Lens (headlamp) refracting—in carton—pair	1915-27		45 00	50
29X	Nut (headlamp to fender bracket bolt)	1909-27	Order 2825B		
339X	Nut (headlamp swivel bolt)	1926-27	Order 4817B		
6592X	Plug—with thimble	1915-27	80	7 00	10
6590AX	Reflector assembly	1915-27	5 00		75
6590BX	Reflector (dimmer type)	1919-21			90
6517X	Rod (headlamp tie) and bracket assembly	1926-27			75
6580X	Screw (focusing)				03
6574AX	Socket (bulb)	1915-25	1 25		15
6574BX	Socket (headlamp plug)	1919-20			15
6591X	Spring (focusing screw)	1915-27			01
6586X	Spring (reflector)	1915-27			05
6589RX	Switch assembly—with screws	1915-17			30
8050RX	Switch (headlamp and horn) assembly	1918-22			40
6509X	Washer (headlamp bracket—conical)	1926-27			02
1943X	Washer (headlamp to fender bracket bolt)		Order 4866C		
7489RX	Wire (lamp to lamp) 40" long	1915-22			10

**SIDE AND TAIL LAMPS**


6403DX	Body (electric tail lamp)	1924-27			10
6520X	Bulb (tail lamp and headlamp dimmer) 6-8 volt—2 1/4 c. p.—single contact	1919-27	1 60	15 00	20
6460X	Burner (lamp)	1915-27			25
6409X	Bushing (tail lamp wire) assembly	1919-27			03
2107X	Clip (tail lamp wire)	1919-27			01
6956X	Door (side oil lamp)	1915-27			50
6957AX	Door (tail lamp)	1916-22			50
6957BX	Door (tail lamp)	1923-27			50
6599X	Mount (side oil and tail lamp)	1915-27			50
6414BX	Gasket (electric tail lamp)	1923-27			02
6568ARX	Lamp (tail)	1915-23	2 50		2 50
6568BX	Lamp (tail) oil	1923-27			2 50
7669RX	Lamp (electric tail) assembly	1919-23	8 00		90
8786CX	Lamp (electric tail) and license bracket assy.—including lamp	1924-27	6 00		90
6561RX	Lamp (side oil) per pair	1915-27			4 50
6484BRX	Lens (electric tail lamp) red	1919-23		10 00	15
6484CX	Lens (electric tail lamp) red—celluloid	1923-25			03
6484DX	Lens (electric tail lamp) side—red	1924-27			10
6405CX	Lens (electric tail lamp) white	1924-27			15
6405EX	Lens (oil tail lamp door) white—Edmunds & Jones design	1924-27			15
6405FX	Lens (oil tail lamp door) white—J. W. Brown design	1924-25			15
6483BX	Lens (side oil lamp door)	1915-27			15
6484ARX	Lens (tail lamp) red	1915-27			15
6406ARX	Retainer (electric tail lamp white lens)	1923			05

*Used on cars without starter with switch on instrument panel.

†Used as left hand lamp by changing position of door.

Above quantity prices as well as individual prices subject to wholesale trade discount.

Part No.	Name of Part	Year	LIST PRICE Lots of 10 per lot	LIST PRICE Lots of 100 per lot	Each
6406BX	Retainer (electric tail lamp body and lens)	1923-27			\$0 05
64954RX	Socket (electric tail lamp bulb)	1919-23			15
6495DX	Socket (electric tail lamp bulb) assembly	1924-27			15
2108X	Spring (tail lamp wire)	1920-27			03
6410X	Support (tail lamp wire bushing)	1919-27			01
6426X	Terminal (tail lamp wire)	1924-27			01
778821RX	Wire (tail lamp to ground) assembly				15
6392X	Wick (lamp)	1915-27			05

**TOURING CAR AND ROADSTER WINDSHIELDS—1915-22**

7810X	Bolt (windshield hinge)	1915-16			10
7845ARX	Bracket (windshield) right	1915-22			50
7845BX	Bracket (windshield) right	1919-22			50
7846ARX	Bracket (windshield) left	1915-22			50
7846BX	Bracket (windshield) left	1919-22			50
7824ARX	Clamp (windshield glass)	1915-22			02
7839X	Filler block (windshield frame)	1915-17			25
7803ARX	Filler block (windshield lower frame)	1915-22			20
7888ARX	Filler block (windshield upper frame)	1917-22			1 50
7820BX	Frame (windshield) assembly—upper	1915-22			1 00
7802ARX	Frame (windshield) only—lower	1917-22			75
7887X	Frame (windshield) upper	1915-22			3 00
7828RX	Glass (windshield) lower	1915-22			2 55
7827ARX	Glass (windshield) upper	1917-22			50
7819BX	Hinge (windshield) assembly—left	1917-22			50
7818BX	Hinge (windshield) assembly—right	1917-22			02
8827X	Loop (windshield top snap)	1915-22			01
1154X	Nut (windshield hinge bolt)	1915-22	Order 3929C		\$0 75
2449BX	Screw (windshield glass clamp)	1915-22			1 00
2257BX	Screw (windshield hinge to frame)	1915-22			02
292X	Spring (windshield hinge)		Order 2742		
7851ARX	Stop (windshield upper glass) nickel	1915-22			20
7852ARX	Stop (windshield lower glass) nickel	1915-22			20
7808X	Thimble (windshield hinge)	1915-22			03
7840ARX	Windshield assembly				10 00
7823ARX	Windshield assembly—lower half	1915-22			4 75
7822BX	Windshield assembly—upper half	1917-22			4 00

TOURING CAR AND ROADSTER WINDSHIELDS—1922-25

7836RX	Anti-rattler (windshield)	1922-25			15
*8064X	Bolt (windshield bracket to body)	1922-25		1 00	02
6645X	Bolt (windshield bracket to instrument panel)	1922-25		1 00	03
7837RX	Bracket (windshield) assembly—R. H.	1922-25			60
7838RX	Bracket (windshield) assembly—L. H.	1922-25			60
7891X	Bracket (side oil lamp)	1922-25			30
9066X	Channel (windshield) center	1922-25			35
7816RX	Cone (windshield frame)	1922-25			15
7888BX	Filler (windshield upper frame) lower	1922-25			05
7847RX	Filler (windshield upper frame) upper	1922-25			05
7803BRX	Filler (windshield lower frame)	1922-25			10
7802BRX	Frame (windshield) assembly—lower	1922-25			1 00
7887CRX	Frame (windshield) assembly—upper	1922-25			1 00
9534X	Glass (windshield) lower	1922-25			2 55
7827BRX	Glass (windshield) upper	1922-25			2 35
1507RX	Nut (windshield bracket to instrument panel bolt) lower	1922-25		2 00	05
7825X	Nut (windshield clamp stud wing)	1922-23			15
7842X	Nut (windshield cone lock)	1922-25			02
7852BRX	Retainer (windshield glass) lower	1922-25			15
7851BX	Retainer (windshield glass) upper	1922-25			03
7826RX	Stud (windshield frame clamping)	1922-25			50
7833X	Washer (windshield clamp stud nut)	1922-25			01
7840BRX	Windshield assembly	1922-25			10 00
7823BRX	Windshield assembly—lower half	1922-25			4 00
7822CX	Windshield assembly—upper half	1922-25			4 10

*Used on cars without starter.

Above quantity prices as well as individual prices subject to wholesale trade discount.

Part No.	Name of Part	Year	LIST PRICE		Each
			Lots of 10 per lot	Lots of 100 per lot	
TOURING CAR AND ROADSTER WINDSHIELDS—1926-27					
40325X	Bracket (windshield) assembly—right	1926-27			\$0 75
40326X	Bracket (windshield) assembly—left	1926-27			75
40324X	Channel (windshield) center	1926-27			35
40315X	Clamp (windshield glass)	1926-27			05
7816X	Cone (windshield bracket)	1926-27			15
41128X	Fastener (windshield bracket curtain) male	1926-27			03
40306X	Filler (windshield lower frame)	1926-27			10
40319X	Filler (windshield upper frame) lower	1926-27			05
40318X	Filler (windshield upper frame) upper	1926-27			05
40303X	Frame (windshield lower) assembly	1926-27			1 00
40320X	Frame (windshield upper) assembly	1926-27			1 00
40308	Glass (windshield) lower	1926-27			2 30
40323	Glass (windshield) upper	1926-27			2 55
7825X	Nut (windshield bracket stud)	1926-27			15
7842X	Nut (windshield cone lock)	1926-27			02
17329X	Screw (windshield glass clamp)	1926-27			02
45520AX	Strip (windshield glass retaining) upper—use with thick glass	1926-27			10
45520BX	Strip (windshield glass retaining) upper—use with thin glass	1926-27			10
45521AX	Strip (windshield glass retaining) lower—use with thick glass	1926-27			10
45521BX	Strip (windshield glass retaining) lower—use with thin glass	1926-27			10
40317X	Stud (windshield clamping)	1926-27			03
7833X	Washer (windshield bracket stud)	1926-27		50	01
40314X	Weatherstrip (windshield) bottom	1926-27			25
40312X	Weatherstrip (windshield) lower	1926-27			05
40313X	Weatherstrip (windshield) upper	1926-27			05
40328	Windshield assembly—lower	1926-27			4 15
40327	Windshield assembly—upper	1926-27			4 10
40300	Windshield assembly	1926-27			11 00

***TOURING CAR TOPS—1915-22**

3897X	Bow (touring car) wood	1913-17			60
6694hX	Celluloid (side curtain) 20"x50"—.010" thick (Old No. 6682X)	1913-22			1 50
6683X	Celluloid (back curtain) 20"x50"—.020" thick	1913-22			2 25
8902RX	Cotter (rib socket)	1918-22			02
6882ARX	Curtain (touring car storm) right	1913-22			1 75
6883ARX	Curtain (touring car storm) left	1913-22			1 75
6940ARX	Curtain (back) and stay assembly	1915-22			3 00
4966BRX	Curtain (touring car side) right	1915-22			2 00
4967BRX	Curtain (touring car side) left	1915-22			2 00
6894ARX	Deck (touring car center) complete	1915-22			7 00
8940X	Eyelet (curtain fastener)	1917-22			\$0 75
8937X	Fastener (touring car top snap) single	1917-22			3 50
8938X	Fastener (touring car top snap) double	1917-22			3 50
7831ARX	Hook (curtain to windshield)	1915-22			05
7832X	Hook (curtain to body)	1915-22			02
8624X	Nut (touring car bow socket to seat iron) japanned	1913-22			1 00
6815ARX	Pad (touring car side quarter)	1915-22			1 00
3314ARX	Rest (touring car top prop) with strap	1913-22			60
3858X	Rest (touring car top prop arm)	1913-21			25
41032X	Rib touring car front and rear extension	1918-22			30
8974ARX	Rib touring car front and rear upright	1918-22			30
6832X	Separator (bow)	1918-22			05
6860BRX	Socket (touring car front extension rib) right	1918-22			1 00
6861BRX	Socket (touring car front extension rib) left	1918-22			1 00
3884BRX	Socket (touring car rear extension rib) right	1918-22			1 00
3885BRX	Socket (touring car rear extension rib) left	1918-22			1 00
6862BRX	Socket (touring car front upright rib) right	1918-22			1 00
6863BRX	Socket (touring car front upright rib) left	1918-22			1 00
3882BRX	Socket (touring car rear upright rib) right	1918-22			1 00
3883BRX	Socket (touring car rear upright rib) left	1918-22			1 00
3924RX	Strap (touring car top to windshield) assembly	1915-22			20
3629ARX	Strap (touring car stay) assembly—complete	1913-21			35
3629BRX	Strap (stay) assembly	1921-22			25
6829BX	Support (touring car extension) upper	1918-22			10
6830BX	Support (touring car extension) lower	1918-22			05
7940ARX	Top (touring car) complete	1915-22			†27 00
4681ARX	Visor (touring car top)	1920-22			50
8945X	Washer (curtain fastener eyelet)	1917-22			50

TOURING CAR TOPS—1922-25

3573X	Brace (top extension) right	1922-25			25
3574X	Brace (top extension) left	1922-25			25
**3588X	Bracket (top clamping) assembly	1922-25			20
**6902X	Button (glove fastener)	1922-25			02
6882BX	Curtain (front side) assembly—right	1922-25			1 75
6883BX	Curtain (front side) assembly—left	1922-25			1 85

†Not subject to regular discount.

**Also used on 1922-25 Roadster Top.

*Service Dealers' discount applies on Touring Car and Roadster top parts to shops specializing in top repairs.

Above quantity prices as well as individual prices subject to wholesale trade discount.

Part No.	Name of Part	Year	LIST PRICE		Each
			Lots of 10 per lot	Lots of 100 per lot	
††6940BRX	Curtain (rear) assembly	1922			\$2 50
6940CRX	Curtain (rear) assembly	1922-25			2 50
††4966CRX	Curtain (rear side) assembly—right	1922			2 00
4966DRX	Curtain (rear side) assembly—right	1922-25			1 75
††4967CRX	Curtain (rear side) assembly—left	1922			2 00
4967DRX	Curtain (rear side) assembly—left	1922-25			1 75
††6894BRX	Deck (top) assembly	1922			6 50
6894CX	Deck (top) assembly	1922-25			6 50
**6903X	Eyelet (side curtain rear glove fastener)	1922-25			02
**6904X	Fastener (rear curtain glove)	1922-25			02
**7831BRX	Hook (curtain to windshield)	1922-25			02
6815BX	Pad (top side quarter) assembly	1922-25			1 00
3314BX	Rest (prop) and strap assembly	1922-25			60
8975RX	Rib (top center and rear)	1922-25			30
8974BX	Rib (top center extension)	1922-25			30
8973BRX	Rib (top front)	1922-25			30
**3548X	Screw (front socket fastener)	1922-25		doz.	05
6890CRX	Socket (top rib) front—right	1922-25	\$8 00		1 00
6861CRX	Socket (top rib) front—left	1922-25	8 00		1 00
3882CRX	Socket (top rib) center—right	1922-25	9 00		1 00
3883CRX	Socket (top rib) center—left	1922-25	9 00		1 00
††3884CRX	Socket (top rib) rear—right	1922			1 25
3884DRX	Socket (top rib) rear—right	1922-25	9 00		1 00
††3885CRX	Socket (top rib) rear—left	1922			1 25
3885DRX	Socket (top rib) rear—left	1922-25	9 00		1 00
6892CRX	Socket (top rib) center extension—right	1922-25	8 00		1 00
6863CRX	Socket (top rib) center extension—left	1922-25	8 00		1 00
6844BX	Strainer (top center)	1922-25			40
6845AX	Strainer (top quarter)	1922-25			40
**3629CX	Strap (stay)	1922-25			20
**6901RX	Stud (rear curtain glove fastener)	1922-25			02
3572RX	Support (center extension to brace)	1922-25			05
3551RX	Support (center) on rear socket	1922-25			05
3564RX	Support (center extension) on center socket	1922-25			05
7940BX	Top assembly	1922-25	†250 00		†27 00
**4981BRX	Visor (top) assembly	1922-23			75
**6305X	Washer (side curtain rear glove fastener)	1922-25			02

TOURING CAR TOPS—1926-27

41022X	Brace (front) right	1926-27			25
41023X	Brace (front) left	1926-27			25
41024X	Brace (center)	1926-27			15
41042X	Brace (rear) right	1926-27			25
41043X	Brace (rear) left	1926-27			25
*3588X	Bracket (top clamping) assembly	1926-27			20
*41100ARX	Curtain (front side) assembly—right	1926-27			2 25
*41100BRX	Curtain (front side) assembly—right	1926-27			2 25
*41100CX	Curtain (front side) assembly—left	1926-27			2 25
*41101ARX	Curtain (front side) assembly—left	1926-27			2 25
*41101BRX	Curtain (front side) assembly—left	1926-27			2 25
*41101CX	Curtain (front side) assembly—left	1926-27			2 25
*41102ARX	Curtain (center side) assembly—right	1926-27			2 25
*41102BRX	Curtain (center side) assembly—right	1926-27			2 25
*41102CX	Curtain (center side) assembly—left	1926-27			2 25
*41103ARX	Curtain (center side) assembly—left	1926-27			2 25
*41103BRX	Curtain (center side) assembly—left	1926-27			2 25
*41103CX	Curtain (center side) assembly—left	1926-27			1 00
*41104ARX	Curtain (rear side) assembly—right	1926-27			1 00
*41104BRX	Curtain (rear side) assembly—right	1926-27			1 00
*41104CX	Curtain (rear side) assembly—right	1926-27			1 00
*41105ARX	Curtain (rear side) assembly—left	1926-27			1 00
*41105BRX	Curtain (rear side) assembly—left	1926-27			1 00
*41105CX	Curtain (rear side) assembly—left	1926-27			3 00
*41106X	Curtain (back) assembly	1926-27			1 10
*41097SX	Curtain (gypsy) front—right	1926-27			1 10
*41098SX	Curtain (gypsy) front—left	1926-27			6 50
*41110ARX	Deck (top) assembly	1926-27			6 50
*41110BX	Deck (top) assembly	1926-27			05
*8937X	Fastener (No. 1 socket screw base snap)	1926-27		\$3 50	03
*41128X	Fastener (windshield bracket lift the dot) male	1926-27			4 00
41114AX	Hood (dust) with straps	1926-27			02
*7832X	Hook (curtain to body)	1926-27			30
*41032X	Rib (No. 1)	1926-27			30
*41033X	Rib (No. 2)	1926-27			30
*41034X	Rib (No. 3)	1926-27			30
*41035X	Rib (No. 4)	1926-27			01
41040X	Ring (brace support pin)	1926-27			20
*41045X	Rod (curtain) front—right	1926-27			20
*41046X	Rod (curtain) front—left	1926-27			20
*41047X	Rod (curtain) rear—right	1926-27			20
*41048X	Rod (curtain) rear—left	1926-27			1 00
*41008X	Socket (No. 1) right and left	1926-27			

*Also used on 1926-27 Roadster Top.

**Also used on 1922-25 Roadster Top.

†Not subject to regular discount.

††Used on tops with straight side quarters.
Above quantity prices as well as individual prices subject to wholesale trade discount

Part No.	Name of Part	Year	LIST PRICE		Each
			Lots of 10	Lots of 100	

TOURING CAR TOPS—1926-27—Continued

41002X	Socket (No. 2) right	1926-27			\$1 00
41003X	Socket (No. 2) left	1926-27			1 00
41004X	Socket (No. 3) right and left	1926-27			1 00
41005X	Socket (No. 4) right	1926-27			1 50
41006X	Socket (No. 4) left	1926-27			1 50
*41199SX	Spring (gypsy curtain—front) hook and clip assembly	1926-27			15
*45832X	Strip (back curtain finishing)	1926-27			15
*6844BX	Strainer (center)	1926-27			40
*3629CX	Strap (stay)	1926-27			20
*3576X	Tip (binding finishing)	1926-27			02
*41011X	Top assembly—including curtains and curtain rods	1926-27			127 00
41158X	Visor assembly	1926-27			75

ROADSTER TOP PARTS—1915-22

6937ARX	Curtain (Roadster side) rear—right	1915-22			1 25
6938ARX	Curtain (Roadster side) rear—left	1915-22			1 25
6935ARX	Curtain (Roadster side) front—right	1915-22			1 50
6936ARX	Curtain (Roadster side) front—left	1915-22			1 50
6950ARX	Curtain (Roadster back) assembly	1915-22			2 40
6964ARX	Deck (Roadster center) complete	1915-22			4 50
69071X	Pad (Roadster side quarter)	1914-22			60
3577X	Rest (Roadster prop) with strap	1913-22			60
3772X	Rib (upright)	1918-22			30
3988ARX	Rib (front extension)	1918-22			30
3989ARX	Rib (rear extension)	1918-22			30
6870BX	Socket (Roadster rib) upright—right	1918-22			1 00
6871BX	Socket (Roadster rib) upright—left	1918-22			1 00
6872BX	Socket (Roadster rib) front extension—right	1918-22			1 00
6873BX	Socket (Roadster rib) front extension—left	1918-22			1 00
4907BX	Socket (Roadster rib) rear extension—right	1918-22			1 00
4908BX	Socket (Roadster rib) rear extension—left	1918-22			1 00
7941ARX	Top (Roadster) complete	1915-22			1 00
					222 00

ROADSTER TOPS—1922-25

6935BRX	Curtain (front side) assembly—right	1922-25			1 25
6936BRX	Curtain (front side) assembly—left	1922-25			1 35
6937BRX	Curtain (rear side) assembly—right	1922-25			90
6938BRX	Curtain (rear side) assembly—left	1922-25			90
6950BRX	Curtain (rear) assembly	1922-25			2 50
6965BRX	Deck (top) assembly	1922-25			3 50
6806BX	Pad (top side quarter) assembly	1922-25			60
6889BRX	Rib (top) center and rear	1922-25			35
6888BRX	Rib (top) front	1922-25			35
6870CRX	Socket (top rib) center—right	1922-25	\$8 00		1 00
6871CRX	Socket (top rib) center—left	1922-25	8 00		1 00
6872CRX	Socket (top rib) front	1922-25	8 00		1 00
4907CRX	Socket (top rib) rear—right	1922-25	9 00		1 00
4908CRX	Socket (top rib) rear—left	1922-25	9 00		1 00
7941BX	Top assembly	1922-25	200 00		222 00

ROADSTER TOPS—1926-27

41067ARX	Curtain (rear side) assembly—right	1926-27			1 00
41067BRX	Curtain (rear side) assembly—left	1926-27			1 00
41067CX	Curtain (rear side) assembly—right	1926-27			1 00
41068ARX	Curtain (rear side) assembly—left	1926-27			1 00
41068BRX	Curtain (rear side) assembly—left	1926-27			1 00
41068CX	Curtain (rear side) assembly—left	1926-27			1 00
41069X	Curtain (back) assembly	1926-27			1 00
41070ARX	Deck assembly	1926-27			2 50
41070BX	Deck assembly	1926-27			3 50
41077AX	Hood (dust) with straps	1926-27			3 50
3876BX	Rest (prop) and strap assembly	1926-27			4 00
8974BX	Rib (Nos. 2 and 3)	1926-27			60
41055X	Socket (No. 1)	1926-27			30
41056X	Socket (No. 2) right	1926-27			1 00
41057X	Socket (No. 2) left	1926-27			1 00
41058X	Socket (No. 3) right	1926-27			1 00
41059X	Socket (No. 3) left	1926-27			1 00
41049X	Top assembly—including curtains and curtain rods	1926-27			122 00


†Not subject to regular discount.

*Also used on 1926-27 Roadster Top.

†For additional 1922-25 Roadster Top parts see 1922-25 Touring Car Top parts marked with a double asterisk (**).

‡For additional 1926-27 Roadster Top parts see 1926-27 Touring Car Top parts marked with an asterisk (*). Above quantity prices as well as individual prices subject to wholesale trade discount.

Price List of Parts for Model T One Ton Truck



Part No.	Name of Part	Year	LIST PRICE		Each	Model	Fac. No.	No. Req. per Car
			Lots of 10	Lots of 100				

REAR AXLE

REAR AXLE			REAR WHEEL			REAR SPRING		
1000.	Axle assembly—rear 7 ¹ / ₄ to 1	1918-27			\$110 00	TT	95A	1
1000B.	Axle assembly—rear 5 ¹ / ₈ to 1	1918-27			110 00	TT	95B	1
1001.	Axle housing—right	1918-27			15 00	TT	4	1
1002.	Axle housing—left	1918-27			15 00	TT	5	1
1003.	Axle housing bolt	1918-27	\$0 40	\$3 00	05	TT	52	13
1003B.	Axle housing bolt nut	1918-27	Order 2719					
1004.	Axle housing cap	1918-27			40	TT	133	1
1005.	Axle housing cap gasket	1918-27		1 50	02	TT	134	1
1006.	Axle housing cap screw	1918-27	45	4 00	05	TT	72A	4
1007.	Axle housing cap screw lock wire	1918-27			01	TT	140	1
1008.	Axle housing gasket—upper	1918-27	15	1 00	02	TT	138	1
1009.	Axle housing gasket—lower	1918-27	40	3 00	05	TT	139	1
1010.	Axle brake housing plate—right	1918-27			35	TT	147	1
1011.	Axle brake housing plate—left	1919-27			35	TT	148	1
1012.	Axle housing drain plug	1918-27			05	TT	136	2
1013.	Axle shaft	1918-27			4 00	TT	2818	2
1014.	Axle shaft cotter	1918-27		doz.	05	TT	165	2
1015.	Axle shaft nut	1918-27	90	8 00	10	TT	166	2
1016.	Axle shaft washer	1918-27	35	2 50	05	TT	135	2
1017.	Axle shaft dust cap	1918-27			03	TT	56	2
1018.	Axle shaft inner ball bear. assy.	1918-27			5 00	TT	125	2
1019.	Axle shaft outer roller bearing	1918-27	9 00		1 00	TT	253	2
1020.	Axle shaft outer R. B. sleeve—R.	1918-27	3 00		35	TT	170	1
1020B.	Axle shaft outer R. B. sleeve—L.	1918-27	3 00		35	TT	161	4
1021.	Axle shaft bearing felt	1918-27	1 20	10 00	15	TT	143	2
1022.	Axle shaft bearing retainer	1918-27			05	TT	20	2
1023.	Axle shaft bearing retainer washer	1918-27		1 50	02	TT	23	2
1024.	Axle shaft felt retainer assembly	1918-27	1 50		20	TT	144	1
1025.	Axle shaft felt retainer cup	1918-27			03	TT	145	2
1026.	Axle shaft felt retainer plate	1918-27			03	TT	146	2
1026B.	Rear axle oil retainer	1926-27			25	TT	198	2
1027.	Differential gear	1918-27			1 25	TT	13	2
1028B.	Differential gear case—R. or L. half	1923-27			2 50	TT	11B	2


Above quantity prices as well as individual prices subject to wholesale trade discount.

Part No.	Name of Part	Year	LIST PRICE		Each	Model	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot				

REAR AXLE—Continued


REAR AXLE—Continued

1029	Differential gear case bolt	1918-27	Order 1003		\$0 02	TT	118	2
1031	Differential gear lock ring	1918-27			50	TT	14	2
1032	Differential pinion	1918-27			30	TT	15AR	1
1085	Differential pinion shaft	1918-23			1 50	TT	15B	1
1033B	Differential spider	1923-27						



DRIVE SHAFT


1034	Drive shaft	1918-27			7 00	TT	87	1
1036	D. S. tube assembly	1918-27			10 00	TT	153	1
1037	D. S. tube flange gasket	1918-27	\$0 15	\$1 25	02	TT	194	1
1038	D. S. tube flange screw	1918-27	Order 1006					
1039	D. S. felt	1918-27	80		10	TT	109	1
1040	D. S. felt container	1918-27			03	TT	110	1
1041	D. S. to worm coupling	1918-19			70	TT	85A	1
1041B	D. S. to worm coupling	1920-27			70	TT	85B	1
1042	D. S. to worm coupling pin	1918-27			01	TT	86	2



WORM

1043	Worm—7 1/4 to 1	1918-27			6 00	TT	16A	1
1043B	Worm—5 1/2 to 1	1918-27			6 00	TT	16B	1
1044	Worm gear—7 1/4 to 1	1918-27			10 00	TT	12A	1
1044B	Worm gear—5 1/2 to 1	1918-27			10 00	TT	12B	1
1045	Worm cotter	1918-27	Order 1014					
1046	Worm roller bearing	1918-27	6 50		75	TT	108	2
1047	Worm roller bearing retainer	1918-27	Order 1023					
1048	Worm roller bearing sleeve	1918-27	7 50		1 00	TT	107	2
1049	Worm roller bearing housing screw	1918-27			03	TT	101	2
1050	Worm thrust bearing collar	1918-27			50	TT	114	1
1051	Worm thrust ball and sep. assy.	1918-27	5 00		60	TT	123	1
1053	Worm thrust bearing retainer	1918-27	1 25		15	TT	111	1
1054	Worm thrust bearing retainer nut	1918-27	Order 1015					
1055	Worm thrust bearing retainer pin	1918-27	50		01	TT	112	1

Above quantity prices as well as individual prices subject to wholesale trade discount.



Part No.	Name of Part	Year	LIST PRICE		Each	Model	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot				

BRAKE PARTS

1056	Brake shoe	1918-27			\$1 50	TT	2814	2
1057	Brake shoe lining, each	1918-27	\$2 00		25	TT	58	4
1058	Brake shoe lining rivet	1918-27		\$0 75	01	TT	68	40
1059	Brake shoe spring	1918-27	40		05	TT	67	2
1060	Brake shoe bolt	1918-27	80	7 50	10	TT	59	2
1060B	Brake shoe bolt nut	1918-27	Order 2507					
1061	Brake shoe expander lever	1918-27			40	TT	61	2
1062	Brake shoe expander lever	1918-27			15	TT	62	2
1063	Brake shoe expander adj. collar	1918-27			15	TT	175	2
1064	Brake shoe expander adj. collar	1918-27			10	TT	173	2
1065	Brake shoe expander bushing	1918-27			01	TT	7	2
1066	Brake shoe expander pin	1918-25			08	TT	176	4
1067	Brake shoe expander link	1918-27	25	2 00	03	TT	177	8
1068	Brake shoe expander link pin	1918-27			30	TT	119	2
1069	Brake rod	1918-27	60	5 00	10	TT	120	2
1070	Brake rod support—right	1918-27	60	5 00	10	TT	121	1
1071	Brake rod support—left	1918-27	15	1 00	02	T	7181	2
1072	Brake rod support bolt	1918-25						
1072B	Brake rod support bolt nut	1918-27	Order 3088E					

RADIUS ROD


1073	Rear radius rod—right	1918-27			3 00	TT	152	1
1073B	Rear radius rod—left	1918-27			3 00	TT	158	1
1074	Rear radius rod bolt—front	1918-27	85	7 50	10	TT	84	1
1075	Rear radius rod bolt—rear	1918-27	85	7 50	10	TT	83	4
1075B	Rear radius rod bolt nut	1918-27	Order 2507					
1076	Universal joint bushing	1918-27			60	TT	69	1

SPRINGS

REAR SPRING

1077	Rear spring—right or left, each	1918-27			4 00	TT	333	2
1078	Spring leaf No. 1	1918-27	8 00		90	TT	334	2
1079	Spring leaf No. 2	1918-27	4 00		50	TT	362	2
1080	Spring leaf No. 3	1918-27	3 50		45	TT	363	2
1081	Spring leaf No. 4	1918-27	3 00		40	TT	364	2
1082	Spring leaf No. 5	1918-27	2 80		35	TT	365	2
1083	Spring leaf No. 6	1918-27	2 50		30	TT	366	2
1084	Spring leaf No. 7	1918-27	2 30		25	TT	367	2
1085	Spring leaf No. 8	1918-27			20	TT	368	2
1086	Spring leaf No. 9	1918-27			20	TT	331	2
1087	Spring bushing	1918-27			20	TT	172B	2
1088	Spring clip	1918-27			45	TT	326	2
1089	Spring clip nut	1918-27			05	TT	327	2
1091	Spring clip plate	1918-27			20	TT	329	4
1092	Spring tie bolt	1918-27			15	TT	330	2
1093	Spring tie bolt nut	1918-27	Order 1089					
1094	Spring tie bolt cotter	1918-27			*doz. 05	TT	328	2
1095	Spring clamp	1918-27	75		10	TT	375	2
1096	Spring clamp bolt	1918-27	25	2 00	03	TT	376	2
1096B	Spring clamp bolt nut	1918-27	Order 3514					

*\$0.25 gross, \$0.75 per thousand.
Above quantity prices as well as individual prices subject to wholesale trade discount.



Part No.	Name of Part	Year	LIST PRICE		Each	Model	Fac. No.	No. Req. per Car
			Lots of 10	Lots of 100				


SPRINGS—Continued

REAR SPRING—Continued

1097	Spring perch	1918-27	\$8 00		\$0 90	TT	2804	2
1098	Spring perch nut	1918-27	Order 1015					
1099	Spring perch cotter	1918-27	Order 1014					
1100	Spring perch bushing	1918-27	3 00		35	TT	172AR	2
1101	Spring perch bushing spacer	1918-27			10	TT	169	4
1102	Spring hanger assembly	1918-27	2 50		30	TT	91	4

FRONT SPRING (nine-leaf)

1151	Front spring	1926-27	27 50		3 00	TT	332	1
1152	Front spring—first leaf	1926-27	Order 3801B					
1153	Front spring—second leaf	1926-27	Order 3802C					
1154	Front spring—third leaf	1926-27	Order 3803C					
1155	Front spring—fourth leaf	1926-27	Order 3804C					
1156	Front spring—fifth leaf	1926-27	Order 3805C					
1157	Front spring—sixth leaf	1926-27			25	TT	2939	1
1158	Front spring—seventh leaf	1926-27			20	TT	2940	1
1159	Front spring—eighth leaf	1926-27			20	TT	2941	1
1160	Front spring—ninth leaf	1926-27	Order 3807D					
1161	Front spring tie bolt	1926-27			05	TT	1362	1
1162	Front spring tie bolt nut	1926-27	Order 3811B					
1164B	C. C. front bearing and spring clip assembly	1926-27			90	TT	2921	1
1165	Front spring clip bar	1926-27			25	TT	342	1
1166	C. C. front bearing and spring clip nut	1926-27	Order 2507					



WHEELS


1105B	Rear wheel—dem.—Kelsey	1919-24	15 00	TT	7698A	2
1105C	Rear wheel—dem.—Hayes	1919-24	15 00	TT	7698B	2
1105D	Rear wheel—dem.—less rim and hub—Kelsey	1919-24	6 50	TT	2817AR	2
1105E	Rear wheel—dem.—less rim and hub—Hayes	1919-24	6 50	TT	2817BR	2
†1105H	Rear wheel complete—dem.	1924-27	14 75	TT	7698C	
†1105J	Rear wheel—less rim	1924-27	10 75	TT	2815F	
†1105K	Rear wheel—less rim and hub	1924-27	6 50	TT	2817C	
1106C	Dem. rim—Hayes	1919-27	3 50	TT	8774B	2

†30" x 5" wheel.

Above quantity prices as well as individual prices subject to wholesale trade discount.

Part No.	Name of Part	Year	LIST PRICE		Each	Model	Fac. No.	No. Req. per Car
			Lots of 10	Lots of 100				

*1106D	Dem. rim—Kelsey	1922-27			\$ 3 50	TT	8774C	2
1106E	Dem. rim retainer ring—Kelsey	1922-27			45	TT	178	2
†1106F	Dem. rim and flange assy.	1924-27			2 75	TT	8774D	
							TT189	
†1106G	Dem. rim flange	1924-27			90	TT	189	
1107B	Clamp and nut assy.—Kelsey	1919-27	\$1 25		15	TT	8807	12
†1107C	Clamp	1924-27			10	TT	8831D	
1108B	Clamp bolt	1919-24	40	\$3 50	05	TT	8832	12
†1108C	Clamp bolt	1924-27	45	4 00	05	TT	8832B	
†1108D	Clamp nut	1924-27	40	3 50	05	TT	8834B	
1109	Rear wheel complete, less tire	1918-27			17 50	TT	2815A	2
1109B	Rear wheel—solid tire design—less hub and tire	1919-27			13 25	TT	2816	2
1111	Rear hub	1918-27	20 00		2 25	TT	40	2
1112	Rear hub flange	1918-27			40	TT	149	2
1113	Rear hub brake drum	1918-27			1 25	TT	3	2
1114	Rear hub bolt	1918-27	40	3 50	05	TT	28	12
1114B	Rear hub bolt nut	1918-27		1 50	02	TT	29	12
1116	Rear hub cap	1918-27	2 25		25	TT	150	2
1117	Rear hub key	1918-27		2 50	03	TT	26	2
1118	Rear hub felt	1918-27	75	5 50	10	TT	162	2



FRAME

1119	Frame assembly	1918-27	25 00	TT	300	1
1120	Side member—right	1918-27	9 00	TT	301	1
1121	Side member—left	1918-27	9 00	TT	302	1
1122	Front cross member	1918-27	1 00	TT	303	1
1123	Rear cross member	1918-27	4 00	TT	304	1
1124	Front corner bracket—right	1918-27	15	TT	305	1
1125	Front corner bracket—left	1918-27	15	TT	306	1
1125B	Front end spacer—right	1918-27	15	TT	319	1
1125C	Front end spacer—left	1918-27	15	TT	318	1
1126	Rear cross member gusset plate	1918-27	25	TT	307	2
1127	Rear cross member reinforcement	1918-27	35	TT	325	2

TRANSMISSION CONTROL

1133	Speed lever	1918-27	10	TT	862	1
1134	Control shaft with speed lever	1918-27	60	TT	1557	1

†30" x 5" wheel.

*Includes 1106E.

Above quantity prices as well as individual prices subject to wholesale trade discount.

W H HOLMES CO,
BEL AIR
MD

2.50
6.40
6.50
2.25-
8.50
2.60

28.75-

4805